

**OilReset\_Acura\_V1.00 Function List** (Note:For reference only)

YEAR	Vehicle Type	Reset
1996~2012	ALL	reset with tool
1997	2. 2CL	reset without tool
1998	2. 3CL	reset without tool
1996	2. 5TL	reset without tool
1997	3. 0CL	reset without tool
1998	3. 0CL	reset without tool
2001	3. 2CL	reset without tool
2002	3. 2CL	reset without tool
2003	3. 2CL	reset without tool
1996	3. 2TL	reset without tool
1997	3. 2TL	reset without tool
2000	3. 2TL	reset without tool
2001	3. 2TL	reset without tool
2002	3. 2TL	reset without tool
2003	3. 2TL	reset without tool
1996	3. 5RL	reset without tool
1997	3. 5RL	reset without tool
1998	3. 5RL	reset without tool
2000	3. 5RL	reset without tool
2001	3. 5RL	reset without tool
2002	3. 5RL	reset without tool
2003	3. 5RL	reset without tool
2004	3. 5RL	reset without tool
2005	3. 5RL	reset without tool
2006	3. 5RL	reset without tool
2001	MDX	reset without tool
2002	MDX	reset without tool
2003	MDX	reset without tool
2004	MDX	reset without tool
2005	MDX	reset without tool
2006	MDX	reset without tool
2007	MDX	reset without tool
2008	MDX	reset without tool
2009	MDX	reset without tool
2010	MDX	reset without tool
2011	MDX	reset without tool
2012	MDX	reset without tool
2007	RDX	reset without tool

YEAR	Vehicle Type	Reset
2008	RDX	reset without tool
2009	RDX	reset without tool
2010	RDX	reset without tool
2011	RDX	reset without tool
2012	RDX	reset without tool
2007	RL	reset without tool
2008	RL	reset without tool
2009	RL	reset without tool
2010	RL	reset without tool
2011	RL	reset without tool
2012	RL	reset without tool
2002	RSX	reset without tool
2003	RSX	reset without tool
2004	RSX	reset without tool
2005	RSX	reset without tool
2006	RSX	reset without tool
1995	TL	reset without tool
2004	TL	reset without tool
2005	TL	reset without tool
2006	TL	reset without tool
2007	TL	reset without tool
2008	TL	reset without tool
2009	TL	reset without tool
2010	TL	reset without tool
2011	TL	reset without tool
2012	TL	reset without tool
2004	TSX	reset without tool
2005	TSX	reset without tool
2006	TSX	reset without tool
2007	TSX	reset without tool
2008	TSX	reset without tool
2009	TSX	reset without tool
2010	TSX	reset without tool
2011	TSX	reset without tool
2012	TSX	reset without tool
2010	ZDX	reset without tool
2011	ZDX	reset without tool
2012	ZDX	reset without tool