

MaxiDiag_Daewoo_V2.00 Function List (Note:For reference only)

NOTES:

- This function is supported. ✖ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

YEAR	Vhehicle Type	System Type	System Name	Ecu Info.	Read Codes	Erase Codes
(8) 2008	(EP) Epica/Tosca	Engine	2.0L L6 DOHC	●	●	●
(9) 2009	(EP) Epica/Tosca	Engine	2.0L L6 DOHC	●	●	●
(A) 2010	(EP) Epica/Tosca	Engine	2.0L L6 DOHC	●	●	●
(B) 2011	(EP) Epica/Tosca	Engine	2.0L L6 DOHC	●	●	●
(7) 2007	(EP) Epica/Tosca	Engine	2.5L L6 DOHC	●	●	●
(8) 2008	(EP) Epica/Tosca	Engine	2.5L L6 DOHC	●	●	●
(9) 2009	(EP) Epica/Tosca	Engine	2.5L L6 DOHC	●	●	●
(A) 2010	(EP) Epica/Tosca	Engine	2.5L L6 DOHC	●	●	●
(B) 2011	(EP) Epica/Tosca	Engine	2.5L L6 DOHC	●	●	●
(7) 2007	(EP) Epica/Tosca	Chassis	ABS / ETC	●	●	●
(8) 2008	(EP) Epica/Tosca	Chassis	ABS / ETC	●	●	●
(9) 2009	(EP) Epica/Tosca	Chassis	ABS / ETC	●	●	●
(A) 2010	(EP) Epica/Tosca	Chassis	ABS / ETC	●	●	●
(B) 2011	(EP) Epica/Tosca	Chassis	ABS / ETC	●	●	●
(7) 2007	(EP) Epica/Tosca	Transmission	Automatic Transmission	●	●	●
(8) 2008	(EP) Epica/Tosca	Transmission	Automatic Transmission	●	●	●
(9) 2009	(EP) Epica/Tosca	Transmission	Automatic Transmission	●	●	●
(A) 2010	(EP) Epica/Tosca	Transmission	Automatic Transmission	●	●	●
(B) 2011	(EP) Epica/Tosca	Transmission	Automatic Transmission	●	●	●
(1) 2001	(U) Tacuma/Rezzo	Transmission	ZF 4HP16 Automatic Transaxle	●	●	●
(2) 2002	(U) Tacuma/Rezzo	Transmission	ZF 4HP16 Automatic Transaxle	●	●	●
(3) 2003	(U) Tacuma/Rezzo	Transmission	ZF 4HP16 Automatic Transaxle	●	●	●
(X) 1999	(U) Tacuma/Rezzo	Transmission	ZF 4HP16 Automatic Transaxle	●	●	●
(Y) 2000	(U) Tacuma/Rezzo	Transmission	ZF 4HP16 Automatic Transaxle	●	●	●
(1) 2001	(V) Leganza/Evanda	Engine	2.2L L4 DOHC	●	●	●
(2) 2002	(V) Leganza/Evanda	Engine	2.2L L4 DOHC	●	●	●
(3) 2003	(V) Leganza/Evanda	Engine	2.2L L4 DOHC	●	●	●
(4) 2004	(V) Leganza/Evanda	Engine	2.2L L4 DOHC	●	●	●
(X) 1999	(V) Leganza/Evanda	Engine	2.2L L4 DOHC	●	●	●
(Y) 2000	(V) Leganza/Evanda	Engine	2.2L L4 DOHC	●	●	●
(1) 2001	(V) Leganza/Evanda	Chassis	ABS 5		●	●
(2) 2002	(V) Leganza/Evanda	Chassis	ABS 5		●	●
(3) 2003	(V) Leganza/Evanda	Chassis	ABS 5		●	●
(4) 2004	(V) Leganza/Evanda	Chassis	ABS 5		●	●

YEAR	Vehicle Type	System Type	System Name	Ecu Info.	Read Codes	Erase Codes
(X) 1999	(V) Leganza/Evanda	Chassis	ABS 5		●	●
(Y) 2000	(V) Leganza/Evanda	Chassis	ABS 5		●	●
(1) 2001	(V) Leganza/Evanda	Transmission	AISIN 50-40LE Automatic Transaxle		●	●
(2) 2002	(V) Leganza/Evanda	Transmission	AISIN 50-40LE Automatic Transaxle		●	●
(3) 2003	(V) Leganza/Evanda	Transmission	AISIN 50-40LE Automatic Transaxle		●	●
(4) 2004	(V) Leganza/Evanda	Transmission	AISIN 50-40LE Automatic Transaxle		●	●
(X) 1999	(V) Leganza/Evanda	Transmission	AISIN 50-40LE Automatic Transaxle		●	●
(Y) 2000	(V) Leganza/Evanda	Transmission	AISIN 50-40LE Automatic Transaxle		●	●
(1) 2001	(V) Leganza/Evanda	Body	SDM (Airbag)	●	●	●
(2) 2002	(V) Leganza/Evanda	Body	SDM (Airbag)	●	●	●
(3) 2003	(V) Leganza/Evanda	Body	SDM (Airbag)	●	●	●
(4) 2004	(V) Leganza/Evanda	Body	SDM (Airbag)	●	●	●
(X) 1999	(V) Leganza/Evanda	Body	SDM (Airbag)	●	●	●
(Y) 2000	(V) Leganza/Evanda	Body	SDM (Airbag)	●	●	●