

# MaxiDiag\_Holden\_V6.02 Function List (Note:For reference only)

**NOTES:**

- This function is supported.                      ✖ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported.                ▲ This function is the new feature in this version.

Year	Vhehicle Type	System Type	System Name	Subsystem	Ecu Info.	Read Codes	Erase Codes	Live Data
(7) 2007	(EP) Epica/Tosca	Engine	2.0L L6 DOHC		●	●	●	●
(8) 2008- (B) 2011	(EP) Epica/Tosca	Engine	2.0L L6 DOHC (KWP2000)		●	●	●	●
(7) 2007	(EP) Epica/Tosca	Engine	2.5L L6 DOHC		●	●	●	●
(8) 2008- (B) 2011	(EP) Epica/Tosca	Engine	2.5L L6 DOHC (KWP2000)		●	●	●	●
(7) 2007- (B) 2011	(EP) Epica/Tosca	Engine	2.0L L6 DOHC (GMLAN)		●	●	●	●
(8) 2008- (B) 2011	(EP) Epica/Tosca	Engine	2.5L L6 DOHC (GMLAN)		●	●	●	●
(7) 2007- (B) 2011	(EP) Epica/Tosca	Engine	2.0L (Diesel)		●	●	●	●
(7) 2007- (B) 2011	(EP) Epica/Tosca	Chassis	ABS/TC/ESP (Vehicle Dynamic System)		●	●	●	●
(7) 2007- (B) 2011	(EP) Epica/Tosca	Chassis	ABS / ETC		●	●	●	●
(7) 2007- (B) 2011	(EP) Epica/Tosca	Transmission	Automatic Transmission		●	●	●	●
(7) 2007- (B) 2011	(EP) Epica/Tosca	Body	SDM (Sensing and Diagnostic Module)		●	●	●	
(3) 2003- (4) 2004	(J) Lacetti/Optra/Excelle	Engine	1.8L L4 DOHC		●	●	●	●
(3) 2003- (4) 2004	(J) Lacetti/Optra/Excelle	Chassis	ABS		●	●	●	●
(3) 2003- (4) 2004	(J) Lacetti/Optra/Excelle	Body	SDM (Sensing and Diagnostic Module)		●	●	●	
(3) 2003- (4) 2004	(J) Lacetti/Optra/Excelle	Transmission	ZF 4HP16 Automatic Transaxle		●	●	●	●
(X) 1999- (4) 2004	(J) Nubira	Engine	1.6L L4 DOHC			●	●	●
(X) 1999- (4) 2004	(J) Nubira	Engine	2.0L L4 DOHC			●	●	●
(X) 1999- (4) 2004	(J) Nubira	Transmission	4T40-E Automatic Transaxle			●	●	●

Year	Vehicle Type	System Type	System Name	Subsystem	Ecu Info.	Read Codes	Erase Codes	Live Data
(X) 1999- (4) 2004	(J) Nubira	Chassis	ABS 5			●	●	●
(X) 1999- (4) 2004	(J) Nubira	Body	SDM (Airbag)		●	●	●	●
(6) 2006- (9) 2009	(J) Viva	Engine	1.8L L4 DOHC		●	●	●	●
(6) 2006- (9) 2009	(J) Viva	Chassis	ABS		●	●	●	●
(7) 2007- (9) 2009	(J) Viva	Chassis	ABS (Bosch)		●	●	●	●
(6) 2006- (9) 2009	(J) Viva	Body	SDM (Sensing and Diagnostic Module)		●	●	●	
(6) 2006- (9) 2009	(J) Viva	Transmission	ZF 4HP16 Automatic Transaxle		●	●	●	●
(X) 1999- (4) 2004	(M) Matiz/Spark	Engine	0.8L L3 SOHC (12PIN ALDL)		●	●	●	
(X) 1999- (4) 2004	(M) Matiz/Spark	Body	SDM (Sensing and Diagnostic Module)		●	●	●	
(6) 2006- (B) 2011	(T) Barina	Engine	1.6L L4 DOHC		●	●	●	●
(6) 2006- (B) 2011	(T) Barina	Chassis	ABS		●	●	●	●
(6) 2006- (B) 2011	(T) Barina	Transmission	AISIN Automatic Transaxle		●	●	●	●
(6) 2006- (B) 2011	(T) Barina	Body	SDM (Sensing and Diagnostic Module)		●	●	●	
(3) 2003- (4) 2004	(T) Kalos/Aveo	Engine	1.5L L4 SOHC		●	●	●	●
(3) 2003- (4) 2004	(T) Kalos/Aveo	Transmission	AISIN Automatic Transaxle		●	●	●	●
(3) 2003- (4) 2004	(T) Kalos/Aveo	Body	SDM (Sensing and Diagnostic Module)		●	●	●	
(V) 1997- (3) 2003	(T) Lanos	Engine	1.5L L4 SOHC			●	●	●
(V) 1997- (3) 2003	(T) Lanos	Engine	1.6L L4 DOHC			●	●	●
(V) 1997- (3) 2003	(T) Lanos	Transmission	4T40-E Automatic Transaxle			●	●	●
(V) 1997- (3) 2003	(T) Lanos	Body	SDM (Sensing and Diagnostic Module)		●	●	●	
(X) 1999- (2) 2002	(U) Tacuma/Rezzo	Engine	2.0L L4 DOHC			●	●	●
(3) 2003	(U) Tacuma/Rezzo	Engine	2.0L L4 DOHC (ITMS6F)			●	●	●

Year	Vehicle Type	System Type	System Name	Subsystem	Ecu Info.	Read Codes	Erase Codes	Live Data
(X) 1999–(2) 2002	(U) Tacuma/Rezzo	Engine	2.0L L4 DOHC (MR140)		●	●	●	●
(X) 1999–(2) 2002	(U) Tacuma/Rezzo	Chassis	ABS/TC/ESP		●	●	●	●
(X) 1999–(2) 2002	(U) Tacuma/Rezzo	Body	Airbag		●	●	●	●
(X) 1999–(2) 2002	(U) Tacuma/Rezzo	Transmission	ZF 4HP16 Automatic Transaxle		●	●	●	●
(X) 1999–(4) 2004	(V) Leganza/Evanda	Engine	2.2L L4 DOHC		●	●	●	●
(X) 1999–(4) 2004	(V) Leganza/Evanda	Chassis	ABS 5			●	●	●
(X) 1999–(4) 2004	(V) Leganza/Evanda	Transmission	AISIN 50–40LE Automatic Transaxle			●	●	●
(X) 1999–(4) 2004	(V) Leganza/Evanda	Body	SDM (Airbag)		●	●	●	●
(7) 2007–(B) 2011	Antara, Captiva (Short Body)	Engine	2.0 L (Diesel)		●	●	●	●
(7) 2007–(B) 2011	Antara, Captiva (Short Body)	Chassis	ABS/TC/ESP (Vehicle Dynamic System)		●	●	●	●
(7) 2007–(B) 2011	Antara, Captiva (Short Body)	Transmission	Automatic Transmission		●	●	●	●
(7) 2007–(B) 2011	Antara, Captiva (Short Body)	Body	SDM (Airbag)		●	●	●	
(7) 2007–(B) 2011	Antara, Captiva (Short Body)	Transmission	TCCM (Transfer Case Control Module)		●	●	●	
(7) 2007–(B) 2011	Antara, Captiva (Short Body)	Engine	Z 24 XE		●	●	●	●
(7) 2007–(B) 2011	Antara, Captiva (Short Body)	Engine	Z 32 SE		●	●	●	●
(V) 1997–(W) 1998	Astra-F	Engine	14 SE		●	●	●	●
(V) 1997–(W) 1998	Astra-F	Engine	14 SE		●	●	●	●
(V) 1997–(Y) 2000	Astra-F	Engine	16 NZR		●	●	●	●
(V) 1997–(X) 1999	Astra-F	Engine	18 SE		●	●	●	●
(V) 1997–(2) 2002	Astra-F	Chassis	ABS-2E		●	●	●	
(V) 1997–(W) 1998	Astra-F	Transmission	AF 13/14/20		●	●	●	
(V) 1997–(Y) 2000	Astra-F	Transmission	AF 13II/20/22/30		●	●	●	●

Year	Vehicle Type	System Type	System Name	Subsystem	Ecu Info.	Read Codes	Erase Codes	Live Data
(V) 1997-(2) 2002	Astra-F	Body	Airbag-S		●	●	●	●
(V) 1997	Astra-F	Engine	C 14 NZ		●	●	●	●
(V) 1997-(W) 1998	Astra-F	Engine	C 14 SE		●	●	●	
(V) 1997-(X) 1999	Astra-F	Engine	C 16 SE		●	●	●	●
(V) 1997-(X) 1999	Astra-F	Engine	C 18 SEL		●	●	●	●
(W) 1998-(2) 2002	Astra-F	Engine	X 14 NZ		●	●	●	●
(V) 1997-(W) 1998	Astra-F	Engine	X 14 XE		●	●	●	●
(Y) 2000-(2) 2002	Astra-F	Engine	X 16 NE		●	●	●	●
(W) 1998-(2) 2002	Astra-F	Engine	X 16 SZR		●	●	●	●
(V) 1997-(2) 2002	Astra-F	Engine	X 16 XEL		●	●	●	●
(V) 1997-(W) 1998	Astra-F	Engine	X 18 XE		●	●	●	●
(V) 1997-(W) 1998	Astra-F	Engine	X 20 XEV		●	●	●	●
(W) 1998-(B) 2011	Astra-G	Chassis	ABS-5. 3/5. 4 (+TC)		●	●	●	●
(W) 1998-(B) 2011	Astra-G	Transmission	AF 13-II/17/20/22		●	●	●	●
(1) 2001-(B) 2011	Astra-G	Transmission	AF 13-II/17/20/22 CAN		●	●	●	●
(Y) 2000-(B) 2011	Astra-G	Body	Airbag		●	●	●	●
(W) 1998-(Y) 2000	Astra-G	Body	Airbag SAB6		●	●	●	●
(X) 1999-(B) 2011	Astra-G	Engine	C 16 SEL		●	●	●	●
(W) 1998-(Y) 2000	Astra-G	Engine	X 12 XE		●	●	●	●
(W) 1998-(Y) 2000	Astra-G	Engine	X 14 XE		●	●	●	●
(W) 1998-(1) 2001	Astra-G	Engine	X 16 SZR		●	●	●	●
(W) 1998-(Y) 2000	Astra-G	Engine	X 16 XEL		●	●	●	●

Year	Vehicle Type	System Type	System Name	Subsystem	Ecu Info.	Read Codes	Erase Codes	Live Data
(W) 1998-(Y) 2000	Astra-G	Engine	X 17 DTL		●	●	●	●
(W) 1998-(1) 2001	Astra-G	Engine	X 18 XE1		●	●	●	●
(W) 1998-(Y) 2000	Astra-G	Engine	X 20 DTL		●	●	●	●
(Y) 2000	Astra-G	Engine	X 20 XER		●	●	●	●
(W) 1998-(Y) 2000	Astra-G	Engine	X 20 XEV		●	●	●	●
(Y) 2000-(B) 2011	Astra-G	Engine	Y 17 DT		●	●	●	●
(Y) 2000-(B) 2011	Astra-G	Engine	Y 20 DTH		●	●	●	●
(1) 2001-(2) 2002	Astra-G	Engine	Y 20 DTL		●	●	●	●
(3) 2003-(B) 2011	Astra-G	Engine	Y 22 DTR		●	●	●	●
(1) 2001-(B) 2011	Astra-G	Engine	Z 12 XE		●	●	●	●
(B) 2011	Astra-G	Engine	Z 12 XE		●	●	●	●
(1) 2001-(B) 2011	Astra-G	Engine	Z 14 XE		●	●	●	●
(5) 2005-(B) 2011	Astra-G	Engine	Z 14 XEP		●	●	●	●
(1) 2001-(B) 2011	Astra-G	Engine	Z 16 SE		●	●	●	●
(1) 2001-(B) 2011	Astra-G	Engine	Z 16 XE		●	●	●	●
(3) 2003-(B) 2011	Astra-G	Engine	Z 16 XEP		●	●	●	●
(3) 2003-(B) 2011	Astra-G	Engine	Z 16 YNG		●	●	●	●
(3) 2003-(B) 2011	Astra-G	Engine	Z 17 DTL		●	●	●	●
(1) 2001-(B) 2011	Astra-G	Engine	Z 18 XE		●	●	●	●
(1) 2001-(B) 2011	Astra-G	Engine	Z 18 XEL		●	●	●	●
(1) 2001-(B) 2011	Astra-G	Engine	Z 20 LET		●	●	●	●
(Y) 2000-(B) 2011	Astra-G	Engine	Z 22 SE		●	●	●	●

Year	Vehicle Type	System Type	System Name	Subsystem	Ecu Info.	Read Codes	Erase Codes	Live Data
(4) 2004- (B) 2011	Astra-H	Chassis	ABS/TC/ESP (Vehicle Dynamic System)		●	●	●	
(4) 2004- (B) 2011	Astra-H	Chassis	ABS/TC/ESP ECU (Electronic Control Unit)		●	●	●	●
(4) 2004- (B) 2011	Astra-H	Transmission	AF 17-4		●	●	●	●
(6) 2006- (B) 2011	Astra-H	Transmission	AF 40-6		●	●	●	
(6) 2006- (B) 2011	Astra-H	Transmission	MTA (Easytronic Magneti Marelli)		●	●	●	
(4) 2004- (B) 2011	Astra-H	Transmission	MTA (Easytronic)		●	●	●	
(9) 2009- (B) 2011	Astra-H	Engine	A 16 LET		●	●	●	●
(B) 2011	Astra-H	Engine	A 16 XER		●	●	●	●
(8) 2008- (B) 2011	Astra-H	Engine	A 17 DTJ		●	●	●	●
(8) 2008- (B) 2011	Astra-H	Engine	A 17 DTR		●	●	●	●
(B) 2011	Astra-H	Engine	A 18 XER		●	●	●	●
(7) 2007- (B) 2011	Astra-H	Engine	Y 13 DTH		●	●	●	●
(7) 2007- (B) 2011	Astra-H	Engine	Z 16 XER		●	●	●	●
(7) 2007- (B) 2011	Astra-H	Engine	Z 16 LET		●	●	●	●
(7) 2007- (B) 2011	Astra-H	Engine	Z 16 XE1		●	●	●	●
(7) 2007- (B) 2011	Astra-H	Engine	Z 17 DTJ		●	●	●	●
(7) 2007- (B) 2011	Astra-H	Engine	Z 17 DTR		●	●	●	●
(7) 2007- (B) 2011	Astra-H	Engine	Z 22 YH		●	●	●	●
(6) 2006- (B) 2011	Astra-H	Engine	Z 12 XEP		●	●	●	●
(6) 2006- (B) 2011	Astra-H	Engine	Z 14 XEL		●	●	●	●
(7) 2007- (B) 2011	Astra-H	Engine	Z 18 XER		●	●	●	●
(6) 2006- (B) 2011	Astra-H	Engine	Z 19 DT		●	●	●	●

Year	Vehicle Type	System Type	System Name	Subsystem	Ecu Info.	Read Codes	Erase Codes	Live Data
(5) 2005- (B) 2011	Astra-H	Engine	Z 13 DTH		●	●	●	●
(5) 2005- (B) 2011	Astra-H	Engine	Z 19 DTH		●	●	●	●
(5) 2005- (B) 2011	Astra-H	Engine	Z 20 LEH		●	●	●	●
(4) 2004- (B) 2011	Astra-H	Engine	Z 14 XEP		●	●	●	●
(4) 2004- (B) 2011	Astra-H	Engine	Z 16 XEP		●	●	●	●
(4) 2004- (B) 2011	Astra-H	Engine	Z 17 DTH		●	●	●	●
(4) 2004- (B) 2011	Astra-H	Engine	Z 17 DTL		●	●	●	●
(4) 2004- (B) 2011	Astra-H	Engine	Z 18 XE		●	●	●	●
(4) 2004- (B) 2011	Astra-H	Engine	Z 20 LER		●	●	●	●
(V) 1997	Calibra	Chassis	ABS-2E		●	●	●	
(V) 1997	Calibra	Transmission	AF 13/14/20		●	●	●	
(V) 1997	Calibra	Transmission	AF 13II/20/22/30		●	●	●	●
(V) 1997	Calibra	Body	Airbag-S		●	●	●	●
(V) 1997	Calibra	Engine	X 20 XEV		●	●	●	●
(7) 2007- (B) 2011	Captiva (Long Body)	Engine	2.0 L (Diesel)		●	●	●	●
(7) 2007- (B) 2011	Captiva (Long Body)	Chassis	ABS/TC/ESP (Vehicle Dynamic System)		●	●	●	●
(7) 2007- (B) 2011	Captiva (Long Body)	Transmission	Automatic Transmission		●	●	●	●
(7) 2007- (B) 2011	Captiva (Long Body)	Body	SDM (Airbag)		●	●	●	
(7) 2007- (B) 2011	Captiva (Long Body)	Transmission	TCCM (Transfer Case Control Module)		●	●	●	●
(7) 2007- (B) 2011	Captiva (Long Body)	Engine	Z 24 XE		●	●	●	●
(7) 2007- (B) 2011	Captiva (Long Body)	Engine	Z 32 SE		●	●	●	●
(9) 2009- (B) 2011	Colorado	Engine	2.4L LG1 Euro3		●	●	●	●

Year	Vehicle Type	System Type	System Name	Subsystem	Ecu Info.	Read Codes	Erase Codes	Live Data
(9) 2009- (B) 2011	Colorado	Engine	3.0L 4JJ1-TC (Delphi)		●	●	●	●
(9) 2009- (B) 2011	Colorado	Engine	3.0L 4JJ1-TC (TransTron)		●	●	●	●
(9) 2009- (B) 2011	Colorado	Transmission	AW30-40LE		●	●	●	●
(9) 2009- (B) 2011	Colorado	Transmission	Automatic Transmission		●	●	●	●
(9) 2009- (B) 2011	Colorado	Chassis	ABS		●	●	●	●
(9) 2009- (B) 2011	Colorado	Body	Airbag		●	●	●	●
(9) 2009- (B) 2011	Colorado	Engine	V6 Engine		●	●	●	●
(V) 1997- (W) 1998	Corsa-B	Engine	12 NZ		●	●	●	●
(V) 1997- (3) 2003	Corsa-B	Chassis	ABS-5.3		●	●	●	●
(V) 1997- (Y) 2000	Corsa-B	Transmission	AF 13/14/20		●	●	●	
(W) 1998- (Y) 2000	Corsa-B	Transmission	AF 13II/20/22/30		●	●	●	●
(X) 1999- (3) 2003	Corsa-B	Body	Airbag SAB6		●	●	●	●
(V) 1997- (3) 2003	Corsa-B	Body	Airbag-S		●	●	●	●
(V) 1997- (W) 1998	Corsa-B	Engine	C 12 NZ		●	●	●	
(V) 1997- (W) 1998	Corsa-B	Engine	C 14 NZ		●	●	●	●
(W) 1998- (3) 2003	Corsa-B	Engine	C 14 SE		●	●	●	
(W) 1998- (Y) 2000	Corsa-B	Engine	C 14 SEL		●	●	●	●
(W) 1998- (Y) 2000	Corsa-B	Engine	C 16 SEL		●	●	●	●
(V) 1997- (Y) 2000	Corsa-B	Engine	X 10 XE		●	●	●	●
(V) 1997- (X) 1999	Corsa-B	Engine	X 10 XE S		●	●	●	
(V) 1997- (W) 1998	Corsa-B	Engine	X 12 SZ		●	●	●	
(W) 1998- (Y) 2000	Corsa-B	Engine	X 12 XE		●	●	●	●



Year	Vehicle Type	System Type	System Name	Subsystem	Ecu Info.	Read Codes	Erase Codes	Live Data
(Y) 2000–(3) 2003	Corsa-B	Engine	X 14 NE		●	●	●	●
(Y) 2000	Corsa-B	Engine	X 14 NE		●	●	●	●
(V) 1997–(3) 2003	Corsa-B	Engine	X 14 SZ		●	●	●	●
(V) 1997–(Y) 2000	Corsa-B	Engine	X 14 XE		●	●	●	●
(W) 1998–(3) 2003	Corsa-B	Engine	X 16 NE		●	●	●	●
(1) 2001–(B) 2011	Corsa-C	Chassis	ABS-5.3/5.4 (+TC)		●	●	●	●
(1) 2001–(B) 2011	Corsa-C	Chassis	ABS8/ESP8		●	●	●	●
(1) 2001–(B) 2011	Corsa-C	Transmission	AF 13-II/17/20/22 CAN		●	●	●	●
(1) 2001–(B) 2011	Corsa-C	Body	Airbag		●	●	●	●
(1) 2001–(B) 2011	Corsa-C	Transmission	MTA (Easytronic)		●	●	●	●
(7) 2007–(B) 2011	Corsa-D	Engine	Z 10 XEP		●	●	●	●
(A) 2010–(B) 2011	Corsa-D	Engine	A 10 XEP		●	●	●	●
(A) 2010–(B) 2011	Corsa-D	Engine	A 12 XEL		●	●	●	●
(A) 2010–(B) 2011	Corsa-D	Engine	A 12 XER		●	●	●	●
(A) 2010–(B) 2011	Corsa-D	Engine	Z 13 DTE		●	●	●	●
(B) 2011	Corsa-D	Engine	A 13 DTE		●	●	●	●
(B) 2011	Corsa-D	Engine	A 13 DTC		●	●	●	●
(B) 2011	Corsa-D	Engine	A 13 DTR		●	●	●	●
(A) 2010–(B) 2011	Corsa-D	Engine	A 14 XEL		●	●	●	●
(A) 2010–(B) 2011	Corsa-D	Engine	A 14 XER		●	●	●	●
(A) 2010–(B) 2011	Corsa-D	Engine	A 16 LEL		●	●	●	●
(A) 2010–(B) 2011	Corsa-D	Engine	A 16 LER		●	●	●	●

Year	Vehicle Type	System Type	System Name	Subsystem	Ecu Info.	Read Codes	Erase Codes	Live Data
(A) 2010- (B) 2011	Corsa-D	Engine	A 17 DTS		●	●	●	●
(8) 2008- (B) 2011	Corsa-D	Engine	Z 16 LEL		●	●	●	●
(7) 2007- (B) 2011	Corsa-D	Engine	Z 12 XEP		●	●	●	●
(7) 2007- (B) 2011	Corsa-D	Engine	Z 13 DTH		●	●	●	●
(7) 2007- (B) 2011	Corsa-D	Engine	Z 13 DTJ		●	●	●	●
(7) 2007- (B) 2011	Corsa-D	Engine	Z 16 LER		●	●	●	●
(7) 2007- (B) 2011	Corsa-D	Engine	Z 17 DTR		●	●	●	●
(7) 2007- (B) 2011	Corsa-D	Chassis	ABS/ESP		●	●	●	●
(7) 2007- (B) 2011	Corsa-D	Transmission	AF 13-4		●	●	●	
(8) 2008- (B) 2011	Corsa-D	Transmission	MTA (Easytronic Magneti Marelli)		●	●	●	
(7) 2007- (B) 2011	Corsa-D	Transmission	MTA (Easytronic)		●	●	●	
(7) 2007- (B) 2011	Corsa-D	Engine	Z 13 DTJ		●	●	●	●
(7) 2007- (B) 2011	Corsa-D	Engine	Z 14 XEP		●	●	●	●
(X) 1999- (Y) 2000	Frontera	Powertrain	2. 2L L4 X22SE		●	●	●	●
(V) 1997- (W) 1998	Frontera	Engine	25 TDS		●	●	●	●
(X) 1999- (3) 2003	Frontera	Powertrain	3. 2L V6 6VD1		●	●	●	●
(X) 1999- (3) 2003	Frontera	Powertrain	4L30E		●	●	●	●
(X) 1999- (3) 2003	Frontera	Chassis	ABS		●	●	●	●
(V) 1997- (W) 1998	Frontera	Chassis	ABS 415		●	●	●	●
(V) 1997- (3) 2003	Frontera	Body	Airbag		●	●	●	●
(V) 1997- (W) 1998	Frontera	Engine	X 20 SE		●	●	●	
(V) 1997- (W) 1998	Frontera	Engine	X 22 XE		●	●	●	

Year	Vehicle Type	System Type	System Name	Subsystem	Ecu Info.	Read Codes	Erase Codes	Live Data
(W) 1998- (3) 2003	Jackaroo	Powertrain	3.0L L4 4JX1		●	●	●	●
(W) 1998- (3) 2003	Jackaroo	Powertrain	3.5L V6 6VE1		●	●	●	●
(W) 1998- (3) 2003	Jackaroo	Powertrain	4L30E		●	●	●	●
(W) 1998- (3) 2003	Jackaroo	Chassis	ABS		●	●	●	
(W) 1998- (3) 2003	Jackaroo	Body	Airbag		●	●	●	●
(Y) 2000- (2) 2002	Jackaroo	Powertrain	AW30-40LE		●	●	●	●
(3) 2003- (4) 2004	Meriva	Chassis	ABS-5.3/5.4 (+TC)		●	●	●	●
(5) 2005- (A) 2010	Meriva	Chassis	ABS8/ESP8		●	●	●	●
(3) 2003- (A) 2010	Meriva	Body	Airbag		●	●	●	●
(3) 2003- (4) 2004	Meriva	Transmission	MTA (Easytronic)		●	●	●	●
(5) 2005- (A) 2010	Meriva	Engine	Y 13 DT		●	●	●	●
(6) 2006- (A) 2010	Meriva	Engine	Z 13 DT		●	●	●	
(5) 2005- (A) 2010	Meriva	Engine	Z 14 XEP		●	●	●	●
(6) 2006- (A) 2010	Meriva	Engine	Z 16 LET		●	●	●	
(3) 2003- (A) 2010	Meriva	Engine	Z 16 SE		●	●	●	●
(3) 2003- (A) 2010	Meriva	Engine	Z 16 XE		●	●	●	●
(6) 2006- (A) 2010	Meriva	Engine	Z 16 XEP		●	●	●	●
(7) 2007- (A) 2010	Meriva	Engine	Z 17 DT		●	●	●	
(4) 2004- (A) 2010	Meriva	Engine	Z 17 DTH		●	●	●	●
(7) 2007- (A) 2010	Meriva	Engine	Z 17 DTR		●	●	●	
(3) 2003- (A) 2010	Meriva	Engine	Z 18 XE		●	●	●	●
(V) 1997- (X) 1999	Monterey	Chassis	ABS 5		●	●	●	●

Year	Vehicle Type	System Type	System Name	Subsystem	Ecu Info.	Read Codes	Erase Codes	Live Data
(V) 1997- (X) 1999	Monterey	Body	Airbag		●	●	●	●
(6) 2006- (7) 2007	RA Rodeo	Engine	2. 4L LG1 Euro3		●	●	●	●
(6) 2006	RA Rodeo/Colorado	Engine	3. 0L 4JJ1-TC (Delphi)		●	●	●	●
(7) 2007	RA Rodeo/Colorado	Engine	3. 0L 4JJ1-TC (Delphi)		●	●	●	●
(8) 2008	RA Rodeo/Colorado	Engine	2. 4L LG1 Euro3		●	●	●	●
(6) 2006- (7) 2007	RA Rodeo	Chassis	ABS		●	●	●	●
(8) 2008	RA Rodeo/Colorado	Engine	3. 0L 4JJ1-TC (Delphi)		●	●	●	●
(8) 2008	RA Rodeo/Colorado	Engine	3. 0L 4JJ1-TC (TransTron)		●	●	●	●
(8) 2008	RA Rodeo/Colorado	Chassis	ABS		●	●	●	●
(6) 2006- (7) 2007	RA Rodeo	Body	Airbag		●	●	●	●
(8) 2008	RA Rodeo/Colorado	Body	Airbag		●	●	●	●
(6) 2006- (7) 2007	RA Rodeo	Transmission	Automatic Transmission		●	●	●	●
(8) 2008	RA Rodeo/Colorado	Transmission	Automatic Transmission		●	●	●	●
(6) 2006- (7) 2007	RA Rodeo	Engine	V6 Engine		●	●	●	●
(8) 2008	RA Rodeo/Colorado	Engine	V6 Engine		●	●	●	●
(Y) 2000- (2) 2002	Rodeo	Powertrain	2. 2L L4 SOHC		●	●	●	
(Y) 2000- (2) 2002	Rodeo	Powertrain	3. 2L V6 6VD1 Hitachi		●	●	●	●
(1) 2001- (2) 2002	Rodeo	Powertrain	4JH1-TC Bosch		●	●	●	
(W) 1998- (2) 2002	Rodeo	Powertrain	4L30E		●	●	●	●
(Y) 2000- (2) 2002	Rodeo	Body	Airbag		●	●	●	●
(2) 2002	Rodeo	Powertrain	AW30-40LE		●	●	●	●
(V) 1997- (X) 1999	Sintra	Transmission	AF 13II/20/22/30		●	●	●	●

Year	Vehicle Type	System Type	System Name	Subsystem	Ecu Info.	Read Codes	Erase Codes	Live Data
(W) 1998-(X) 1999	Sintra	Engine	X 22 DTH		●	●	●	●
(V) 1997-(X) 1999	Sintra	Engine	X 22 XE		●	●	●	
(V) 1997-(X) 1999	Sintra	Engine	X 30 XE		●	●	●	
(V) 1997-(Y) 2000	Tigra	Chassis	ABS-5.3		●	●	●	●
(V) 1997-(Y) 2000	Tigra	Transmission	AF 13/14/20		●	●	●	
(X) 1999-(Y) 2000	Tigra	Body	Airbag SAB6		●	●	●	●
(V) 1997-(Y) 2000	Tigra	Body	Airbag-S		●	●	●	●
(W) 1998-(Y) 2000	Tigra	Engine	C 14 SEL		●	●	●	●
(W) 1998-(Y) 2000	Tigra	Engine	C 16 SEL		●	●	●	●
(V) 1997-(Y) 2000	Tigra	Engine	X 14 XE		●	●	●	●
(V) 1997-(Y) 2000	Tigra	Engine	X 16 XE		●	●	●	●
(5) 2005-(B) 2011	Tigra-B	Chassis	ABS8/ESP8		●	●	●	●
(5) 2005-(B) 2011	Tigra-B	Body	Airbag		●	●	●	●
(A) 2010	Tigra-B	Chassis	Chassis	ABS8/ESP8	●	●	●	●
(A) 2010	Tigra-B	Chassis	Chassis	Electronic Power Steering	●	●	●	●
(A) 2010	Tigra-B	Engine	Engine	Y 13 DT	●	●	●	●
(A) 2010	Tigra-B	Engine	Engine	Z 13 DT	●	●	●	
(A) 2010	Tigra-B	Engine	Engine	Z 14 XEP	●	●	●	●
(A) 2010	Tigra-B	Engine	Engine	Z 16 SE	●	●	●	●
(A) 2010	Tigra-B	Engine	Engine	Z 16 XE	●	●	●	●
(A) 2010	Tigra-B	Engine	Engine	Z 16 XEP	●	●	●	●
(A) 2010	Tigra-B	Engine	Engine	Z 16 LET	●	●	●	

Year	Vehicle Type	System Type	System Name	Subsystem	Ecu Info.	Read Codes	Erase Codes	Live Data
(A) 2010	Tigra-B	Engine	Engine	Z 17 DT	●	●	●	
(A) 2010	Tigra-B	Engine	Engine	Z 17 DTH	●	●	●	●
(A) 2010	Tigra-B	Engine	Engine	Z 17 DTR	●	●	●	
(A) 2010	Tigra-B	Engine	Engine	Z 18 XE	●	●	●	●
(5) 2005-(B) 2011	Tigra-B	Transmission	MTA (Easytronic)		●	●	●	●
(A) 2010	Tigra-B	Transmission	Transmission	MTA (Easytronic)	●	●	●	●
(5) 2005-(B) 2011	Tigra-B	Engine	Z 13 DT		●	●	●	●
(5) 2005-(B) 2011	Tigra-B	Engine	Z 14 XEP		●	●	●	●
(5) 2005-(B) 2011	Tigra-B	Engine	Z 18 XE		●	●	●	●
(2) 2002-(4) 2004	V2 Series	Chassis	ABS / ETC		●	●	●	●
(2) 2002-(4) 2004	V2 Series	Transmission	Automatic Transmission		●	●	●	●
(2) 2002-(4) 2004	V2 Series	Transmission	GEN III Automatic Transmission		●	●	●	●
(2) 2002-(4) 2004	V2 Series	Body	SRS		●	●	●	●
(2) 2002-(4) 2004	V2 Series	Engine	V6			●	●	●
(2) 2002-(4) 2004	V2 Series	Engine	V8 GEN III		●	●	●	●
(7) 2007-(B) 2011	VE and WM Series	Transmission	Automatic Transmission		●	●	●	●
(7) 2007-(B) 2011	VE and WM Series	Chassis	EBCM (Electronic Brake Control Module)		●	●	●	●
(7) 2007-(B) 2011	VE and WM Series	Body	SDM (Sensing and Diagnostic Module)		●	●	●	●
(7) 2007-(B) 2011	VE and WM Series	Engine	V6 Engine		●	●	●	●
(7) 2007-(B) 2011	VE and WM Series	Engine	V8 GEN IV		●	●	●	●
(V) 1997-(Y) 2000	Vectra-B	Engine	16 LZ 2		●	●	●	●
(V) 1997-(Y) 2000	Vectra-B	Engine	20 NEJ		●	●	●	●

Year	Vehicle Type	System Type	System Name	Subsystem	Ecu Info.	Read Codes	Erase Codes	Live Data
(V) 1997- (X) 1999	Vectra-B	Chassis	ABS 415		●	●	●	●
(W) 1998- (Y) 2000	Vectra-B	Chassis	ABS 430		●	●	●	●
(W) 1998- (1) 2001	Vectra-B	Chassis	ABS-5. 3/5. 4 (+TC)		●	●	●	●
(V) 1997- (X) 1999	Vectra-B	Chassis	ABS-5-TC		●	●	●	●
(W) 1998- (1) 2001	Vectra-B	Transmission	AF 13-II/17/20/22		●	●	●	●
(Y) 2000- (1) 2001	Vectra-B	Transmission	AF 13-II/17/20/22 CAN		●	●	●	●
(V) 1997- (X) 1999	Vectra-B	Transmission	AF 13II/20/22/30		●	●	●	●
(1) 2001	Vectra-B	Body	Airbag		●	●	●	●
(W) 1998- (1) 2001	Vectra-B	Body	Airbag SAB6		●	●	●	●
(V) 1997- (1) 2001	Vectra-B	Engine	C 20 SEL		●	●	●	●
(V) 1997- (Y) 2000	Vectra-B	Engine	X 16 SZR		●	●	●	●
(V) 1997- (1) 2001	Vectra-B	Engine	X 16 XEL		●	●	●	●
(V) 1997- (X) 1999	Vectra-B	Engine	X 18 XE		●	●	●	●
(V) 1997- (X) 1999	Vectra-B	Engine	X 18 XE1		●	●	●	●
(W) 1998- (Y) 2000	Vectra-B	Engine	X 20 DTH		●	●	●	●
(V) 1997- (Y) 2000	Vectra-B	Engine	X 20 DTL		●	●	●	●
(W) 1998- (1) 2001	Vectra-B	Engine	X 20 XEV		●	●	●	●
(V) 1997- (Y) 2000	Vectra-B	Engine	X 25 XE		●	●	●	●
(Y) 2000- (1) 2001	Vectra-B	Engine	Y 16 XE		●	●	●	●
(1) 2001	Vectra-B	Engine	Y 20 DTH		●	●	●	●
(1) 2001	Vectra-B	Engine	Y 22 DTR		●	●	●	●
(1) 2001	Vectra-B	Engine	Y 26 SE		●	●	●	●

Year	Vehicle Type	System Type	System Name	Subsystem	Ecu Info.	Read Codes	Erase Codes	Live Data
(1) 2001	Vectra-B	Engine	Z 16 XE		●	●	●	●
(1) 2001	Vectra-B	Engine	Z 18 XE		●	●	●	●
(1) 2001	Vectra-B	Engine	Z 18 XEL		●	●	●	●
(1) 2001	Vectra-B	Engine	Z 22 SE		●	●	●	●
(2) 2002- (8) 2008	Vectra-C / Signum	Chassis	ABS/TC/ESP	AHL/AFL (Headlamp Levelling)	●	●	●	
(2) 2002- (8) 2008	Vectra-C / Signum	Chassis	ABS/TC/ESP	CIM (Steering Column Module)	●	●	●	●
(2) 2002- (8) 2008	Vectra-C / Signum	Chassis	ABS/TC/ESP	ABS/TC/ESP	●	●	●	●
(2) 2002- (8) 2008	Vectra-C / Signum	Chassis	ABS/TC/ESP	Automatic Transmission	●	●	●	●
(2) 2002- (8) 2008	Vectra-C / Signum	Chassis	ABS/TC/ESP	Engine	●	●	●	●
(2) 2002- (8) 2008	Vectra-C / Signum	Chassis	ABS/TC/ESP	IPC (Instrument)	●	●	●	●
(2) 2002- (8) 2008	Vectra-C / Signum	Chassis	ABS/TC/ESP	TPMS (Tyre Pressure Monitoring System)	●	●	●	●
(2) 2002- (4) 2004	Vectra-C / Signum	Transmission	AF 23-5/33-5		●	●	●	
(5) 2005- (8) 2008	Vectra-C / Signum	Transmission	AF 23-5/33-5/40-6	Automatic Transmission	●	●	●	●
(5) 2005- (8) 2008	Vectra-C / Signum	Transmission	AF 23-5/33-5/40-6	Engine	●	●	●	●
(5) 2005- (8) 2008	Vectra-C / Signum	Transmission	AF 23-5/33-5/40-6	CIM (Steering Column Module)	●	●	●	●
(5) 2005- (8) 2008	Vectra-C / Signum	Transmission	AF 23-5/33-5/40-6	IPC (Instrument)	●	●	●	●
(5) 2005- (8) 2008	Vectra-C / Signum	Transmission	AF 23-5/33-5/40-6	SLM (Shift Lever Module)	●	●	●	●
(4) 2004- (8) 2008	Vectra-C / Signum	Transmission	CVTronic		●	●	●	
(2) 2002- (8) 2008	Vectra-C / Signum	Engine	Engine Cooling		●	●	●	●
(6) 2006- (8) 2008	Vectra-C / Signum	Transmission	MTA (Easytronic)		●	●	●	
(2) 2002- (8) 2008	Vectra-C / Signum	Engine	Y 20 DTH		●	●	●	●
(2) 2002- (8) 2008	Vectra-C / Signum	Engine	Y 22 DTR		●	●	●	●



Year	Vehicle Type	System Type	System Name	Subsystem	Ecu Info.	Read Codes	Erase Codes	Live Data
(2) 2002–(8) 2008	Vectra-C / Signum	Engine	Z 16 XE		●	●	●	●
(6) 2006–(8) 2008	Vectra-C / Signum	Engine	Z 16 XEP		●	●	●	●
(2) 2002–(8) 2008	Vectra-C / Signum	Engine	Z 18 XE		●	●	●	●
(6) 2006–(8) 2008	Vectra-C / Signum	Engine	Z 18 XER		●	●	●	●
(4) 2004–(8) 2008	Vectra-C / Signum	Engine	Z 19 DT		●	●	●	●
(4) 2004–(8) 2008	Vectra-C / Signum	Engine	Z 19 DTH		●	●	●	●
(3) 2003–(8) 2008	Vectra-C / Signum	Engine	Z 20 NET		●	●	●	●
(2) 2002–(8) 2008	Vectra-C / Signum	Engine	Z 22 SE		●	●	●	●
(3) 2003–(8) 2008	Vectra-C / Signum	Engine	Z 22 YH		●	●	●	●
(7) 2007–(8) 2008	Vectra-C / Signum	Engine	Z 28 NEH		●	●	●	●
(8) 2008	Vectra-C / Signum	Engine	Z 30 DT		●	●	●	●
(2) 2002–(8) 2008	Vectra-C / Signum	Engine	Z 32 SE		●	●	●	●
(7) 2007	Vectra-C / Signum	Engine	Z 30 DT		●	●	●	●
(6) 2006–(8) 2008	Vectra-C / Signum	Engine	Z 28 NEL		●	●	●	●
(6) 2006–(8) 2008	Vectra-C / Signum	Engine	Z 28 NET		●	●	●	●
(6) 2006	Vectra-C / Signum	Engine	Z 30 DT		●	●	●	●
(3) 2003–(5) 2005	Vectra-C / Signum	Engine	Y 30 DT		●	●	●	○
(-U) -1996	VR Commodore	Chassis	ABS / ETC			●	●	●
(-U) -1996	VR Commodore	Transmission	Automatic Transmission			●	●	●
(-U) -1996	VR Commodore	Body	SRS			●	●	●
(-U) -1996	VR Commodore	Engine	V6			●	●	●
(-U) -1996	VR Commodore	Engine	V8			●	●	●

Year	Vehicle Type	System Type	System Name	Subsystem	Ecu Info.	Read Codes	Erase Codes	Live Data
(-U) -1996	VS Commodore	Chassis	ABS / ETC			●	●	●
(-U) -1996	VS Commodore	Transmission	Automatic Transmission			●	●	●
(W) 1998	VS Commodore	Transmission	Automatic Transmission		●	●	●	●
(X) 1999	VS Commodore	Transmission	Automatic Transmission		●	●	●	●
(-U) -1996	VS Commodore	Body	SRS			●	●	●
(-U) -1996	VS Commodore	Engine	V6			●	●	●
(-U) -1996	VS Commodore	Engine	V8			●	●	●
(W) 1998	VS Commodore	Engine	V8			●	●	●
(X) 1999	VS Commodore	Engine	V8			●	●	●
(V) 1997-(Y) 2000	VT Commodore	Chassis	ABS / ETC		●	●	●	●
(V) 1997-(Y) 2000	VT Commodore	Transmission	Automatic Transmission		●	●	●	●
(X) 1999-(Y) 2000	VT Commodore	Transmission	GEN III Automatic Transmission		●	●	●	●
(V) 1997-(Y) 2000	VT Commodore	Body	SRS		●	●	●	●
(V) 1997-(Y) 2000	VT Commodore	Engine	V6			●	●	●
(V) 1997-(Y) 2000	VT Commodore	Engine	V6 LPG			●	●	●
(V) 1997-(Y) 2000	VT Commodore	Engine	V6 Supercharged			●	●	●
(V) 1997-(Y) 2000	VT Commodore	Engine	V8			●	●	●
(X) 1999-(Y) 2000	VT Commodore	Engine	V8 GEN III		●	●	●	●
(1) 2001-(2) 2002	VU Utility	Chassis	ABS / ETC		●	●	●	●
(1) 2001-(2) 2002	VU Utility	Transmission	Automatic Transmission		●	●	●	●
(1) 2001-(2) 2002	VU Utility	Transmission	GEN III Automatic Transmission		●	●	●	●
(1) 2001-(2) 2002	VU Utility	Body	SRS		●	●	●	●

Year	Vehicle Type	System Type	System Name	Subsystem	Ecu Info.	Read Codes	Erase Codes	Live Data
(1)2001-(2)2002	VU Utility	Engine	V6			●	●	●
(1)2001-(2)2002	VU Utility	Engine	V8 GEN III		●	●	●	●
(1)2001-(2)2002	VX Commodore	Chassis	ABS / ETC		●	●	●	●
(1)2001-(2)2002	VX Commodore	Transmission	Automatic Transmission		●	●	●	●
(1)2001-(2)2002	VX Commodore	Transmission	GEN III Automatic Transmission		●	●	●	●
(1)2001-(2)2002	VX Commodore	Body	SRS		●	●	●	●
(1)2001-(2)2002	VX Commodore	Engine	V6		●	●	●	●
(1)2001-(2)2002	VX Commodore	Engine	V8 GEN III		●	●	●	●
(3)2003-(4)2004	VY Series	Chassis	ABS / ETC		●	●	●	●
(3)2003-(4)2004	VY Series	Transmission	Automatic Transmission		●	●	●	●
(3)2003-(4)2004	VY Series	Transmission	GEN III Automatic Transmission		●	●	●	●
(4) 2004	VY Series	Chassis	GEN III AWD ABS/ETC			●	●	●
(3)2003-(4)2004	VY Series	Body	SRS		●	●	●	●
(3)2003-(4)2004	VY Series	Engine	V6		●	●	●	●
(3)2003-(4)2004	VY Series	Engine	V8 GEN III		●	●	●	●
(5)2005-(6)2006	VZ and WL Series	Chassis	ABS / ETC		●	●	●	●
(5)2005-(6)2006	VZ and WL Series	Chassis	ABS/TC/ESP 8.0		●	●	●	●
(5)2005-(6)2006	VZ and WL Series	Transmission	Automatic Transmission		●	●	●	●
(5)2005-(6)2006	VZ and WL Series	Transmission	GEN III Automatic Transmission		●	●	●	●
(5)2005-(6)2006	VZ and WL Series	Chassis	GEN III AWD ABS/ETC			●	●	●
(5)2005-(6)2006	VZ and WL Series	Body	SRS		●	●	●	●
(5)2005-(6)2006	VZ and WL Series	Engine	V6 Engine		●	●	●	●

Year	Vehicle Type	System Type	System Name	Subsystem	Ecu Info.	Read Codes	Erase Codes	Live Data
(5) 2005–(6) 2006	VZ and WL Series	Engine	V8 GEN III		●	●	●	●
(5) 2005–(6) 2006	VZ and WL Series	Engine	V8 GEN IV		●	●	●	●
(X) 1999–(3) 2003	WH Statesman & Caprice	Chassis	ABS / ETC		●	●	●	●
(X) 1999–(3) 2003	WH Statesman & Caprice	Transmission	Automatic Transmission		●	●	●	●
(X) 1999–(3) 2003	WH Statesman & Caprice	Transmission	GEN III Automatic Transmission		●	●	●	●
(X) 1999–(3) 2003	WH Statesman & Caprice	Body	SRS		●	●	●	●
(X) 1999–(3) 2003	WH Statesman & Caprice	Engine	V6			●	●	●
(X) 1999–(Y) 2000	WH Statesman & Caprice	Engine	V6 LPG			●	●	●
(X) 1999–(Y) 2000	WH Statesman & Caprice	Engine	V6 Supercharged			●	●	●
(X) 1999–(Y) 2000	WH Statesman & Caprice	Engine	V8			●	●	●
(X) 1999–(3) 2003	WH Statesman & Caprice	Engine	V8 GEN III		●	●	●	●
(4) 2004	WK Series	Transmission	Automatic Transmission		●	●	●	●
(4) 2004	WK Series	Transmission	GEN III Automatic Transmission		●	●	●	●
(4) 2004	WK Series	Body	SRS		●	●	●	●
(4) 2004	WK Series	Engine	V6			●	●	●
(4) 2004	WK Series	Engine	V8 GEN III		●	●	●	●
(2) 2002–(6) 2006	YG Cruze	Chassis	ABS		●	●	●	●
(2) 2002–(6) 2006	YG Cruze	Body	Airbag		●	●	●	●
(2) 2002–(6) 2006	YG Cruze	Transmission	Automatic Transmission		●	●	●	●
(2) 2002–(6) 2006	YG Cruze	Engine	Engine		●	●	●	●
(X) 1999–(5) 2005	Zafira	Chassis	ABS-5.3/5.4 (+TC)		●	●	●	●
(X) 1999–(Y) 2000	Zafira	Transmission	AF 13-II/17/20/22		●	●	●	●

Year	Vehicle Type	System Type	System Name	Subsystem	Ecu Info.	Read Codes	Erase Codes	Live Data
(1) 2001- (5) 2005	Zafira	Transmission	AF 13-II/17/20/22 CAN		●	●	●	●
(1) 2001- (5) 2005	Zafira	Body	Airbag		●	●	●	●
(X) 1999- (Y) 2000	Zafira	Body	Airbag SAB6		●	●	●	●
(X) 1999- (Y) 2000	Zafira	Engine	X 16 XEL		●	●	●	●
(X) 1999- (Y) 2000	Zafira	Engine	X 18 XE1		●	●	●	●
(Y) 2000- (5) 2005	Zafira	Engine	X 20 DTL		●	●	●	●
(1) 2001- (5) 2005	Zafira	Engine	Y 20 DTH		●	●	●	●
(2) 2002- (5) 2005	Zafira	Engine	Y 22 DTR		●	●	●	●
(1) 2001- (5) 2005	Zafira	Engine	Z 16 XE		●	●	●	●
(1) 2001- (5) 2005	Zafira	Engine	Z 16 YNG		●	●	●	●
(1) 2001- (5) 2005	Zafira	Engine	Z 18 XE		●	●	●	●
(2) 2002- (5) 2005	Zafira	Engine	Z 20 LET		●	●	●	●
(1) 2001- (5) 2005	Zafira	Engine	Z 22 SE		●	●	●	●
(5) 2005- (B) 2011	Zafira-B	Chassis	ABS/TC/ESP (Vehicle Dynamic System)		●	●	●	●
(5) 2005- (B) 2011	Zafira-B	Chassis	ABS/TC/ESP ECU (Electronic Control Unit)		●	●	●	●
(5) 2005- (B) 2011	Zafira-B	Transmission	AF 22-4		●	●	●	
(5) 2005- (B) 2011	Zafira-B	Transmission	AF 40-6		●	●	●	
(6) 2006- (B) 2011	Zafira-B	Transmission	MTA (Easytronic)		●	●	●	●
(5) 2005- (B) 2011	Zafira-B	Body	SDM (Airbag)		●	●	●	●
(B) 2011	Zafira-B	Engine	A 16 XER		●	●	●	●
(B) 2011	Zafira-B	Engine	A 16 XNT		●	●	●	●
(8) 2008- (A) 2011	Zafira-B	Engine	A 17 DTJ		●	●	●	●

Year	Vehicle Type	System Type	System Name	Subsystem	Ecu Info.	Read Codes	Erase Codes	Live Data
(B) 2011	Zafira-B	Engine	A 18 XER		●	●	●	●
(9) 2009- (A) 2011	Zafira-B	Engine	Z 16 XNT		●	●	●	●
(8) 2008- (A) 2011	Zafira-B	Engine	A 17 DTR		●	●	●	●
(8) 2008- (A) 2011	Zafira-B	Engine	Z 16 XER		●	●	●	●
(5) 2005- (A) 2011	Zafira-B	Engine	Z 16 XE1		●	●	●	●
(6) 2006- (A) 2011	Zafira-B	Engine	Z 16 YNG		●	●	●	●
(6) 2006- (A) 2011	Zafira-B	Engine	Z 20 LEH		●	●	●	●
(7) 2007- (A) 2011	Zafira-B	Engine	Z 16 XEP		●	●	●	●
(5) 2005- (A) 2011	Zafira-B	Engine	Z 18 XER		●	●	●	●
(5) 2005- (A) 2011	Zafira-B	Engine	Z 19 DT		●	●	●	●
(5) 2005- (A) 2011	Zafira-B	Engine	Z 19 DTH		●	●	●	●
(5) 2005- (A) 2011	Zafira-B	Engine	Z 20 LER		●	●	●	●
(5) 2005- (A) 2011	Zafira-B	Engine	Z 22 YH		●	●	●	●
(A) 2010- (B) 2011	Meriva-B	Engine	Engine Control Module		●	●	●	●
(A) 2010- (B) 2011	Meriva-B	Engine	A13DTC 1.3 (LDV)		●	●	●	●
(A) 2010- (B) 2011	Meriva-B	Engine	A13DTE 1.3 (LSF)		●	●	●	●
(A) 2010- (B) 2011	Meriva-B	Engine	A14NEL (LUH)		●	●	●	●
(A) 2010- (B) 2011	Meriva-B	Engine	A14NET (LUJ)		●	●	●	●
(A) 2010- (B) 2011	Meriva-B	Engine	A14XER (LDD)		●	●	●	●
(A) 2010- (B) 2011	Meriva-B	Engine	A17DT 1.7 (LUB)		●	●	●	●
(A) 2010- (B) 2011	Meriva-B	Engine	A17DTC 1.7 (LUE)		●	●	●	●
(A) 2010- (B) 2011	Meriva-B	Engine	A17DTS 1.7 (LUD)		●	●	●	●

Year	Vehicle Type	System Type	System Name	Subsystem	Ecu Info.	Read Codes	Erase Codes	Live Data
(A) 2010- (B) 2011	Meriva-B	Transmission	Transmission Control Module		●	●	●	●
(A) 2010- (B) 2011	Meriva-B	Chassis	Electronic Brake Control Module		●	●	●	●
(A) 2010- (B) 2011	Meriva-B	Chassis	Parking Brake Control Module		●	●	●	●
(A) 2010- (B) 2011	Meriva-B	Body	Inflatable Restraint Sensing and Diagnostic Module		●	●	●	●