

MaxiDiag_Renault_V2.20 Function List (Note:For reference only)

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Vehicle Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Function Test
AVANTIME	A. B. S.	●	●	●	●	●
AVANTIME	AIR CONDITIONING	●	●	●	●	●
AVANTIME	AIRBAG / PRETENSIONERS	●	●	●	●	●
AVANTIME	AUTOMATIC GEARBOX	●	●	●	●	●
AVANTIME	CONNECTION UNIT	●	●	●	●	●
AVANTIME	DISCHARGE LAMP	●	●	●	●	○
AVANTIME	HEATER	●	●	●	●	●
AVANTIME	IMMOBILISER	●	●	●	●	●
AVANTIME	INJECTION	●	●	●	●	●
AVANTIME	INSTRUMENT PANEL	●	●	●	●	●
AVANTIME	LIGHTING	●	●	●	●	○
CLIO II	A. B. S.	●	●	●	●	※
CLIO II	AIR CONDITIONING	●	●	●	●	●
CLIO II	AIRBAG / PRETENSIONERS	●	●	●	●	●
CLIO II	AUTOMATIC GEARBOX	●	●	●	●	●
CLIO II	CONNECTION UNIT	●	●	●	●	※
CLIO II	GAS INJ.	●	●	●	●	●
CLIO II	IMMOBILISER	●	●	●	●	※
CLIO II	INJECTION	●	●	●	●	※
CLIO III	A. B. S.	●	●	●	●	●
CLIO III	AIR CONDITIONING	●	●	●	●	●
CLIO III	AIRBAG / PRETENSIONERS	●	●	●	●	●
CLIO III	AUTOMATIC GEARBOX	●	●	●	●	●
CLIO III	COMMUNICATIONS UNIT	●	●	●	●	●
CLIO III	INJECTION	●	●	●	●	●
CLIO III	INSTRUMENT PANEL	●	●	●	●	●
CLIO III	LIGHTING	●	●	●	●	●
CLIO III	MULTIMED. CONNECTION	●	●	●	●	●
CLIO III	MULTIMEDIA INTERFACE	●	●	●	●	●
CLIO III	PARKING ASSISTANCE	●	●	●	●	●
CLIO III	RADIO	●	●	●	●	●

Vehicle Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Function Test
CLIO III	TYRES	●	●	●	●	●
CLIO III	UCH	●	●	●	●	●
CLIO III	UPC	●	●	●	●	●
CLIO III	VARIABLE P. A. S.	●	●	●	●	●
CLIO V6	AIR CONDITIONING	●	●	●	●	●
CLIO V6	AIRBAG / PRETENSIONERS	●	●	●	●	●
CLIO V6	CONNECTION UNIT	●	●	●	●	○
CLIO V6	INJECTION	●	●	●	●	●
CLIO V6 PH 2	AIR CONDITIONING	●	●	●	●	○
CLIO V6 PH 2	AIRBAG / PRETENSIONERS	●	●	●	●	○
CLIO V6 PH 2	CONNECTION UNIT	●	●	●	●	●
CLIO V6 PH 2	IMMOBILISER	●	●	●	●	●
CLIO V6 PH 2	INJECTION	●	●	●	●	●
CLIOIIP2/3/4	A. B. S.	●	●	●	●	※
CLIOIIP2/3/4	AIR CONDITIONING	●	●	●	●	○
CLIOIIP2/3/4	AIRBAG / PRETENSIONERS	●	●	●	●	○
CLIOIIP2/3/4	AUTOMATIC GEARBOX	●	●	●	●	●
CLIOIIP2/3/4	CONNECTION UNIT	●	●	●	●	●
CLIOIIP2/3/4	DISCHARGE LAMP	●	●	●	●	○
CLIOIIP2/3/4	GAS INJ.	●	●	●	●	●
CLIOIIP2/3/4	IMMOBILISER	●	●	●	●	※
CLIOIIP2/3/4	INJECTION	●	●	●	●	●
CLIOIIP2/3/4	LIGHTING	●	●	●	●	○
CLIOIIP2/3/4	VARIABLE P. A. S.	●	●	●	●	○
DUSTER	4 WHEELS DRIVE	●	●	●	●	●
DUSTER	A. B. S.	●	●	●	●	●
DUSTER	AIRBAG / PRETENSIONERS	●	●	●	●	●
DUSTER	AUTOMATIC GEARBOX	●	●	●	●	●
DUSTER	INJECTION	●	●	●	●	●
DUSTER	RADIO	●	●	●	●	●
DUSTER	TRACKER	●	●	●	●	●
DUSTER	UCH	●	●	●	●	●
DUSTER	VARIABLE P. A. S.	●	●	●	●	●
ESPACE	A. B. S.	●	●	●	●	●
ESPACE	AIR CONDITIONING	●	●	●	●	●
ESPACE	AIRBAG / PRETENSIONERS	●	●	●	●	●
ESPACE	AUTOMATIC GEARBOX	●	●	●	●	●
ESPACE	CONNECTION UNIT	●	●	●	●	※

Vehicle Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Function Test
ESPACE	DISCHARGE LAMP	●	●	●	●	○
ESPACE	HEATER	●	●	●	●	●
ESPACE	IMMOBILISER	●	●	●	●	※
ESPACE	INJECTION	●	●	●	●	●
ESPACE	INSTRUMENT PANEL	●	※	※	●	※
ESPACE	LIGHTING	●	●	●	●	○
ESPACE IV	A. B. S.	●	●	●	●	●
ESPACE IV	AIR CONDITIONING	●	●	●	●	●
ESPACE IV	AIRBAG / PRETENSIONERS	●	●	●	●	●
ESPACE IV	AUTOMATIC GEARBOX	●	●	●	●	●
ESPACE IV	DISCHARGE LAMP	●	●	●	●	●
ESPACE IV	HANDS-FREE KIT	●	●	●	●	●
ESPACE IV	HEATER	●	●	●	●	●
ESPACE IV	INJECTION	●	●	●	●	●
ESPACE IV	INSTRUMENT PANEL	●	●	●	●	●
ESPACE IV	PARKING ASSISTANCE	●	●	●	●	●
ESPACE IV	PARKING BRAKE	●	●	●	●	●
ESPACE IV	UCH	●	●	●	●	●
ESPACEIV PH2	A. B. S.	●	●	●	●	●
ESPACEIV PH2	AIR CONDITIONING	●	●	●	●	●
ESPACEIV PH2	AIRBAG / PRETENSIONERS	●	●	●	●	●
ESPACEIV PH2	AUTOMATIC GEARBOX	●	●	●	●	●
ESPACEIV PH2	COMMUNICATIONS UNIT	●	●	●	●	●
ESPACEIV PH2	HEATER	●	●	●	●	●
ESPACEIV PH2	INJECTION	●	●	●	●	●
ESPACEIV PH2	INSTRUMENT PANEL	●	●	●	●	●
ESPACEIV PH2	LIGHTING	●	●	●	●	●
ESPACEIV PH2	MULTIMED. CONNECTION	●	●	●	●	●
ESPACEIV PH2	MULTIMEDIA INTERFACE	●	●	●	●	●
ESPACEIV PH2	PARKING ASSISTANCE	●	●	●	●	●
ESPACEIV PH2	PARKING BRAKE	●	●	●	●	●
ESPACEIV PH2	PARKING PROX CAN	●	●	●	●	●
ESPACEIV PH2	RADIO	●	●	●	●	●
ESPACEIV PH2	UCH	●	●	●	●	●
KANGOO	A. B. S.	●	●	●	●	●
KANGOO	AIR CONDITIONING	●	●	●	●	●
KANGOO	AIRBAG / PRETENSIONERS	●	●	●	●	●
KANGOO	AUTOMATIC GEARBOX	●	●	●	●	●

Vehicle Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Function Test
KANGOO	CONNECTION UNIT	●	●	●	●	○
KANGOO	GAS INJ.	●	●	●	●	●
KANGOO	HEATER	●	●	●	●	●
KANGOO	IMMOBILISER	●	●	●	●	●
KANGOO	INJECTION	●	●	●	●	※
KANGOO	INVERTER	●	●	●	●	○
KANGOO	SUPERVISOR	●	●	●	●	●
KANGOO II	A. B. S.	●	●	●	●	●
KANGOO II	ADAPTATION UNIT	●	●	●	●	●
KANGOO II	AIR CONDITIONING	●	●	●	●	●
KANGOO II	AIRBAG / PRETENSIONERS	●	●	●	●	●
KANGOO II	AUTOMATIC GEARBOX	●	●	●	●	●
KANGOO II	COMMUNICATIONS UNIT	●	●	●	●	●
KANGOO II	INJECTION	●	●	●	●	●
KANGOO II	INSTRUMENT PANEL	●	●	●	●	●
KANGOO II	MULTIMED. CONNECTION	●	●	●	●	●
KANGOO II	MULTIMEDIA INTERFACE	●	●	●	●	●
KANGOO II	PARKING ASSISTANCE	●	●	●	●	●
KANGOO II	RADIO	●	●	●	●	●
KANGOO II	UCH	●	●	●	●	●
KANGOO II	UPC	●	●	●	●	●
KANGOO II	TELEMATIC CTRL UNIT	●	●	●	●	●
KANGOO II	VARIABLE P. A. S.	●	●	●	●	●
KANGOO MUX	A. B. S.	●	●	●	●	※
KANGOO MUX	AIRBAG / PRETENSIONERS	●	●	●	●	●
KANGOO MUX	AUTOMATIC GEARBOX	●	●	●	●	●
KANGOO MUX	CONNECTION UNIT	●	●	●	●	●
KANGOO MUX	GAS INJ.	●	●	●	●	●
KANGOO MUX	IMMOBILISER	●	●	●	●	●
KANGOO MUX	INJECTION	●	●	●	●	●
KANGOO ZE/STOPSTART/PH2	A. B. S.	●	●	●	※	※
KANGOO ZE/STOPSTART/PH2	ADAPTATION UNIT	●	●	●	●	○
KANGOO ZE/STOPSTART/PH2	AIR CONDITIONING	●	●	●	●	●
KANGOO ZE/STOPSTART/PH2	AIRBAG / PRETENSIONERS	●	●	●	●	○
KANGOO ZE/STOPSTART/PH2	BCB	●	●	●	●	●
KANGOO ZE/STOPSTART/PH2	COMMUNICATIONS UNIT	●	●	●	●	○
KANGOO ZE/STOPSTART/PH2	EVC	●	●	●	●	○
KANGOO ZE/STOPSTART/PH2	HEATER	●	●	●	○	○

Vehicle Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Function Test
KANGOO ZE/STOPSTART/PH2	INSTRUMENT PANEL	●	●	●	●	●
KANGOO ZE/STOPSTART/PH2	LBC	●	●	●	●	●
KANGOO ZE/STOPSTART/PH2	LBC2	●	●	●	●	●
KANGOO ZE/STOPSTART/PH2	MULTIMED. CONNECTION	●	●	●	●	○
KANGOO ZE/STOPSTART/PH2	MULTIMEDIA INTERFACE	●	●	●	●	●
KANGOO ZE/STOPSTART/PH2	PARKING ASSISTANCE	●	●	●	●	○
KANGOO ZE/STOPSTART/PH2	PEB	●	●	●	●	●
KANGOO ZE/STOPSTART/PH2	INJECTION	●	●	●	●	●
KANGOO ZE/STOPSTART/PH2	RADIO	●	※	※	●	○
KANGOO ZE/STOPSTART/PH2	TELEMATIC CTRL UNIT	●	●	●	●	○
KANGOO ZE/STOPSTART/PH2	UCH	●	●	●	※	○
KANGOO ZE/STOPSTART/PH2	UPC	●	※	※	●	○
KANGOO ZE/STOPSTART/PH2	VARIABLE P. A. S.	●	●	●	●	○
KOLEOS/QM5	4 WHEELS DRIVE	●	●	●	●	●
KOLEOS/QM5	A. B. S.	●	●	●	●	●
KOLEOS/QM5	ADIVI	●	●	●	●	●
KOLEOS/QM5	AIRBAG / PRETENSIONERS	●	●	●	○	○
KOLEOS/QM5	AMPLIFIER	●	●	●	●	●
KOLEOS/QM5	AUTO FRONT LIGHTING	●	●	●	●	●
KOLEOS/QM5	AUTOMATIC GEARBOX	●	●	●	●	●
KOLEOS/QM5	COMMUNICATIONS UNIT	●	●	●	●	●
KOLEOS/QM5	DISCHARGE LAMP	●	●	●	●	●
KOLEOS/QM5	INJECTION	●	●	●	●	●
KOLEOS/QM5	INSTRUMENT PANEL	●	●	●	●	●
KOLEOS/QM5	MULTIMED. CONNECTION	●	●	●	●	●
KOLEOS/QM5	MULTIMEDIA INTERFACE	●	●	●	●	●
KOLEOS/QM5	PARKING BRAKE	●	●	●	●	●
KOLEOS/QM5	PARKING PROX CAN	●	●	●	●	●
KOLEOS/QM5	RADIO	●	●	※	●	●
KOLEOS/QM5	TYRES	●	●	●	●	●
KOLEOS/QM5	UCH	●	●	●	●	●
KOLEOS/QM5	UPC	●	●	●	●	●
KOLEOS/QM5	TELEMATIC CTRL UNIT	●	●	●	●	●
KOLEOS/QM5	VARIABLE P. A. S.	●	●	●	●	●
LAGUNA	A. B. S.	●	●	●	●	※
LAGUNA	AIR CONDITIONING	●	●	●	●	●
LAGUNA	AIRBAG / PRETENSIONERS	●	●	●	●	●
LAGUNA	AUTOMATIC GEARBOX	●	●	●	●	●

Vehicle Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Function Test
LAGUNA	IMMOBILISER	●	●	●	●	●
LAGUNA	INJECTION	●	●	●	●	●
LAGUNA	INSTRUMENT PANEL	●	●	●	●	●
LAGUNA	VARIABLE P. A. S.	●	●	●	●	●
LAGUNA	SEAT MANAGEMENT	●	●	●	●	●
LAGUNA	VOICE SYNTHESISER	●	●	●	●	●
LAGUNA II	A. B. S.	●	●	●	●	●
LAGUNA II	AIR CONDITIONING	●	●	●	●	●
LAGUNA II	AIRBAG / PRETENSIONERS	●	●	●	●	●
LAGUNA II	AUTOMATIC GEARBOX	●	●	●	●	●
LAGUNA II	DISCHARGE LAMP	●	●	●	●	●
LAGUNA II	GAS INJ.	●	●	●	●	●
LAGUNA II	HEATER	●	●	●	●	●
LAGUNA II	INJECTION	●	●	●	●	●
LAGUNA II	INSTRUMENT PANEL	●	●	●	●	●
LAGUNA II	PARKING ASSISTANCE	●	●	●	●	●
LAGUNA II	UCH	●	●	●	●	●
LAGUNA III	4 WHEELS STEERING	●	●	●	●	○
LAGUNA III	A. B. S.	●	●	●	●	○
LAGUNA III	AIR CONDITIONING	●	●	●	●	○
LAGUNA III	AIRBAG / PRETENSIONERS	●	●	●	●	○
LAGUNA III	AMPLIFIER	●	●	●	●	○
LAGUNA III	AUTOMATIC GEARBOX	●	●	●	●	○
LAGUNA III	COMMUNICATIONS UNIT	●	●	●	●	○
LAGUNA III	DRIVER'S DOOR	●	●	●	●	○
LAGUNA III	INJECTION	●	●	●	●	○
LAGUNA III	INSTRUMENT PANEL	●	●	●	●	○
LAGUNA III	LEFT-HAND DOOR	●	○	○	●	○
LAGUNA III	LIGHTING	●	●	●	●	○
LAGUNA III	MULTIMED. CONNECTION	●	●	●	●	○
LAGUNA III	MULTIMEDIA INTERFACE	●	●	●	●	○
LAGUNA III	PARKING BRAKE	●	●	●	●	○
LAGUNA III	PARKING PROX CAN	●	●	●	●	○
LAGUNA III	PASSENGER'S DOOR	●	●	●	●	○
LAGUNA III	RADIO	●	●	※	※	○
LAGUNA III	RIGHT-HAND DOOR	●	○	○	●	○
LAGUNA III	SEAT MANAGEMENT	●	●	●	●	○
LAGUNA III	UCH	●	●	●	●	○

Vehicle Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Function Test
LAGUNA III	UPC	●	●	●	●	○
LAGUNA III	TELEMATIC CTRL UNIT	●	●	●	●	●
LAGUNA III	VARIABLE P. A. S.	●	●	●	●	○
LAGUNA PHASE 2	A. B. S.	●	●	●	●	※
LAGUNA PHASE 2	AIR CONDITIONING	●	●	●	●	●
LAGUNA PHASE 2	AIRBAG / PRETENSIONERS	●	●	●	●	●
LAGUNA PHASE 2	AUTOMATIC GEARBOX	●	●	●	●	●
LAGUNA PHASE 2	GAS INJ.	●	●	●	●	●
LAGUNA PHASE 2	IMMOBILISER	●	●	●	●	●
LAGUNA PHASE 2	INJECTION	●	●	●	●	●
LAGUNA PHASE 2	INSTRUMENT PANEL	●	●	●	●	●
LAGUNA PHASE 2	SEAT MANAGEMENT	●	●	●	●	●
LAGUNA PHASE 2	VARIABLE P. A. S.	●	●	●	●	●
LAGUNA PHASE 2	VOICE SYNTHESISER	●	●	●	●	●
LAGUNAII PH2	A. B. S.	●	●	●	●	●
LAGUNAII PH2	AIR CONDITIONING	●	●	●	●	●
LAGUNAII PH2	AIRBAG / PRETENSIONERS	●	●	●	●	●
LAGUNAII PH2	AUTOMATIC GEARBOX	●	●	●	●	●
LAGUNAII PH2	COMMUNICATIONS UNIT	●	●	●	●	●
LAGUNAII PH2	HANDS-FREE KIT	●	●	●	●	●
LAGUNAII PH2	HEATER	●	●	●	●	●
LAGUNAII PH2	INJECTION	●	●	●	●	●
LAGUNAII PH2	INSTRUMENT PANEL	●	●	●	●	●
LAGUNAII PH2	LIGHTING	●	●	●	●	●
LAGUNAII PH2	PARKING ASSISTANCE	●	●	●	●	●
LAGUNAII PH2	PARKING BRAKE	●	●	●	●	●
LAGUNAII PH2	UCH	●	●	●	●	●
LATITUDE/SM5	A. B. S.	●	●	●	●	○
LATITUDE/SM6	ADIVI	●	●	●	●	○
LATITUDE/SM5	AIR CONDITIONING	●	●	●	●	●
LATITUDE/SM5	AIRBAG / PRETENSIONERS	●	●	●	○	○
LATITUDE/SM5	AMPLIFIER	●	●	●	●	○
LATITUDE/SM5	AUTOMATIC GEARBOX	●	●	●	●	●
LATITUDE/SM5	COMMUNICATIONS UNIT	●	●	●	●	○
LATITUDE/SM5	DRIVER'S DOOR	●	●	●	○	○
LATITUDE/SM5	INJECTION	●	●	●	※	○
LATITUDE/SM5	INSTRUMENT PANEL	●	●	●	●	※
LATITUDE/SM5	LEFT-HAND DOOR	●	○	○	○	○

Vehicle Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Function Test
LATITUDE/SM5	LIGHTING	●	●	●	●	○
LATITUDE/SM5	MULTIMED. CONNECTION	●	●	●	○	○
LATITUDE/SM5	MULTIMEDIA INTERFACE	●	●	●	●	○
LATITUDE/SM5	PARKING BRAKE	●	●	●	●	●
LATITUDE/SM5	PARKING PROX CAN	●	●	●	●	○
LATITUDE/SM5	PASSENGER' S DOOR	●	●	●	●	●
LATITUDE/SM5	RADIO	●	●	●	●	○
LATITUDE/SM5	RIGHT-HAND DOOR	●	○	○	○	○
LATITUDE/SM5	SEAT MANAGEMENT	●	●	●	●	●
LATITUDE/SM5	UCH	●	●	●	●	○
LATITUDE/SM5	UPC	●	●	●	●	○
LATITUDE/SM5	TELEMATIC CTRL UNIT	●	●	●	●	○
LATITUDE/SM5	VARIABLE P. A. S.	●	●	●	●	●
LOGAN	A. B. S.	●	●	●	●	●
LOGAN	AIRBAG / PRETENSIONERS	●	●	●	●	●
LOGAN	AUTOMATIC GEARBOX	●	●	●	●	●
LOGAN	GAS INJ.	●	●	●	●	●
LOGAN	INJECTION	●	●	●	●	●
LOGAN	RADIO	●	●	●	●	●
LOGAN	TRACKER	●	●	●	●	●
LOGAN	UCH	●	●	●	●	●
LOGAN	VARIABLE P. A. S.	●	●	●	●	●
MAST. RWD. PH2	A. B. S.	●	●	●	●	●
MAST. RWD. PH2	ADAPTATION UNIT	●	●	●	●	○
MAST. RWD. PH2	AIRBAG / PRETENSIONERS	●	●	●	●	●
MAST. RWD. PH2	CONNECTION UNIT	●	●	●	●	●
MAST. RWD. PH2	DRIVING SCHOOL UNIT	●	●	●	●	○
MAST. RWD. PH2	IMMOBILISER	●	●	●	●	●
MAST. RWD. PH2	INJECTION	●	●	●	●	●
MAST. RWD. PH3	A. B. S.	●	●	●	●	●
MAST. RWD. PH3	ADAPTATION UNIT	●	●	●	●	●
MAST. RWD. PH3	AIRBAG / PRETENSIONERS	●	●	●	●	●
MAST. RWD. PH3	COMMUNICATIONS UNIT	●	●	●	●	●
MAST. RWD. PH3	INJECTION	●	●	●	●	●
MAST. RWD. PH3	UCH	●	●	●	●	●
MASTER	A. B. S.	●	●	●	●	○
MASTER	AIRBAG / PRETENSIONERS	●	●	●	●	●
MASTER	CONNECTION UNIT	●	●	●	●	○

Vehicle Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Function Test
MASTER	IMMOBILISER	●	●	●	●	●
MASTER	INJECTION	●	●	●	●	※
MASTER	PILOTED SUSPENSION	●	●	●	●	●
MASTER III	A. B. S.	●	●	●	●	○
MASTER III	ADAPTATION UNIT	●	●	●	●	○
MASTER III	AIR CONDITIONING	●	●	●	●	○
MASTER III	AIRBAG / PRETENSIONERS	●	●	●	●	○
MASTER III	AUTOMATIC GEARBOX	●	●	●	○	○
MASTER III	COMMUNICATIONS UNIT	●	●	●	●	○
MASTER III	INJECTION	●	●	●	●	○
MASTER III	INSTRUMENT PANEL	●	●	●	●	○
MASTER III	LIGHTING	●	●	●	●	○
MASTER III	MULTIMED. CONNECTION	●	●	●	●	○
MASTER III	MULTIMEDIA INTERFACE	●	●	●	●	○
MASTER III	PARKING ASSISTANCE	●	●	●	●	○
MASTER III	RADIO	●	※	※	●	○
MASTER III	SMART KEYLESS	●	●	●	○	○
MASTER III	TELEMATIC CTRL UNIT	●	●	●	●	○
MASTER III	UCH	●	●	●	●	○
MASTER III	TRACKER	●	●	●	●	●
MASTER III	UPC	●	●	●	●	○
MASTER PH 2	A. B. S.	●	●	●	●	●
MASTER PH 2	ADAPTATION UNIT	●	●	●	●	○
MASTER PH 2	AIRBAG / PRETENSIONERS	●	●	●	●	●
MASTER PH 2	AUTOMATIC GEARBOX	●	●	●	●	●
MASTER PH 2	CONNECTION UNIT	●	●	●	●	●
MASTER PH 2	DRIVING SCHOOL UNIT	●	●	●	●	○
MASTER PH 2	IMMOBILISER	●	●	●	●	●
MASTER PH 2	INJECTION	●	●	●	●	●
MASTER PH 2	PARKING ASSISTANCE	●	●	●	●	○
MASTER PH 2	PILOTED SUSPENSION	●	●	●	●	●
MASTER PH 3	A. B. S.	●	●	●	●	●
MASTER PH 3	ADAPTATION UNIT	●	●	●	●	●
MASTER PH 3	AIRBAG / PRETENSIONERS	●	●	●	●	●
MASTER PH 3	AUTOMATIC GEARBOX	●	●	●	●	●
MASTER PH 3	COMMUNICATIONS UNIT	●	●	●	●	●
MASTER PH 3	INJECTION	●	●	●	●	●
MASTER PH 3	PARKING ASSISTANCE	●	●	●	●	●

Vehicle Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Function Test
MASTER PH 3	PILOTED SUSPENSION	●	●	●	●	●
MASTER PH 3	TRACKER	●	●	●	●	●
MASTER PH 3	UCH	●	●	●	●	●
MASTER RWD	AIRBAG / PRETENSIONERS	●	●	●	●	●
MASTER RWD	CONNECTION UNIT	●	●	●	●	○
MASTER RWD	IMMOBILISER	●	●	●	●	●
MASTER RWD	INJECTION	●	●	●	●	●
MEGANE II	A. B. S.	●	●	●	●	●
MEGANE II	AIR CONDITIONING	●	●	●	●	●
MEGANE II	AIRBAG / PRETENSIONERS	●	●	●	●	●
MEGANE II	AUTOMATIC GEARBOX	●	●	●	●	●
MEGANE II	COMMUNICATIONS UNIT	●	●	●	●	●
MEGANE II	DISCHARGE LAMP	●	●	●	●	●
MEGANE II	GAS INJ.	●	●	●	●	●
MEGANE II	INJECTION	●	●	●	●	●
MEGANE II	INSTRUMENT PANEL	●	●	●	●	●
MEGANE II	LEFT COSLAD	●	●	●	●	●
MEGANE II	LIGHTING	●	●	●	●	●
MEGANE II	PARKING ASSISTANCE	●	●	●	●	●
MEGANE II	RIGHT COSLAD	●	●	●	●	●
MEGANE II	SUNROOF CONTROL UNIT	●	●	●	●	●
MEGANE II	TRACKER	●	●	●	●	●
MEGANE II	UCH	●	●	●	●	●
MEGANE II	UPC	●	●	●	●	●
MEGANE II	VARIABLE P. A. S.	●	●	●	●	●
MEGANE/SCEN.	A. B. S.	●	●	●	●	●
MEGANE/SCEN.	AIR CONDITIONING	●	●	●	●	●
MEGANE/SCEN.	AIRBAG / PRETENSIONERS	●	●	●	●	●
MEGANE/SCEN.	AUTOMATIC GEARBOX	●	●	●	●	●
MEGANE/SCEN.	GAS INJ.	●	●	●	●	●
MEGANE/SCEN.	INJECTION	●	●	●	●	※
MEGANE/SCEN.	SEAT MANAGEMENT	●	●	●	●	●
MEGANE/SCEN.	SUNROOF CONTROL UNIT	●	●	●	●	●
MEGANE/SCEN.	IMMOBILISER	●	●	●	●	○
MEGANE/SCEN.	CONNECTION UNIT	●	●	●	●	○
MEGANE/SCEN.	TYRES	●	●	●	●	○
MEGANEIII/SCENICIII	A. B. S.	●	●	●	●	○
MEGANEIII/SCENICIII	AIR CONDITIONING	●	●	●	●	○

Vehicle Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Function Test
MEGANEIII/SCENICIII	AIRBAG / PRETENSIONERS	●	●	●	●	○
MEGANEIII/SCENICIII	AUTOMATIC GEARBOX	●	●	●	○	○
MEGANEIII/SCENICIII	COMMUNICATIONS UNIT	●	●	●	●	○
MEGANEIII/SCENICIII	DRIVER'S DOOR	●	●	●	●	○
MEGANEIII/SCENICIII	FRONT CAMERA	●	●	●	●	○
MEGANEIII/SCENICIII	INJECTION	●	●	●	●	○
MEGANEIII/SCENICIII	INSTRUMENT PANEL	●	●	●	●	○
MEGANEIII/SCENICIII	LIGHTING	●	●	●	●	○
MEGANEIII/SCENICIII	MULTIMED. CONNECTION	●	●	●	●	○
MEGANEIII/SCENICIII	MULTIMEDIA INTERFACE	●	●	●	●	○
MEGANEIII/SCENICIII	PARKING BRAKE	●	●	●	●	○
MEGANEIII/SCENICIII	PARKING PROX CAN	●	●	●	●	○
MEGANEIII/SCENICIII	PASSENGER'S DOOR	●	●	●	●	○
MEGANEIII/SCENICIII	RADIO	●	※	※	●	○
MEGANEIII/SCENICIII	SEAT MANAGEMENT	●	●	●	○	○
MEGANEIII/SCENICIII	SUNROOF CONTROL UNIT	●	●	●	※	○
MEGANEIII/SCENICIII	TELEMATIC CTRL UNIT	●	●	●	●	○
MEGANEIII/SCENICIII	UCH	●	●	●	●	○
MEGANEIII/SCENICIII	UPC	●	●	●	●	○
MEGANEIII/SCENICIII	VARIABLE P. A. S.	●	●	●	●	○
MODUS	A. B. S.	●	●	●	●	●
MODUS	AIR CONDITIONING	●	●	●	●	●
MODUS	AIRBAG / PRETENSIONERS	●	●	●	●	●
MODUS	AUTOMATIC GEARBOX	●	●	●	●	●
MODUS	HANDS-FREE KIT	●	●	●	●	●
MODUS	INJECTION	●	●	●	●	●
MODUS	INSTRUMENT PANEL	●	●	●	●	●
MODUS	LIGHTING	●	●	●	●	●
MODUS	PARKING ASSISTANCE	●	●	●	●	●
MODUS	TYRES	●	●	●	●	●
MODUS	UCH	●	●	●	●	●
MODUS	UPC	●	●	●	●	●
MODUS	VARIABLE P. A. S.	●	●	●	●	●
NEW SM3/FLUENCE/MEGANE	A. B. S.	●	●	●	●	○
NEW SM3/FLUENCE/MEGANE	AIR CONDITIONING	●	●	●	●	○
NEW SM3/FLUENCE/MEGANE	AIRBAG / PRETENSIONERS	●	●	●	●	○
NEW SM3/FLUENCE/MEGANE	AMPLIFIER	●	●	●	●	○
NEW SM3/FLUENCE/MEGANE	AUTOMATIC GEARBOX	●	●	●	※	○

Vehicle Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Function Test
NEW SM3/FLUENCE/MEGANE	BCB	●	●	●	○	○
NEW SM3/FLUENCE/MEGANE	COMMUNICATIONS UNIT	●	●	●	※	○
NEW SM3/FLUENCE/MEGANE	DRIVER' S DOOR	●	●	●	●	○
NEW SM3/FLUENCE/MEGANE	EVC	●	●	●	●	○
NEW SM3/FLUENCE/MEGANE	INJECTION	●	●	●	●	○
NEW SM3/FLUENCE/MEGANE	INSTRUMENT PANEL	●	●	●	●	○
NEW SM3/FLUENCE/MEGANE	LBC	●	●	●	●	○
NEW SM3/FLUENCE/MEGANE	LBC2	●	●	●	○	○
NEW SM3/FLUENCE/MEGANE	LIGHTING	●	●	●	●	○
NEW SM3/FLUENCE/MEGANE	MULTIMED. CONNECTION	●	●	●	●	●
NEW SM3/FLUENCE/MEGANE	MULTIMEDIA INTERFACE	●	●	●	●	○
NEW SM3/FLUENCE/MEGANE	PARKING BRAKE	●	●	●	●	○
NEW SM3/FLUENCE/MEGANE	PARKING PROX CAN	●	●	●	●	○
NEW SM3/FLUENCE/MEGANE	PEB	●	●	●	○	○
NEW SM3/FLUENCE/MEGANE	RADIO	●	※	※	●	○
NEW SM3/FLUENCE/MEGANE	SUNROOF CONTROL UNIT	●	●	●	●	○
NEW SM3/FLUENCE/MEGANE	TELEMATIC CTRL UNIT	●	●	●	●	○
NEW SM3/FLUENCE/MEGANE	TRACKER	●	●	●	●	●
NEW SM3/FLUENCE/MEGANE	UCH	●	●	●	●	○
NEW SM3/FLUENCE/MEGANE	UPC	●	●	●	●	○
NEW SM3/FLUENCE/MEGANE	VARIABLE P. A. S.	●	●	●	●	○
SANDERO	A. B. S.	●	●	●	●	●
SANDERO	AIRBAG / PRETENSIONERS	●	●	●	●	●
SANDERO	AUTOMATIC GEARBOX	●	●	●	●	●
SANDERO	GAS INJ.	●	●	●	●	●
SANDERO	INJECTION	●	●	●	●	●
SANDERO	RADIO	●	●	●	●	●
SANDERO	TRACKER	●	●	●	●	●
SANDERO	UCH	●	●	●	●	●
SANDERO	VARIABLE P. A. S.	●	●	●	●	●
SCENIC II	A. B. S.	●	●	●	●	●
SCENIC II	AIR CONDITIONING	●	●	●	●	●
SCENIC II	AIRBAG / PRETENSIONERS	●	●	●	●	●
SCENIC II	AUTOMATIC GEARBOX	●	●	●	●	●
SCENIC II	COMMUNICATIONS UNIT	●	●	●	●	●
SCENIC II	DISCHARGE LAMP	●	●	●	●	●
SCENIC II	GAS INJ.	●	●	●	●	●
SCENIC II	INJECTION	●	●	●	●	●

Vehicle Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Function Test
SCENIC II	INSTRUMENT PANEL	●	●	●	●	●
SCENIC II	MULTIMEDIA INTERFACE	●	●	●	●	●
SCENIC II	PARKING ASSISTANCE	●	●	●	●	●
SCENIC II	PARKING BRAKE	●	●	●	●	●
SCENIC II	PARKING PROX CAN	●	●	●	●	●
SCENIC II	RADIO	●	●	●	●	●
SCENIC II	UCH	●	●	●	●	●
SCENIC II	UPC	●	●	●	●	●
SCENIC II	VARIABLE P. A. S.	●	●	●	●	●
SM7 - L47	A. B. S.	●	●	●	※	※
SM7 - L47	ADIVI	●	●	●	●	●
SM7 - L47	AIR CONDITIONING	●	●	●	●	●
SM7 - L47	AIRBAG / PRETENSIONERS	●	●	●	○	●
SM7 - L47	AMPLIFIER	●	●	●	●	○
SM7 - L47	AUTOMATIC GEARBOX	●	●	●	○	○
SM7 - L47	COMMUNICATIONS UNIT	●	●	●	●	○
SM7 - L47	DRIVER'S DOOR	●	●	●	○	○
SM7 - L47	INJECTION	●	●	●	※	※
SM7 - L47	INSTRUMENT PANEL	●	●	●	●	○
SM7 - L47	LEFT-HAND DOOR	●	○	○	○	○
SM7 - L47	LIGHTING	●	●	●	●	●
SM7 - L47	MULTIMED. CONNECTION	●	●	●	○	○
SM7 - L47	MULTIMEDIA INTERFACE	●	●	●	●	○
SM7 - L47	PARKING BRAKE	●	●	●	●	●
SM7 - L47	PARKING PROX CAN	●	●	●	●	○
SM7 - L47	PASSENGER'S DOOR	●	●	●	●	●
SM7 - L47	RADIO	●	●	●	●	○
SM7 - L47	RIGHT-HAND DOOR	●	○	○	○	○
SM7 - L47	SEAT MANAGEMENT	●	●	●	○	●
SM7 - L47	UCH	●	●	●	●	●
SM7 - L47	UPC	●	●	●	●	●
THALIA/SYMB. 2	A. B. S.	●	●	●	●	●
THALIA/SYMB. 2	AIR CONDITIONING	●	●	●	●	●
THALIA/SYMB. 2	AIRBAG / PRETENSIONERS	●	●	●	●	●
THALIA/SYMB. 2	AUTOMATIC GEARBOX	●	●	●	●	●
THALIA/SYMB. 2	INJECTION	●	●	●	●	●
THALIA/SYMB. 2	TRACKER	●	●	●	●	●
THALIA/SYMB. 2	UCH	●	●	●	●	●

Vehicle Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Function Test
THALIA/SYMB. 2	VARIABLE P. A. S.	●	●	●	●	○
THALIA/SYMBL	A. B. S.	●	●	●	●	※
THALIA/SYMBL	AIR CONDITIONING	●	●	●	●	※
THALIA/SYMBL	AIRBAG / PRETENSIONERS	●	●	●	●	●
THALIA/SYMBL	AUTOMATIC GEARBOX	●	●	●	●	●
THALIA/SYMBL	CONNECTION UNIT	●	●	●	●	※
THALIA/SYMBL	IMMOBILISER	●	●	●	●	※
THALIA/SYMBL	INJECTION	●	●	●	●	●
TRAFIC II	A. B. S.	●	●	●	●	※
TRAFIC II	ADAPTATION UNIT	●	●	●	●	○
TRAFIC II	AIRBAG / PRETENSIONERS	●	●	●	●	●
TRAFIC II	AUTOMATIC GEARBOX	●	●	●	●	●
TRAFIC II	CONNECTION UNIT	●	●	●	●	●
TRAFIC II	DRIVING SCHOOL UNIT	●	●	●	●	○
TRAFIC II	HEATER	●	●	●	●	●
TRAFIC II	IMMOBILISER	●	●	●	●	●
TRAFIC II	INJECTION	●	●	●	●	●
TRAFICII P2/3	A. B. S.	●	●	●	●	●
TRAFICII P2/3	ADAPTATION UNIT	●	●	●	●	●
TRAFICII P2/3	AIR CONDITIONING	●	●	●	●	●
TRAFICII P2/3	AIRBAG / PRETENSIONERS	●	●	●	●	●
TRAFICII P2/3	AUTOMATIC GEARBOX	●	●	●	●	●
TRAFICII P2/3	COMMUNICATIONS UNIT	●	●	●	●	●
TRAFICII P2/3	HEATER	●	●	●	●	●
TRAFICII P2/3	INJECTION	●	●	●	●	●
TRAFICII P2/3	INSTRUMENT PANEL	●	●	●	●	●
TRAFICII P2/3	MULTIMED. CONNECTION	●	●	●	●	●
TRAFICII P2/3	MULTIMEDIA INTERFACE	●	●	●	●	●
TRAFICII P2/3	PARKING ASSISTANCE	●	●	●	●	●
TRAFICII P2/3	RADIO	●	●	●	●	●
TRAFICII P2/3	UCH	●	●	●	●	●
TWINGO II	A. B. S.	●	●	●	●	●
TWINGO II	AIR CONDITIONING	●	●	●	●	●
TWINGO II	AIRBAG / PRETENSIONERS	●	●	●	●	●
TWINGO II	AUTOMATIC GEARBOX	●	●	●	●	●
TWINGO II	INJECTION	●	●	●	●	●
TWINGO II	INSTRUMENT PANEL	●	●	●	●	●
TWINGO II	MULTIMED. CONNECTION	●	●	●	●	●

Vehicle Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Function Test
TWINGO II	MULTIMEDIA INTERFACE	●	●	●	●	●
TWINGO II	PARKING ASSISTANCE	●	●	●	●	●
TWINGO II	RADIO	●	●	●	●	●
TWINGO II	REV COUNTER/SYMBOL	●	●	※	●	●
TWINGO II	UCH	●	●	●	●	●
TWINGO II	VARIABLE P. A. S.	●	●	●	●	●
TWINGO PHASE 2	A. B. S.	●	●	●	●	※
TWINGO PHASE 2	AIRBAG / PRETENSIONERS	●	●	●	●	●
TWINGO PHASE 2	AUTOMATIC GEARBOX	●	●	●	●	●
TWINGO PHASE 2	CONNECTION UNIT	●	●	●	●	※
TWINGO PHASE 2	GAS INJ.	●	●	●	●	●
TWINGO PHASE 2	IMMOBILISER	●	●	●	●	※
TWINGO PHASE 2	INJECTION	●	●	●	●	※
VEL Satis	A. B. S.	●	●	●	●	●
VEL Satis	AIR CONDITIONING	●	●	●	●	●
VEL Satis	AIRBAG / PRETENSIONERS	●	●	●	●	●
VEL Satis	AUTOMATIC GEARBOX	●	●	●	●	●
VEL Satis	DISCHARGE LAMP	●	●	●	●	●
VEL Satis	DISTANCE REGULATOR	●	●	●	●	●
VEL Satis	HEATER	●	●	●	●	●
VEL Satis	INJECTION	●	●	●	●	●
VEL Satis	HANDS-FREE KIT	●	●	●	●	●
VEL Satis	INSTRUMENT PANEL	●	●	●	●	●
VEL Satis	PARKING ASSISTANCE	●	●	●	●	●
VEL Satis	PARKING BRAKE	●	●	●	●	●
VEL Satis	TYRES	●	●	●	●	●
VEL Satis	UCH	●	●	●	●	●
VELSatis PH2	A. B. S.	●	●	●	●	●
VELSatis PH2	AIR CONDITIONING	●	●	●	●	●
VELSatis PH2	AIRBAG / PRETENSIONERS	●	●	●	●	●
VELSatis PH2	AUTOMATIC GEARBOX	●	●	●	●	●
VELSatis PH2	COMMUNICATIONS UNIT	●	●	●	●	●
VELSatis PH2	HANDS-FREE KIT	●	●	●	●	●
VELSatis PH2	HEATER	●	●	●	●	●
VELSatis PH2	INJECTION	●	●	●	●	●
VELSatis PH2	INSTRUMENT PANEL	●	●	●	●	●
VELSatis PH2	LIGHTING	●	●	●	●	●
VELSatis PH2	PARKING ASSISTANCE	●	●	●	●	●

Vehicle Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Function Test
VELSATIS PH2	PARKING BRAKE	●	●	●	●	●
VELSATIS PH2	PARKING PROX CAN	●	●	●	●	●
VELSATIS PH2	UCH	●	●	●	●	●
WIND	A. B. S.	●	●	●	●	●
WIND	AIR CONDITIONING	●	●	●	●	●
WIND	AIRBAG / PRETENSIONERS	●	●	●	●	●
WIND	INJECTION	●	●	●	●	●
WIND	INSTRUMENT PANEL	●	●	●	●	●
WIND	MULTIMED. CONNECTION	●	●	●	●	●
WIND	MULTIMEDIA INTERFACE	●	●	●	●	●
WIND	RADIO	●	●	●	●	●
WIND	SUNROOF CONTROL UNIT	●	●	●	●	●
WIND	UCH	●	●	●	●	●
WIND	VARIABLE P. A. S.	●	●	●	●	●
LODGY	A. B. S.	●	●	●	●	●
LODGY	AIRBAG / PRETENSIONERS	●	●	●	●	●
LODGY	VARIABLE P. A. S.	●	●	●	●	●
LODGY	RADIO	●	●	●	●	※
LODGY	UCH	●	●	●	●	●
LODGY	INSTRUMENT PANEL	●	●	●	●	●
LODGY	INJECTION	●	●	●	●	●
DOKKER	A. B. S.	●	●	●	●	●
DOKKER	AIRBAG / PRETENSIONERS	●	●	●	●	●
DOKKER	VARIABLE P. A. S.	●	●	●	●	●
DOKKER	RADIO	●	●	●	●	※
DOKKER	UCH	●	●	●	●	●
DOKKER	INSTRUMENT PANEL	●	●	●	●	●
DOKKER	INJECTION	●	●	●	●	●
LOGAN II/SANDERO II	TRACKER	●	●	●	●	●
LOGAN II/SANDERO II	AIRBAG / PRETENSIONERS	●	●	●	●	●
LOGAN II/SANDERO II	VARIABLE P. A. S.	●	●	●	●	●
LOGAN II/SANDERO II	RADIO	●	●	●	●	※
LOGAN II/SANDERO II	UCH	●	●	●	●	●
LOGAN II/SANDERO II	INSTRUMENT PANEL	●	●	●	●	●
LOGAN II/SANDERO II	INJECTION	●	●	●	●	●
LOGAN II/SANDERO II	A. B. S.	●	●	●	●	●
LOGAN II/SANDERO II	AIR CONDITIONING	●	●	●	●	●
TWIZY	UCH	●	●	●	●	●

Vehicle Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Function Test
TWIZY	AIRBAG / PRETENSIONERS	●	●	●	●	●
TWIZY	INSTRUMENT PANEL	●	○	○	●	●
TWIZY	LBC	●	●	●	●	●
ZOE	VARIABLE P. A. S.	●	●	●	●	○
ZOE	TELEMATIC CTRL UNIT	●	●	●	●	○
ZOE	AIRBAG / PRETENSIONERS	●	●	●	●	●
ZOE	RADIO	●	●	●	●	○
ZOE	A. B. S.	●	●	●	●	●
ZOE	UNCOUPLED PEDAL	●	●	●	●	●
ZOE	PARKING PROX CAN	●	●	●	●	○
ZOE	AIR CONDITIONING	●	●	●	●	●
ZOE	COMMUNICATIONS UNIT	●	●	●	○	○
ZOE	LBC	●	●	●	●	●
ZOE	BCB	●	●	●	●	●
ZOE	INSTRUMENT PANEL	●	●	●	●	●
ZOE	EVC	●	●	●	●	○
ZOE	PEB	●	●	●	●	●
ZOE	UPC	●	●	●	●	●
ZOE	UCH	●	●	●	●	●
ZOE	LBC2	●	○	○	○	○
CLIO IV	AIRBAG / PRETENSIONERS	●	●	●	●	●
CLIO IV	RADIO	●	●	●	●	※
CLIO IV	UCH	●	●	●	●	●
CLIO IV	INJECTION	●	●	●	●	●
CLIO IV	A. B. S.	●	●	●	●	●
CLIO IV	PARKING PROX CAN	●	●	●	●	○
CLIO IV	AIR CONDITIONING	●	●	●	※	※
CLIO IV	INSTRUMENT PANEL	●	●	●	●	●
CLIO IV	HANDS-FREE MODULE	●	●	●	●	●
CLIO IV	COMMUNICATIONS UNIT	●	●	●	○	○
CLIO IV	VARIABLE P. A. S.	●	●	●	●	●
CLIO IV	UPC	●	●	●	●	●
CLIO IV	MULTIMEDIA INTERFACE	●	●	●	●	●
CLIO IV	TELEMATIC CTRL UNIT	●	●	●	●	●
CLIO IV	AUTOMATIC GEARBOX	●	●	●	●	●
CLIOIIPH6	INJECTION	●	●	●	●	●
CLIOIIPH6	TRACKER	●	●	●	●	●
CLIOIIPH6	UCH	●	●	●	●	●