

MaxiDiag_Subaru_V2.10 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
○ This function is not supported. ▲ This function is the new feature in this version.
As for special function please refer to the special function table.

| System Name | Read Codes | Erase Codes |
|-----------------------------|------------|-------------|
| Engine Control System | ● | ● |
| Transmission Control System | ● | ● |
| Brake Control System | ● | ● |
| Airbag System | ● | ● |
| Integ. unit mode | ● | ● |
| CAN SYSTEM | ● | ○ |
| Cruise Control System | ● | ○ |
| Keyless access system | ● | ● |
| EPS SYSTEM | ● | ● |
| Occupant Detection System | ● | ● |
| Tire Pressuer monitor | ● | ● |
| Air Condition System | ● | ● |
| Parking Break System | ● | ● |