

MaxiDiag_Honda_V1.00 Function List

(Note:For reference only)

NOTES:

- This function is supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported.
- ▲ This function is the new feature in this version.

System	ECU Info.	Read codes	Erase Codes	Live Data
PGM-FI	●	●	●	●
DIESEL	●	●	●	●
A/T	●	●	●	●
CVT	●	●	●	●
ABS	●	●	●	●
SRS	●	●	●	●
EPS	●	●	●	●
POP-UP HOOD	●	●	●	●
IMA	●	●	●	●
IMMOBI	○	○	○	●
KEYLESS ACCESS (RL)	●	●	●	●
EVPS	●	●	●	●
CMS	●	●	●	●
ACM	●	●	●	●
TPMS	●	●	●	●
SH-AWD	●	●	●	●
VTM 4	●	●	●	●
LKAS CAMERA	●	●	●	●
LKAS CONTROL	●	●	●	●
iNVS	●	●	●	●
Honda Smart Parking	●	●	●	●
Adaptive cruise control(ACC)	●	●	●	●

System	ECU Info.	Read codes	Erase Codes	Live Data
Hydraulic booster	●	●	●	●
Active Damper System	●	●	●	●
4WS	●	●	●	●
DBW	●	●	●	●
ATTS	●	●	●	●
i-SHIFT	●	●	●	●
R/C ENG STARTER	○	○	○	○
BODY ELECTRICAL	●	●	●	●
BSI	●	●	●	●
Electric Parking Brake	●	●	●	●
MVCS	●	●	●	●
PCU	●	●	●	●
Active Damper System/Adaptive Damper System	●	●	●	●
CAN Gateway	●	●	●	○
EDLC	●	●	●	●
Electric Servo Brake System	●	●	●	●
Precision All Wheel Steer	●	●	●	●
Real Time AWD/AWD with Intelligent Control	●	●	●	●
SVT	●	●	●	●