

MaxiSys_GmBrazil_V2.11 Function List (Note:For reference only)

NOTES:

- This function is supported. ✘ This function may be supported which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

Year	Vehicle Type	System Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
(A) 2010	Agile	Engine	Engine Control Module	●	●	●	●	●	F8 F21 F35 F39 F41 F43 F45 F50 F51
(B) 2011-(C) 2012	Agile	Engine	Engine Control Module	●	●	●	●	●	F8 F21 F35 F39 F41 F43 F45 F50 F51
(D) 2013-(F) 2015	Agile	Engine	Engine Control Module	●	●	●	●	●	F8 F21 F35 F39 F41 F43 F45 F50 F51
(A) 2010-(C) 2012	Agile	Engine	N14YF 1.4 (LKF)	●	●	●	●	●	F8 F21 F35 F39 F41 F43 F45 F50 F51
(D) 2013-(F) 2015	Agile	Engine	N14YF 1.4 (LKF)	●	●	●	●	●	F8 F21 F35 F39 F41 F43 F45 F50 F51
(A) 2010	Agile	Engine	Z14SE 1.4 (LQ5)	●	●	●	●	●	F21 F39 F41 F43 F45 F50 F51
(B) 2011-(F) 2015	Agile	Engine	Z14SE 1.4 (LQ5)	●	●	●	●	●	F21 F39 F41 F43 F45 F50 F51
(B) 2011-(F) 2015	Agile	Engine	Z18XE 1.8 (LJ1)	●	●	●	●	●	F21 F39 F41 F43 F45 F50 F51
(D) 2013	Agile	Transmission	MTA (Easytronic Magneti Marelli)	●	●	●	●	●	F3 F10 F20 F23 F46 F48 F59
(E) 2014-(F) 2015	Agile	Transmission	MTA (Easytronic Magneti Marelli)	●	●	●	●	●	F3 F10 F20 F23 F46 F48 F59
(A) 2010-(F) 2015	Agile	Chassis	Electronic Brake Control Module	●	●	●	●	●	F10 F20 F25
(A) 2010-2013	Agile	Body	Comfort Control Module		●	●	●	●	F60
(E) 2014-(F) 2015	Agile	Body	Comfort Control Module		●	●	●	●	F60
(A) 2010-(C) 2012	Agile	Body	Inflatable Restraint		●	●	●		
(D) 2013-(F) 2015	Agile	Body	Inflatable Restraint	●	●	●	●		F58 F61
(A) 2010-(B) 2011	Agile	Body	Instrument Cluster	●	●	●	●	●	F20 F57
(C) 2012	Agile	Body	Instrument Cluster	●	●	●	●	●	F20 F57
(D) 2013	Agile	Body	Instrument Cluster	●	●	●	●	●	F20 F57
(E) 2014-(F) 2015	Agile	Body	Instrument Cluster	●	●	●	●	●	F20 F57
(3) 2003-(6) 2006	Celta	Engine	C 10 NE	●	●	●	●	●	F53
(7) 2007-(F) 2015	Celta	Engine	C 10 NE	●	●	●	●	●	F53
(Y) 2000-(2) 2002	Celta	Engine	C 10 NE (E0/E20)	●	●	●	●	●	F53
(2) 2002-(5) 2005	Celta	Engine	C 10 YEH (E0/E20)	●	●	●	●	●	F53
(4) 2004-(6) 2006	Celta	Engine	C 14 SE (E0/E20)	●	●	●	●	●	F53
(7) 2007-(F) 2015	Celta	Engine	C 14 SE (E0/E20)	●	●	●	●	●	F53
(9) 2009	Celta	Engine	N 10 YFH (E20-E100)	●	●	●	●	●	F8 F53
(A) 2010-(F) 2015	Celta	Engine	N 10 YFH (E20-E100)	●	●	●	●	●	F8 F53
(9) 2009	Celta	Engine	N 14 YFH (E20-E100)	●	●	●	●	●	F8 F53
(A) 2010-(F) 2015	Celta	Engine	N 14 YFH (E20-E100)	●	●	●	●	●	F8 F53
(7) 2007-(F) 2015	Celta	Engine	X 10 NEL (E0)	●	●	●	●	●	F53
(6) 2006	Celta	Engine	X 10 YEL (E0/E20)	●	●	●	●	●	F53
(7) 2007-(F) 2015	Celta	Engine	X 10 YEL (E0/E20)	●	●	●	●	●	F53
(6) 2006	Celta	Engine	X 10 YFL (E20-E100)	●	●	●	●	●	F53

Year	Vehicle Type	System Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
(7) 2007–(F) 2015	Celta	Engine	X 10 YFL (E20–E100)	●	●	●	●	●	F53
(7) 2007–(F) 2015	Celta	Engine	X 14 SEL (E0)	●	●	●	●	●	F53
(7) 2007–(F) 2015	Celta	Engine	X 14 YFL (E20–E100)	●	●	●	●	●	F53
(9) 2009–(F) 2015	Celta	Engine	Y 14 NEL	●	●	●	●	●	F53
(B) 2011–(F) 2015	Celta	Engine	Z 14 SE	●	●	●	●	●	F53
(E) 2014–(F) 2015	Celta	Chassis	ABS 9	●	●	●	●	●	
(E) 2014–(F) 2015	Celta	Body	Airbag	●	●	●	●		F58
(8) 2008–(B) 2011	Celta	Body	Comfort Module	●	●	●	●	●	F31 F55
(C) 2012–(F) 2015	Celta	Body	Comfort Module	●	●	●	●	●	F31 F55
(Y) 2000–(F) 2015	Celta	Body	Immobiliser	●	●	●	●	●	F57
(Y) 2000–(6) 2006	Celta	Body	Instrument		●	●	●		
(7) 2007–(A) 2010	Celta	Body	Instrument		●	●	●		
(B) 2011–(F) 2015	Celta	Body	Instrument		●	●	●		
(E) 2014–(F) 2015	Celta	Body	Multiple Application Electrical		●	●			F54
(A) 2010–(F) 2015	Celta	Body	Vehicle Localisation&Immobilisation	●	●	●	●		F56
(X) 1999–(3) 2010	Corsa-B	Engine	16 NE (E0/E20)		●	●	●		
(4) 2004–(F) 2015	Corsa-B	Engine	16 NE (E0/E20)		●	●	●		
(X) 1999–(7) 2007	Corsa-B	Engine	C 10 NE (E0/E20)		●	●	●		
(X) 1999–(3) 2010	Corsa-B	Engine	C 10 SE (E0/E20)	●	●	●	●	●	F22 F28 F32 F34 F80
(X) 1999–(7) 2007	Corsa-B	Engine	C 10 YE (E100)		●	●	●		
(3) 2003	Corsa-B	Engine	C 10 YEH (E0/E20)	●	●	●	●	●	F53
(4) 2004	Corsa-B	Engine	C 10 YEH (E0/E20)	●	●	●	●	●	F53
(5) 2005–(7) 2007	Corsa-B	Engine	C 10 YEH (E0/E20)	●	●	●	●	●	F53
(X) 1999–(7) 2007	Corsa-B	Engine	C 14 NE (E0/E20)		●	●	●	●	
(X) 1999–(3) 2010	Corsa-B	Engine	C 16 SEL (E0/E20)	●	●	●	●	●	F22 F28 F32 F34 F80
(X) 1999–(1) 20015	Corsa-B	Engine	C 16 NE (E0/E20)		●	●	●		
(9) 2009	Corsa-B	Engine	N 10 YFH (E20–E100)	●	●	●	●	●	F8 F53
(A) 2010–(B) 2011	Corsa-B	Engine	N 10 YFH (E20–E100)	●	●	●	●	●	F8 F53
(C) 2012–(F) 2015	Corsa-B	Engine	N 10 YFH (E20–E100)	●	●	●	●	●	F8 F53
(5) 2005–(F) 2015	Corsa-B	Engine	X 10 YFL (E20–E100)	●	●	●	●	●	F53
(1) 2001–(3) 2010	Corsa-B	Engine	X 14 XE	●	●	●	●	●	F22 F28 F32 F34 F80
(9) 2009–(F) 2015	Corsa-B	Engine	Y 14 NEL	●	●	●	●	●	F53
(B) 2011–(C) 2012	Corsa-B	Engine	Z 14 SE	●	●	●	●	●	F53
(D) 2013–(F) 2015	Corsa-B	Engine	Z 14 SE	●	●	●	●	●	F53
(X) 1999–(F) 2015	Corsa-B	Transmission	AF 13II/20/22/30		●	●	●		
(D) 2013–(F) 2015	Corsa-B	Chassis	ABS 9	●	●	●	●	●	
(X) 1999–(F) 2015	Corsa-B	Chassis	ABS-5.3		●	●	●		
(D) 2013	Corsa-B	Body	Airbag	●	●	●	●		F58
(E) 2014–(F) 2015	Corsa-B	Body	Airbag	●	●	●	●		F58
(X) 1999–2013	Corsa-B	Body	Airbag-S		●	●	●		

Year	Vehicle Type	System Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
(X) 1999–(F) 2015	Corsa-B	Body	Anti Theft Warning		●	●	●		
(E) 2014–(F) 2015	Corsa-B	Body	Comfort Module	●	●	●	●	●	F31 F55
(X) 1999–(F) 2015	Corsa-B	Body	Immobiliser		●	●	●		
(3) 2003–(F) 2015	Corsa-B	Body	Immobiliser	●	●	●	●	●	F57
(4) 2004–(A) 2010	Corsa-B	Body	Instrument		●	●	●		
(B) 2011–(F) 2015	Corsa-B	Body	Instrument		●	●	●		
(D) 2013–(F) 2015	Corsa-B	Body	Multiple Application Electrical		●	●			F54
(9) 2009–(F) 2015	Corsa-B	Infotainment	Radio CAR 300		●	●	●		
(9) 2009–(F) 2015	Corsa-B	Infotainment	Triple Info Display		●	●	●		
(X) 1999–(3) 2003	Astra-G	Engine	C 18 NE (E0/E20)	●	●	●	●	●	F30 F38 F53 F67
(1) 2001–(5) 2005	Astra-G	Engine	C 18 YE (E100)	●	●	●	●	●	F30 F38 F53 F67
(X) 1999–(Y) 2000	Astra-G	Engine	C 20 NE (E0/E20)	●	●	●	●	●	F1 F30 F38 F53 F67
(1) 2001	Astra-G	Engine	C 20 NE/C 20 SE (8V) (E0/E20)	●	●	●	●	●	F1 F30 F38 F53 F67
(2) 2002–(C) 2012	Astra-G	Engine	C 20 NE/C 20 SE (8V) (E0/E20)	●	●	●	●	●	F1 F30 F38 F53 F67
(X) 1999–(Y) 2000	Astra-G	Engine	C 20 SE (E0/E20)	●	●	●	●	●	F1 F30 F38 F53 F67
(1) 2001–(C) 2012	Astra-G	Engine	C 20 SE/C 20 SEL (16V) (E0/E20)	●	●	●	●	●	F1 F30 F38 F53 F67
(9) 2009–(A) 2010	Astra-G	Engine	N 20 XF (E20–E100)	●	●	●	●	●	F8 F12 F36 F38 F53
(B) 2011–(C) 2012	Astra-G	Engine	N 20 XF (E20–E100)	●	●	●	●	●	F8 F12 F36 F38 F53
(3) 2003–(7) 2007	Astra-G	Engine	X 16 SE	●	●	●	●	●	F53 F64
(X) 1999–(4) 2004	Astra-G	Engine	X 20 DTL	●	●	●	●	●	F1 F53 F64 F75 F76 F77 F78
(4) 2004	Astra-G	Engine	X 20 SE	●	●	●	●	●	F1 F30 F38 F53 F67
(5) 2005–(7) 2007	Astra-G	Engine	X 20 SE	●	●	●	●	●	F1 F30 F36 F38 F53 F67
(5) 2005–(C) 2012	Astra-G	Engine	X 20 XE (E20–E100)	●	●	●	●	●	F36 F38 F53
(4) 2004	Astra-G	Engine	X 24 SE	●	●	●	●	●	F36 F38 F53
(5) 2005–(C) 2012	Astra-G	Engine	X 24 SE	●	●	●	●	●	F36 F38 F53
(7) 2007	Astra-G	Engine	Y 20 DTH	●	●	●	●	●	F1 F53 F64 F75 F76 F77 F78
(9) 2009–(C) 2012	Astra-G	Engine	Y 20 SE	●	●	●	●	●	F12 F36 F38 F53
(B) 2011–(C) 2012	Astra-G	Engine	Z 20 SE	●	●	●	●	●	F12 F36 F38 F53
(2) 2002–(C) 2012	Astra-G	Transmission	AF 13-II/17/20/22	●	●	●	●	●	F44
(3) 2003	Astra-G	Transmission	AF 13-II/17/20/22 CAN	●	●	●	●	●	F62 F64
(4) 2004–(C) 2012	Astra-G	Transmission	AF 13-II/17/20/22 CAN	●	●	●	●	●	F62 F64
(X) 1999–(4) 2004	Astra-G	Chassis	ABS-5.3/5.4 (+TC)		●	●	●	●	
(5) 2005–(C) 2012	Astra-G	Chassis	ABS-5.3/5.4 (+TC)	●	●	●	●	●	F62
(7) 2007–(C) 2012	Astra-G	Chassis	Cruise Control		●	●	●		
(Y) 2000–(C) 2012	Astra-G	Chassis	Electronic Power Steering		●	●	●	●	
(Y) 2000–(1) 2001	Astra-G	Body	Airbag		●	●			
(7) 2007–(C) 2012	Astra-G	Body	Airbag		●	●			
(X) 1999–(2) 2002	Astra-G	Body	Airbag SAB6		●	●			
(X) 1999–(1) 2001	Astra-G	Body	Anti Theft Warning		●	●	●		
(7) 2007–(8) 2008	Astra-G	Body	Anti Theft Warning		●	●	●		

Year	Vehicle Type	System Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
(X) 1999–(1) 2001	Astra-G	Body	Central Door Lock		●	●	●		
(7) 2007–(8) 2008	Astra-G	Body	Central Door Lock		●	●	●		
(9) 2009–(C) 2012	Astra-G	Body	Comfort Module	●	●	●	●	●	F31 F55
(3) 2003–(C) 2012	Astra-G	Body	Electronic Climate Control		●	●	●		
(X) 1999–(C) 2012	Astra-G	Body	Engine Cooling Module		●	●	●		
(X) 1999–(C) 2012	Astra-G	Body	Immobiliser	●	●	●	●	●	F57
(X) 1999–(C) 2012	Astra-G	Body	Instrument		●	●	●		
(X) 1999–(5) 2005	Astra-G	Infotainment	Multi Info Display		●	●	●		
(6) 2006–(C) 2012	Astra-G	Infotainment	Multi Info Display		●	●	●		
(3) 2003–(C) 2012	Astra-G	Infotainment	Radio CAR 400		●	●	●	●	
(4) 2004–(C) 2012	Astra-G	Infotainment	Radio CDR 500		●	●		●	
(X) 1999–(C) 2012	Astra-G	Infotainment	Triple Info Display		●	●	●		
(7) 2007–(3) 2010	Corsa-C	Engine	C 10 NE (E0/E20)	●	●	●	●	●	F53
(7) 2007–(3) 2010	Corsa-C	Engine	C 10 YE (E100)	●	●	●	●	●	F53
(2) 2002–(3) 2003	Corsa-C	Engine	C 10 YEH (E0/E20)	●	●	●	●	●	F53
(4) 2004–(5) 2005	Corsa-C	Engine	C 10 YEH (E0/E20)	●	●	●	●	●	F53
(3) 2003–(C) 2012	Corsa-C	Engine	C 14 NE (E0/E20)	●	●	●	●	●	F53
(3) 2003–(C) 2012	Corsa-C	Engine	C 14 SE	●	●	●	●	●	F53
(3) 2003–(C) 2012	Corsa-C	Engine	C 16 SE	●	●	●	●	●	F53
(2) 2002–(3) 2003	Corsa-C	Engine	C 18 NE (E0/E20)	●	●	●	●	●	F53
(4) 2004–(7) 2007	Corsa-C	Engine	C 18 NE (E0/E20)	●	●	●	●	●	F53
(8) 2008–(C) 2012	Corsa-C	Engine	C 18 NE (E0/E20)	●	●	●	●	●	F53
(4) 2004–(5) 2005	Corsa-C	Engine	C 18 XE (E20–E100)	●	●	●	●	●	F53
(9) 2009–(A) 2010	Corsa-C	Engine	N 14 YFH (E20–E100)	●	●	●	●	●	F8 F53
(B) 2011–(C) 2012	Corsa-C	Engine	N 14 YFH (E20–E100)	●	●	●	●	●	F8 F53
(9) 2009–(C) 2012	Corsa-C	Engine	N 18 XFH (E20–E100)	●	●	●	●	●	F8 F53
(6) 2006–(C) 2012	Corsa-C	Engine	T 18 NE	●	●	●	●	●	F53
(6) 2006–(C) 2012	Corsa-C	Engine	X 10 YFH (E20–E100)	●	●	●	●	●	F8 F36 F38 F53
(7) 2007	Corsa-C	Engine	X 14 YFH (E20–E100)	●	●	●	●	●	F8 F53
(8) 2008–(C) 2012	Corsa-C	Engine	X 14 YFH (E20–E100)	●	●	●	●	●	F8 F53
(4) 2004–(C) 2012	Corsa-C	Engine	X 18 NE	●	●	●	●	●	F53
(6) 2006–(7) 2007	Corsa-C	Engine	X 18 XF (E20–E100)	●	●	●	●	●	F8 F53
(8) 2008–(C) 2012	Corsa-C	Engine	X 18 XF (E20–E100)	●	●	●	●	●	F8 F53
(5) 2005–(C) 2012	Corsa-C	Engine	X 18 XML	●	●	●	●	●	F53
(3) 2003–(C) 2012	Corsa-C	Engine	Y 17 DT	●	●	●	●	●	F53
(2) 2002	Corsa-C	Engine	Y 17 DTL	●	●	●	●	●	F53
(3) 2003–(C) 2012	Corsa-C	Engine	Y 17 DTL	●	●	●	●	●	F53
(9) 2009–(C) 2012	Corsa-C	Engine	Y 18 NE	●	●	●	●	●	F53
(7) 2007–(C) 2012	Corsa-C	Transmission	Electronic Clutch	●	●	●	●	●	F3 F62 F63 F64
(4) 2004–(5) 2005	Corsa-C	Transmission	MTA (Easytronic)	●	●	●	●	●	F3 F62 F63 F64

Year	Vehicle Type	System Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
(6) 2006-(C) 2012	Corsa-C	Transmission	MTA (Easytronic)	●	●	●	●	●	F3 F62 F63 F64
(7) 2007-(C) 2012	Corsa-C	Chassis	ABS-5.3/5.4 (+TC)		●	●	●	●	
(2) 2002	Corsa-C	Chassis	Electronic Power Steering		●	●	●		F17
(3) 2003-(C) 2012	Corsa-C	Chassis	Electronic Power Steering		●	●	●		F17
(7) 2007-(C) 2012	Corsa-C	Body	Airbag	●	●	●	●		F58 F65
(7) 2007-(C) 2012	Corsa-C	Body	Body Control Module	●	●	●	●	●	F4 F14 F24 F31
(9) 2009-(C) 2012	Corsa-C	Body	Comfort Module	●	●	●	●	●	F31 F55
(7) 2007-(C) 2012	Corsa-C	Body	Immobiliser	●	●	●	●	●	F57
(4) 2004-(C) 2012	Corsa-C	Body	Immobiliser (without BCM)	●	●	●	●	●	F57
(7) 2007-(3) 2010	Corsa-C	Body	Instrument		●	●	●		
(4) 2004-(A) 2010	Corsa-C	Body	Instrument		●	●	●		
(B) 2011-(C) 2012	Corsa-C	Body	Instrument		●	●	●		
(4) 2004-(C) 2012	Corsa-C	Infotainment	Radio CAR 300		●	●	●		
(7) 2007-(C) 2012	Corsa-C	Infotainment	Triple Info Display		●	●	●		
(9) 2009-(A) 2010	E-Lux	Engine	N 20 XF (E20-E100)	●	●	●	●	●	F8 F12 F36 F38 F53
(B) 2011	E-Lux	Engine	N 20 XF (E20-E100)	●	●	●	●	●	F8 F12 F36 F38 F53
(6) 2006-(B) 2011	E-Lux	Engine	X 20 SE	●	●	●	●	●	F36 F38 F53
(6) 2006-(B) 2011	E-Lux	Engine	X 20 XE (E20-E100)	●	●	●	●	●	F36 F38 F53
(6) 2006-(B) 2011	E-Lux	Engine	X 24 SE	●	●	●	●	●	F36 F38 F53
(6) 2006-(B) 2011	E-Lux	Engine	X 24 SFD (E20-E100)	●	●	●	●	●	F8 F36 F38 F53
(9) 2009-(B) 2011	E-Lux	Engine	Y 20 SE	●	●	●	●	●	F12 F36 F38 F53
(9) 2009-(B) 2011	E-Lux	Engine	Y 24 SED	●	●	●	●	●	F12 F36 F38 F53
(B) 2011	E-Lux	Engine	Z 20 SE	●	●	●	●	●	F12 F36 F38 F53
(B) 2011	E-Lux	Engine	Z 24 SED	●	●	●	●	●	F12 F36 F38 F53
(6) 2006-(B) 2011	E-Lux	Transmission	AF 13-II/17/20/22 CAN	●	●	●	●	●	F62 F64
(9) 2009-(B) 2011	E-Lux	Chassis	ABS 8		●	●	●	●	
(6) 2006-(B) 2011	E-Lux	Chassis	ABS-5.3/5.4 (+TC)	●	●	●	●	●	F62
(6) 2006-(B) 2011	E-Lux	Chassis	Electronic Power Steering		●	●	●	●	
(6) 2006-(B) 2011	E-Lux	Body	Airbag	●	●	●	●		F58 F68
(9) 2009-(B) 2011	E-Lux	Body	Comfort Module	●	●	●	●	●	F31 F55
(6) 2006-(B) 2011	E-Lux	Body	Immobiliser	●	●	●	●	●	F57
(6) 2006-(B) 2011	E-Lux	Body	Instrument		●	●	●		
(6) 2006-(B) 2011	E-Lux	Infotainment	Multi Info Display		●	●	●		
(6) 2006-(B) 2011	E-Lux	Infotainment	Triple Info Display		●	●	●		
(3) 2003-(C) 2012	Meriva	Engine	C 18 NE (E0/E20)	●	●	●	●	●	F53
(3) 2003-(5) 2005	Meriva	Engine	C 18 SEL (E0/E20)	●	●	●	●	●	F53 F64
(4) 2004-(5) 2005	Meriva	Engine	C 18 XE (E20-E100)	●	●	●	●	●	F53
(9) 2009	Meriva	Engine	N 14 YFH (E20-E100)	●	●	●	●	●	F8 F53
(A) 2010-(C) 2012	Meriva	Engine	N 14 YFH (E20-E100)	●	●	●	●	●	F8 F53
(9) 2009	Meriva	Engine	N 18 XFH (E20-E100)	●	●	●	●	●	F8 F53

Year	Vehicle Type	System Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
(A) 2010–(C) 2012	Meriva	Engine	N 18 XFH (E20–E100)	●	●	●	●	●	F8 F53
(6) 2006–(C) 2012	Meriva	Engine	T 18 NE	●	●	●	●	●	F53
(9) 2009	Meriva	Engine	X 14 YFH (E20–E100)	●	●	●	●	●	F8 F53
(A) 2010–(C) 2012	Meriva	Engine	X 14 YFH (E20–E100)	●	●	●	●	●	F8 F53
(4) 2004–(5) 2005	Meriva	Engine	X 18 NE1	●	●	●	●	●	F53
(6) 2006–(7) 2007	Meriva	Engine	X 18 XF (E20–E100)	●	●	●	●	●	F8 F53
(8) 2008–(C) 2012	Meriva	Engine	X 18 XF (E20–E100)	●	●	●	●	●	F8 F53
(4) 2004–(C) 2012	Meriva	Engine	Y 17 DT	●	●	●	●	●	F53
(9) 2009–(C) 2012	Meriva	Engine	Y 18 NE	●	●	●	●	●	F53
(B) 2011–(C) 2012	Meriva	Engine	Z 18 NE	●	●	●	●	●	F53
(4) 2004–(5) 2005	Meriva	Transmission	MTA (Easytronic)	●	●	●	●	●	F3 F62 F63 F64
(6) 2006–(C) 2012	Meriva	Transmission	MTA (Easytronic)	●	●	●	●	●	F3 F62 F63 F64
(4) 2004–(C) 2012	Meriva	Chassis	ABS-5.3/5.4 (+TC)		●	●	●	●	
(4) 2004–(C) 2012	Meriva	Chassis	Electronic Power Steering		●	●	●	●	F17
(4) 2004–(C) 2012	Meriva	Body	Airbag	●	●	●	●		F58 F65
(3) 2003–(C) 2012	Meriva	Body	Body Control Module	●	●	●	●	●	F4 F14 F24 F31
(3) 2003–(C) 2012	Meriva	Body	Immobiliser	●	●	●	●	●	F57
(3) 2003–(C) 2012	Meriva	Body	Instrument		●	●	●	●	F40 F66
(3) 2003–(C) 2012	Meriva	Infotainment	Triple Info Display		●	●	●		
(X) 1999–(Y) 2000	Omega	Engine	V6		●	●	●	●	
(1) 2001–(4) 2004	Omega	Engine	V6		●	●	●	●	
(5) 2005	Omega	Engine	V6 Engine	●	●	●	●	●	F2 F19 F26 F39 F79
(6) 2006	Omega	Engine	V6 Engine	●	●	●	●	●	F2 F19 F26 F39 F79
(7) 2007	Omega	Engine	V6 Engine	●	●	●	●	●	F2 F19 F26 F39 F47
(8) 2008	Omega	Engine	V6 Engine	●	●	●	●	●	F2 F19 F26 F39 F47
(9) 2009	Omega	Engine	V6 Engine	●	●	●	●	●	F2 F19 F26 F39 F47
(B) 2011	Omega	Engine	V6 Engine	●	●	●	●	●	F2 F19 F26 F27 F39 F43 F47 F49
(X) 1999–(Y) 2000	Omega	Transmission	Automatic Transmission		●	●		●	
(1) 2001–(2) 2002	Omega	Transmission	Automatic Transmission		●	●		●	
(3) 2003–(4) 2004	Omega	Transmission	Automatic Transmission		●	●		●	
(5) 2005–(6) 2006	Omega	Transmission	Automatic Transmission	●	●	●	●	●	F19 F42
(7) 2007–(9) 2009	Omega	Transmission	Automatic Transmission	●	●	●	●	●	F19 F33 F42 F69
(B) 2011	Omega	Transmission	Automatic Transmission	●	●	●	●	●	F19 F33 F42 F69
(X) 1999–(2) 2002	Omega	Chassis	ABS / ETC		●	●			
(3) 2003–(4) 2004	Omega	Chassis	ABS / ETC		●	●			
(5) 2005	Omega	Chassis	ABS/TC/ESP 8.0		●	●	●	●	F15 F64
(6) 2006	Omega	Chassis	ABS/TC/ESP 8.0		●	●	●	●	F15 F64
(7) 2007–(9) 2009	Omega	Chassis	EBCM (Electronic Brake Control	●	●	●	●	●	
(B) 2011	Omega	Chassis	EBCM (Electronic Brake Control	●	●	●	●	●	F9 F15 F70
(B) 2011	Omega	Chassis	Fuel Pump Control Module	●	●	●	●		F37

Year	Vehicle Type	System Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
(3) 2003–(6) 2006	Omega	Body	Audio System	●	●	●	●	●	
(7) 2007–(9) 2009	Omega	Body	BCM (Body Control Module)	●	●	●	●	●	F52
(B) 2011	Omega	Body	BCM (Body Control Module)	●	●	●	●	●	F52
(X) 1999–(2) 2002	Omega	Body	Body Control Module		●	●	●	●	
(3) 2003–(4) 2004	Omega	Body	Body Control Module		●	●	●		
(5) 2005–(6) 2006	Omega	Body	Body Control Module		●	●	●	●	
(X) 1999–(2) 2002	Omega	Body	Electronic Climate Control		●	●	●	●	
(7) 2007–(B) 2011	Omega	Body	HVAC (Heating Ventilation and	●	●	●	●	●	F5 F13
(7) 2007–(B) 2011	Omega	Body	Immobiliser	●	●	●	●		
(X) 1999–(2) 2002	Omega	Body	Instrument		●	●	●		
(3) 2003–(6) 2006	Omega	Body	Instrument		●	●	●		
(7) 2007–(9) 2009	Omega	Body	IPC (Instrument Panel Cluster)	●	●	●	●	●	F40
(B) 2011	Omega	Body	IPC (Instrument Panel Cluster)	●	●	●	●	●	F40
(7) 2007–(B) 2011	Omega	Body	MSM (Memory Seat and Mirrors)	●	●	●	●	●	
(3) 2003–(6) 2006	Omega	Body	Occupant Climate Control		●	●	●		
(7) 2007–(B) 2011	Omega	Body	Park Assist	●	●	●	●	●	
(5) 2005–(6) 2006	Omega	Body	Powertrain Interface Module		●	●	●		
(7) 2007–(B) 2011	Omega	Body	RFA (Multipurpose Receiver Module)	●	●	●	●		F71 F72 F73
(7) 2007–(9) 2009	Omega	Body	SDM (Sensing and Diagnostic Module)	●	●	●	●		
(B) 2011	Omega	Body	SDM (Sensing and Diagnostic Module)	●	●	●	●		
(X) 1999–(2) 2002	Omega	Body	SRS		●	●	●		
(3) 2003–(6) 2006	Omega	Body	SRS		●	●	●		
(3) 2003–(6) 2006	Omega	Infotainment	Audio System		●	●	●	●	
(7) 2007–(9) 2009	Omega	Infotainment	Audio System	●	●	●	●	●	
(B) 2011	Omega	Infotainment	Audio System	●	●	●	●	●	
(7) 2007–(9) 2009	Omega	Infotainment	Driver Information Display	●	●	●	●	●	F74
(7) 2007–(B) 2011	Omega	Infotainment	RSE (Rear Seat Entertainment)	●	●	●	●	●	
(X) 1999–(Y) 2000	S-10 Truck / Blazer	Engine	B 22 NZ (E0/E20)		●	●	●		
(X) 1999–(Y) 2000	S-10 Truck / Blazer	Engine	C 22 NE (E0/E20)		●	●	●		
(1) 2001–(B) 2011	S-10 Truck / Blazer	Engine	C 24 NE (E0/E20)		●	●	●		
(9) 2009–(A) 2010	S-10 Truck / Blazer	Engine	N 24 XF (E20–E100)	●	●	●	●	●	F8 F12 F36 F38 F53
(B) 2011	S-10 Truck / Blazer	Engine	N 24 XF (E20–E100)	●	●	●	●	●	F8 F12 F36 F38 F53
(7) 2007–(B) 2011	S-10 Truck / Blazer	Engine	X 24 XF (E20–E100)	●	●	●	●	●	F8 F36 F38 F53
(6) 2006–(B) 2011	S-10 Truck / Blazer	Engine	Y 28 DTC	●	●	●	●	●	F18 F53 F55
(B) 2011	S-10 Truck / Blazer	Chassis	ABS 8		●	●	●	●	
(X) 1999–(Y) 2000	S-10 Truck / Blazer	Body	Airbag		●	●	●		
(1) 2001–(B) 2011	S-10 Truck / Blazer	Body	Immobiliser		●	●	●		
(7) 2007–(B) 2011	S-10 Truck / Blazer	Body	Immobiliser	●	●	●	●	●	F57
(1) 2001–(7) 2007	S-10 Truck / Blazer	Body	Instrument		●	●	●		
(8) 2008–(B) 2011	S-10 Truck / Blazer	Body	Instrument		●	●	●		

Year	Vehicle Type	System Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
(X) 1999–(3) 2003	Silverado / Grand Blazer	Engine	C 41 GE (E0/E22)		●	●	●		
(X) 1999–(3) 2010	Silverado / Grand Blazer	Chassis	Servotronic		●	●			
(W) 1998–(Y) 2000	Tigra	Engine	C 16 SEL (E0/E20)	●	●	●	●	●	F22 F28 F32 F34
(W) 1998–(Y) 2000	Tigra	Chassis	ABS-5.3		●	●	●	●	
(X) 1999–(Y) 2000	Tigra	Body	Airbag SAB6		●	●			
(W) 1998–(Y) 2000	Tigra	Body	Airbag-S		●	●	●		
(W) 1998–(Y) 2000	Tigra	Body	Anti Theft Warning		●	●	●		
(W) 1998–(Y) 2000	Tigra	Body	Immobiliser		●	●	●		
(1) 2001–(9) 2009	Tracker	Engine	C 20 SE AT		●	●	●		
(1) 2001–(9) 2009	Tracker	Engine	C 20 SE MT		●	●	●		
(7) 2007–(5) 2005	Tracker	Engine	RHZ - Diesel		●	●	●	●	
(1) 2001–(9) 2009	Tracker	Chassis	ABS		●	●	●	●	
(W) 1998	Vectra-B	Engine	C 20 NE (E0/E20)		●	●	●		
(3) 2003–(5) 2005	Vectra-B	Engine	C 20 NE (E0/E20)		●	●	●		
(W) 1998	Vectra-B	Engine	C 20 SEL (E0/E20)		●	●	●		
(W) 1998–(5) 2005	Vectra-B	Engine	C 22 NE (E0/E20)		●	●	●		
(W) 1998–(5) 2005	Vectra-B	Engine	C 22 SE (E0/E20)		●	●	●		
(W) 1998–(5) 2005	Vectra-B	Transmission	AF 13II/20/22/30		●	●	●		
(W) 1998–(X) 1999	Vectra-B	Chassis	ABS 415		●	●	●		
(Y) 2000–(5) 2005	Vectra-B	Chassis	ABS 430		●	●	●	●	
(W) 1998–(5) 2005	Vectra-B	Chassis	ABS-5.3		●	●	●		
(Y) 2000–(5) 2005	Vectra-B	Chassis	ABS-5.3/5.4 (+TC)		●	●	●	●	
(W) 1998–(X) 1999	Vectra-B	Chassis	ABS-5-TC		●	●			
(W) 1998–(5) 2005	Vectra-B	Body	Airbag		●	●	●		
(W) 1998–(Y) 2000	Vectra-B	Body	Anti Theft Warning		●	●	●		
(1) 2001	Vectra-B	Body	Anti Theft Warning		●	●	●		
(2) 2002–(5) 2005	Vectra-B	Body	Anti Theft Warning		●	●	●		
(W) 1998–(Y) 2000	Vectra-B	Body	Central Door Lock		●	●	●		
(1) 2001	Vectra-B	Body	Central Door Lock		●	●	●		
(2) 2002–(5) 2005	Vectra-B	Body	Central Door Lock		●	●	●		
(W) 1998–(5) 2005	Vectra-B	Body	Electronic Climate Control		●	●	●	●	
(W) 1998–(5) 2005	Vectra-B	Body	Immobiliser		●	●	●		
(W) 1998–(1) 2001	Vectra-B	Body	Instrument		●	●	●	●	
(W) 1998	Vectra-B	Infotainment	Multi Info Display		●	●	●		
(1) 2001	Zafira	Engine	C 20 SE (8V) (E0/E20)	●	●	●	●	●	F1 F30 F38 F53 F67
(7) 2007–(C) 2012	Zafira	Engine	C 20 SE (8V) (E0/E20)	●	●	●	●	●	F1 F30 F38 F53 F67
(1) 2001–(C) 2012	Zafira	Engine	C 20 SEL (16V) (E0/E20)	●	●	●	●	●	F1 F30 F38 F53 F67
(9) 2009–(B) 2011	Zafira	Engine	N 20 XF (E20–E100)	●	●	●	●	●	F8 F12 F36 F38 F53
(C) 2012	Zafira	Engine	N 20 XF (E20–E100)	●	●	●	●	●	F8 F12 F36 F38 F53
(5) 2005–(C) 2012	Zafira	Engine	X 20 XE (E20–E100)	●	●	●	●	●	F36 F38 F53

Year	Vehicle Type	System Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
(9) 2009-(C) 2012	Zafira	Engine	Y 20 SE	●	●	●	●	●	F12 F36 F38 F53
(4) 2004-(C) 2012	Zafira	Transmission	AF 13-II/17/20/22	●	●	●	●	●	F44
(4) 2004-(C) 2012	Zafira	Transmission	AF 13-II/17/20/22 CAN	●	●	●	●	●	F62 F64
(9) 2009-(C) 2012	Zafira	Chassis	ABS 8		●	●	●	●	
(1) 2001-(C) 2012	Zafira	Chassis	ABS-5. 3/5. 4 (+TC)		●	●	●	●	
(1) 2001-(3) 2010	Zafira	Chassis	Electronic Power Steering		●	●	●	●	
(1) 2001	Zafira	Body	Airbag		●	●			
(2) 2002-(C) 2012	Zafira	Body	Airbag		●	●			
(1) 2001	Zafira	Body	Anti Theft Warning		●	●	●		
(2) 2002-(8) 2008	Zafira	Body	Anti Theft Warning		●	●	●		
(1) 2001	Zafira	Body	Central Door Lock		●	●	●		
(2) 2002-(8) 2008	Zafira	Body	Central Door Lock		●	●	●		
(9) 2009-(C) 2012	Zafira	Body	Comfort Module	●	●	●	●	●	F31 F55
(4) 2004-(7) 2007	Zafira	Body	Electronic Climate Control		●	●	●		
(1) 2001-(C) 2012	Zafira	Body	Immobiliser	●	●	●	●	●	F57
(1) 2001-(3) 2003	Zafira	Body	Instrument		●	●	●	●	F40 F66
(4) 2004-(8) 2008	Zafira	Body	Instrument		●	●	●	●	F40 F66
(9) 2009-(C) 2012	Zafira	Body	Instrument		●	●	●	●	F40 F66
(1) 2001-(7) 2007	Zafira	Infotainment	Multi Info Display		●	●	●		
(8) 2008-(C) 2012	Zafira	Infotainment	Multi Info Display		●	●	●		
(1) 2001-(C) 2012	Zafira	Infotainment	Triple Info Display		●	●	●		

Special_Functions

Index	Special Function Name	Index	Special Function Name
F1	Adjust Idle Speed	F2	Throttle Body Relearn
F3	Bleed Clutch Hydraulic	F4	Program Customer Settings
F5	Blower Operating Time Reset	F6	Program ECU Init Coding
F7	Brake Pedal Position Sensor	F8	Program Fuel Type
F9	Brake Pressure Sensor Calibration	F10	Program High Speed CAN-Bus Config.
F11	CKP Variation Learn	F12	Program Idle Speed
F13	Calibrate HVAC Doors	F14	Program Remote Key
F15	Calibrate Steering Angle Sensor	F16	Program Variant Coding
F17	Calibration	F18	Program Variant Configuration
F19	Calibration Verification	F20	Program Vehicle Identification No.
F21	Clutch Pedal Position Learn	F22	Reset O2 BLM
F23	Clutch Replacement	F24	Reset Body Control Module
F25	Configure New Control Module	F26	Reset Engine Oil Life
F27	Crankshaft Pos. System Var. Reset	F28	Reset IAC BLM
F29	Depressurize System	F30	Reset IAC Block Learn Map
F31	Erase Remote Keys	F32	Reset Idle Adjust
F33	Fast Learn Adapt Process	F34	Reset Knockmap
F35	Fuel Composition Reset	F36	Reset Learned Values
F37	Fuel Pump Trim Reset	F38	Reset O2-Loop Block Learn Map
F39	Fuel Trim Reset	F40	Reset Service Interval
F41	H02S Heater Learn	F42	Reset TAP Cells
F43	Idle Learn	F44	Reset TC Signal Status
F45	Idle Speed Adjustment	F46	Sensor Replacement
F47	Learn Clutch Pedal Position	F48	Solenoid Valve Replacement
F49	Oil Life Reset	F50	Inspection/Maintenance Data
F51	Inspection/Maintenance Sys Status	F52	Brake Pedal Position Sensor Learn
F53	Display Immobiliser Status	F54	Air Conditioning Configuration
F55	Reset ECU	F56	SIM Card Data
F57	Erase Transponder-Keys	F58	Clear Deployment Record
F59	Pump Replacement	F60	Erase All Key Fobs
F61	Remove/Reset Module	F62	Read CAN Configuration
F63	Learn Gearbox Parameters	F64	Program VIN
F65	Seat Occupied Detection	F66	Service Interval Setting
F67	Adjust Spark Advance	F68	Read Variant Configuration
F69	Service Cleaning Procedure	F70	Brake Bleed
F71	Erase and Re-Program All Remotes	F72	TPM Learn Mode
F73	Tyre Type/Pressure Selection	F74	Display Type
F75	Read Adjustments	F76	EGR Adjustment
F77	Max. Fuel Quantity Offset	F78	Start Fuel Quantity Offset
F79	Security Information	F80	EGR Pulse Ratio Test