

MaxiSys_Lancia_V4.22 Function List (Note:For reference only)

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
DEDRA	96 1.8 16V 115 CV	Engine - Gearbox	Hitachi MPI Injection	●	●	●	●	●	○
DEDRA	96 1.8 16V 130 CV	Engine - Gearbox	Hitachi MPI Injection	●	●	●	●	●	○
DELTA (111)	96 1.8 16V 115 CV	Engine - Gearbox	Hitachi MPI Injection	●	●	●	●	●	○
DELTA (111)	96 1.8 16V 130 CV	Engine - Gearbox	Hitachi MPI Injection	●	●	●	●	●	○
DELTA (111)	96 1.6 16V	Engine - Gearbox	Magneti Marelli IAW 1AF/1AB Injection	●	●	●	●	●	○
Y	1.4	Engine - Gearbox	Bosch Monomotronic MA1.7.3 Injection	●	●	●	●	●	○
DEDRA	94 1.6 I.E	Safety	ICIT/TRW VAS95 alarm	●	●	●	●	●	○
DEDRA	94 SW INTEGRALE	Safety	ICIT/TRW VAS95 alarm	●	●	●	●	●	○
DEDRA	96 1.8 16V 115 CV	Safety	ICIT/TRW VAS95 alarm	●	●	●	●	●	○
DEDRA	96 1.8 16V 130 CV	Safety	ICIT/TRW VAS95 alarm	●	●	●	●	●	○
DEDRA	98 1.6 16V	Safety	ICIT/TRW VAS95 alarm	●	●	●	●	●	○
DEDRA	FAP Replacement	Safety	ICIT/TRW VAS95 alarm	●	●	●	●	●	○
DELTA (111)	96 1.6 16V	Safety	ICIT/TRW VAS95 alarm	●	●	●	●	●	○
DELTA (111)	96 1.8 16V 115 CV	Safety	ICIT/TRW VAS95 alarm	●	●	●	●	●	○
DELTA (111)	96 1.8 16V 130 CV	Safety	ICIT/TRW VAS95 alarm	●	●	●	●	●	○
DELTA (111)	96 2.0 TURBO 16V	Safety	ICIT/TRW VAS95 alarm	●	●	●	●	●	○
DELTA (111)	96 TD	Safety	ICIT/TRW VAS95 alarm	●	●	●	●	●	○
DELTA (111)	98 1.6 16V	Safety	ICIT/TRW VAS95 alarm	●	●	●	●	●	○
DELTA (111)	98 1.8 16V	Safety	ICIT/TRW VAS95 alarm	●	●	●	●	●	○
Y	Manual System Configuration	Safety	ICIT/TRW VAS95 alarm	●	●	●	●	●	○
Y	1.2	Safety	ICIT/TRW VAS95 alarm	●	●	●	●	●	○
Y	1.2 16V	Safety	ICIT/TRW VAS95 alarm	●	●	●	●	●	○
Y	1.2 16V CF3	Safety	ICIT/TRW VAS95 alarm	●	●	●	●	●	○
Y	1.2 CF3	Safety	ICIT/TRW VAS95 alarm	●	●	●	●	●	○
Y	1.4	Safety	ICIT/TRW VAS95 alarm	●	●	●	●	●	○
DEDRA	96 1.8 16V 115 CV	Safety	Bosch 5.3 ABS	●	●	●	●	●	○
DEDRA	96 1.8 16V 130 CV	Safety	Bosch 5.3 ABS	●	●	●	●	●	○
DEDRA	98 1.6 16V	Safety	Bosch 5.3 ABS	●	●	●	●	●	○
DELTA (111)	96 1.6 16V	Safety	Bosch 5.3 ABS	●	●	●	●	●	○
DELTA (111)	96 1.8 16V 115 CV	Safety	Bosch 5.3 ABS	●	●	●	●	●	○
DELTA (111)	96 1.8 16V 130 CV	Safety	Bosch 5.3 ABS	●	●	●	●	●	○
DELTA (111)	96 2.0 TURBO 16V	Safety	Bosch 5.3 ABS	●	●	●	●	●	○
DELTA (111)	96 TD	Safety	Bosch 5.3 ABS	●	●	●	●	●	○
DELTA (111)	98 1.6 16V	Safety	Bosch 5.3 ABS	●	●	●	●	●	○
DELTA (111)	98 1.8 16V	Safety	Bosch 5.3 ABS	●	●	●	●	●	○
K	2.0	Safety	Bosch 5.3 ABS	●	●	●	●	●	○
K	2.0 TURBO	Safety	Bosch 5.3 ABS	●	●	●	●	●	○
K	2.4	Safety	Bosch 5.3 ABS	●	●	●	●	●	○
K	2.4 TD	Safety	Bosch 5.3 ABS	●	●	●	●	●	○

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
K	3.0	Safety	Bosch 5.3 ABS	●	●	●	●	●	○
K	98 2.4 JTD	Safety	Bosch 5.3 ABS	●	●	●	●	●	○
K	99 2.0	Safety	Bosch 5.3 ABS	●	●	●	●	●	○
K	99 2.4	Safety	Bosch 5.3 ABS	●	●	●	●	●	○
K	99 3.0	Safety	Bosch 5.3 ABS	●	●	●	●	●	○
LYBRA	1.6	Safety	Bosch 5.3 ABS	●	●	●	●	●	○
LYBRA	1.8	Safety	Bosch 5.3 ABS	●	●	●	●	●	○
LYBRA	1.9 JTD	Safety	Bosch 5.3 ABS	●	●	●	●	●	○
LYBRA	2.0	Safety	Bosch 5.3 ABS	●	●	●	●	●	○
LYBRA	2.4 JTD	Safety	Bosch 5.3 ABS	●	●	●	●	●	○
Y	1.1	Safety	Bosch 5.3 ABS	●	●	●	●	●	○
Y	1.2	Safety	Bosch 5.3 ABS	●	●	●	●	●	○
Y	1.2 16V	Safety	Bosch 5.3 ABS	●	●	●	●	●	○
Y	1.2 16V CF3	Safety	Bosch 5.3 ABS	●	●	●	●	●	○
Y	1.2 CF3	Safety	Bosch 5.3 ABS	●	●	●	●	●	○
Y	1.4	Safety	Bosch 5.3 ABS	●	●	●	●	●	○
Y	1.1	Engine - Gearbox	Magneti Marelli IAW 16F Injection	●	●	●	●	●	○
Y	1.2	Engine - Gearbox	Magneti Marelli IAW 16F Injection	●	●	●	●	●	○
DEDRA	94 1.8 I.E	Engine - Gearbox	Magneti Marelli IAW 18F Injection	●	○	○	●	●	○
DELTA (111)	93 1.8 I.E.	Engine - Gearbox	Magneti Marelli IAW 18F Injection	●	○	○	●	●	○
K	2.0 TURBO	Engine - Gearbox	Bosch Motronic M2.7 Injection (El. key)	●	●	●	●	●	○
DEDRA	1.8 I.E ECO	Engine - Gearbox	Magneti Marelli IAW 08F Injection	●	○	○	●	●	○
DEDRA	94 1.8 I.E	Engine - Gearbox	Magneti Marelli IAW 08F Injection	●	○	○	●	●	○
DELTA (111)	93 1.8 I.E.	Engine - Gearbox	Magneti Marelli IAW 08F Injection	●	○	○	●	●	○
DELTA (111)	93 1.6 I.E.	Engine - Gearbox	Bosch Monomotronic MA 1.7 Injection (El.	●	●	●	●	●	○
DEDRA	1.6 I.E ECO	Engine - Gearbox	Bosch Monomotronic MA1.7 Injection	●	●	●	●	●	○
DELTA (111)	93 1.6 I.E.	Engine - Gearbox	Bosch Monomotronic MA1.7 Injection	●	●	●	●	●	○
Y10	92 4WD	Engine - Gearbox	Bosch Monomotronic MA1.7 Injection	●	●	●	●	●	○
Y10	92 FIRE	Engine - Gearbox	Bosch Monomotronic MA1.7 Injection	●	●	●	●	●	○
Y10	92 SELECTRONIC	Engine - Gearbox	Bosch Monomotronic MA1.7 Injection	●	●	●	●	●	○
Z	TURBO	Engine - Gearbox	Bosch Motronic MP 3.2 Injection	●	●	●	●	●	○
DEDRA	1.6 I.E ECO	Safety	ICIT VAS 93 anti-theft device	●	●	●	●	●	○
DEDRA	1.8 I.E ECO	Safety	ICIT VAS 93 anti-theft device	●	●	●	●	●	○
DEDRA	2.0 I.E ECO	Safety	ICIT VAS 93 anti-theft device	●	●	●	●	●	○
DEDRA	2.0 TURBO I.E ECO	Safety	ICIT VAS 93 anti-theft device	●	●	●	●	●	○
DEDRA	94 1.6 I.E	Safety	ICIT VAS 93 anti-theft device	●	●	●	●	●	○
DEDRA	94 1.8 I.E	Safety	ICIT VAS 93 anti-theft device	●	●	●	●	●	○
DEDRA	94 2.0 16V	Safety	ICIT VAS 93 anti-theft device	●	●	●	●	●	○
DEDRA	94 SW INTEGRALE	Safety	ICIT VAS 93 anti-theft device	●	●	●	●	●	○
DEDRA	96 1.8 16V 115 CV	Safety	ICIT VAS 93 anti-theft device	●	●	●	●	●	○
DEDRA	96 1.8 16V 130 CV	Safety	ICIT VAS 93 anti-theft device	●	●	●	●	●	○
DEDRA	98 1.6 16V	Safety	ICIT VAS 93 anti-theft device	●	●	●	●	●	○
DEDRA	INTEGRALE ECO	Safety	ICIT VAS 93 anti-theft device	●	●	●	●	●	○
DEDRA	TURBO DS ECO	Safety	ICIT VAS 93 anti-theft device	●	●	●	●	●	○
DELTA (111)	93 1.6 I.E.	Safety	ICIT VAS 93 anti-theft device	●	●	●	●	●	○
DELTA (111)	93 1.8 I.E.	Safety	ICIT VAS 93 anti-theft device	●	●	●	●	●	○
DELTA (111)	93 2.0 16V	Safety	ICIT VAS 93 anti-theft device	●	●	●	●	●	○
DELTA (111)	93 2.0 TURBO	Safety	ICIT VAS 93 anti-theft device	●	●	●	●	●	○

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
DELTA (111)	93 TD	Safety	ICIT VAS 93 anti-theft device	●	●	●	●	●	○
DELTA (111)	96 1.6 16V	Safety	ICIT VAS 93 anti-theft device	●	●	●	●	●	○
DELTA (111)	96 1.8 16V 115 CV	Safety	ICIT VAS 93 anti-theft device	●	●	●	●	●	○
DELTA (111)	96 1.8 16V 130 CV	Safety	ICIT VAS 93 anti-theft device	●	●	●	●	●	○
DELTA (111)	96 2.0 TURBO 16V	Safety	ICIT VAS 93 anti-theft device	●	●	●	●	●	○
DELTA (111)	96 TD	Safety	ICIT VAS 93 anti-theft device	●	●	●	●	●	○
DELTA (111)	98 1.6 16V	Safety	ICIT VAS 93 anti-theft device	●	●	●	●	●	○
K	2.0 TURBO	Engine - Gearbox	Bosch Motronic M2.10.4 Injection (2.0 20v T eng.)	●	●	●	●	●	○
THEMA	92 16V I.E	Engine - Gearbox	Bosch Motronic M1.7 Injection (2.0 16v	●	●	●	●	●	○
K	2.0	Engine - Gearbox	Bosch Motronic M2.10.3 Injection (2.0 and 2.4 20v eng.)	●	●	●	●	●	○
K	2.4	Engine - Gearbox	Bosch Motronic M2.10.3 Injection (2.0 and 2.4 20v eng.)	●	●	●	●	●	○
K	2.4 TD	Engine - Gearbox	Bosch MSA 11 Diesel Injection (2.4 eng. El. key)	●	●	●	●	●	○
K	3.0	Engine - Gearbox	Bosch Motronic M3.7.1 Injection (3.0 12/24v eng. El. key)	●	●	●	●	●	○
THEMA	92 3.0 V6	Engine - Gearbox	Bosch Motronic M1.7 injection (V6 3.0 eng.)	●	●	●	●	●	○
Y	1.2 16V	Engine - Gearbox	Magneti Marelli IAW 18 FD injection	●	○	○	●	●	○
Z	97 TURBO	Engine - Gearbox	Bosch Motronic MP3.2 injection (9600 Baud)	●	●	●	●	●	○
THEMA	92 16V TURBO	Engine - Gearbox	Bosch Motronic M2.7 injection	●	●	●	●	●	○
K	98 2.4 JTD	Engine - Gearbox	Bosch EDC15 Diesel Injection (2.4 TD d.i.	●	●	●	●	●	○
LYBRA	2.4 JTD	Engine - Gearbox	Bosch EDC15 Diesel Injection (2.4 TD d.i.	●	●	●	●	●	○
LYBRA	1.6	Safety	Allied MY97 Airbag (2F-2P-I-S)	●	●	●	●	○	○
LYBRA	1.8	Safety	Allied MY97 Airbag (2F-2P-I-S)	●	●	●	●	○	○
LYBRA	1.9 JTD	Safety	Allied MY97 Airbag (2F-2P-I-S)	●	●	●	●	○	○
LYBRA	2.0	Safety	Allied MY97 Airbag (2F-2P-I-S)	●	●	●	●	○	○
LYBRA	2.4 JTD	Safety	Allied MY97 Airbag (2F-2P-I-S)	●	●	●	●	○	○
LYBRA	1.9 JTD	Engine - Gearbox	Bosch Diesel EDC15 injection (1.9 TD d.i. engine)	●	●	●	●	●	○
DEDRA	98 1.6 16V	Engine - Gearbox	Magneti Marelli IAW 49F injection (1.6	●	●	●	●	●	○
DELTA (111)	98 1.6 16V	Engine - Gearbox	Magneti Marelli IAW 49F injection (1.6	●	●	●	●	●	○
LYBRA	1.6	Engine - Gearbox	Magneti Marelli IAW 49F injection (1.6	●	●	●	●	●	○
K	3.0	Engine - Gearbox	ZF 4HP18 K Automatic Transmission	●	●	●	●	●	○
K	2.0	Safety	TRW MY 97 Air Bag (2F-2P)	●	●	●	●	○	○
K	2.0 TURBO	Safety	TRW MY 97 Air Bag (2F-2P)	●	●	●	●	○	○
K	2.4	Safety	TRW MY 97 Air Bag (2F-2P)	●	●	●	●	○	○
K	2.4 TD	Safety	TRW MY 97 Air Bag (2F-2P)	●	●	●	●	○	○
K	3.0	Safety	TRW MY 97 Air Bag (2F-2P)	●	●	●	●	○	○
K	98 2.4 JTD	Safety	TRW MY 97 Air Bag (2F-2P)	●	●	●	●	○	○
K	99 2.0	Safety	TRW MY 97 Air Bag (2F-2P)	●	●	●	●	○	○
K	99 2.4	Safety	TRW MY 97 Air Bag (2F-2P)	●	●	●	●	○	○
K	99 3.0	Safety	TRW MY 97 Air Bag (2F-2P)	●	●	●	●	○	○
K	2.0	Safety	TRW MY 97 Air Bag (2F-2P-S)	●	●	●	●	○	○
K	2.0 TURBO	Safety	TRW MY 97 Air Bag (2F-2P-S)	●	●	●	●	○	○
K	2.4	Safety	TRW MY 97 Air Bag (2F-2P-S)	●	●	●	●	○	○
K	2.4 TD	Safety	TRW MY 97 Air Bag (2F-2P-S)	●	●	●	●	○	○

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
K	3.0	Safety	TRW MY 97 Air Bag (2F-2P-S)	●	●	●	●	○	○
K	98 2.4 JTD	Safety	TRW MY 97 Air Bag (2F-2P-S)	●	●	●	●	○	○
K	99 2.0	Safety	TRW MY 97 Air Bag (2F-2P-S)	●	●	●	●	○	○
K	99 2.4	Safety	TRW MY 97 Air Bag (2F-2P-S)	●	●	●	●	○	○
K	99 3.0	Safety	TRW MY 97 Air Bag (2F-2P-S)	●	●	●	●	○	○
K	2.0	Safety	TRW MY 97 Air Bag (2F-2P-2L-S)	●	●	●	●	○	○
K	2.0 TURBO	Safety	TRW MY 97 Air Bag (2F-2P-2L-S)	●	●	●	●	○	○
K	2.4	Safety	TRW MY 97 Air Bag (2F-2P-2L-S)	●	●	●	●	○	○
K	2.4 TD	Safety	TRW MY 97 Air Bag (2F-2P-2L-S)	●	●	●	●	○	○
K	3.0	Safety	TRW MY 97 Air Bag (2F-2P-2L-S)	●	●	●	●	○	○
K	98 2.4 JTD	Safety	TRW MY 97 Air Bag (2F-2P-2L-S)	●	●	●	●	○	○
K	99 2.0	Safety	TRW MY 97 Air Bag (2F-2P-2L-S)	●	●	●	●	○	○
K	99 2.4	Safety	TRW MY 97 Air Bag (2F-2P-2L-S)	●	●	●	●	○	○
K	99 3.0	Safety	TRW MY 97 Air Bag (2F-2P-2L-S)	●	●	●	●	○	○
Y	1.1	Safety	Allied MY 97 Airbag (2F-2P)	●	●	●	●	○	○
Y	1.2	Safety	Allied MY 97 Airbag (2F-2P)	●	●	●	●	○	○
Y	1.2 16V	Safety	Allied MY 97 Airbag (2F-2P)	●	●	●	●	○	○
Y	1.2 16V CF3	Safety	Allied MY 97 Airbag (2F-2P)	●	●	●	●	○	○
Y	1.2 CF3	Safety	Allied MY 97 Airbag (2F-2P)	●	●	●	●	○	○
Y	1.4	Safety	Allied MY 97 Airbag (2F-2P)	●	●	●	●	○	○
Y	1.1	Safety	Allied MY 97 Air Bag (2F-2P-S)	●	●	●	●	○	○
Y	1.2	Safety	Allied MY 97 Air Bag (2F-2P-S)	●	●	●	●	○	○
Y	1.2 16V	Safety	Allied MY 97 Air Bag (2F-2P-S)	●	●	●	●	○	○
Y	1.2 16V CF3	Safety	Allied MY 97 Air Bag (2F-2P-S)	●	●	●	●	○	○
Y	1.2 CF3	Safety	Allied MY 97 Air Bag (2F-2P-S)	●	●	●	●	○	○
LYBRA	1.6	Safety	Allied MY 97 Air Bag (2F-2P-2L-I-S)	●	●	●	●	○	○
LYBRA	1.8	Safety	Allied MY 97 Air Bag (2F-2P-2L-I-S)	●	●	●	●	○	○
LYBRA	1.9 JTD	Safety	Allied MY 97 Air Bag (2F-2P-2L-I-S)	●	●	●	●	○	○
LYBRA	2.0	Safety	Allied MY 97 Air Bag (2F-2P-2L-I-S)	●	●	●	●	○	○
LYBRA	2.4 JTD	Safety	Allied MY 97 Air Bag (2F-2P-2L-I-S)	●	●	●	●	○	○
Y	1.1	Safety	Allied MY 97 Air Bag (2F-2P-2L-S)	●	●	●	●	○	○
Y	1.2	Safety	Allied MY 97 Air Bag (2F-2P-2L-S)	●	●	●	●	○	○
Y	1.2 16V	Safety	Allied MY 97 Air Bag (2F-2P-2L-S)	●	●	●	●	○	○
Y	1.2 16V CF3	Safety	Allied MY 97 Air Bag (2F-2P-2L-S)	●	●	●	●	○	○
Y	1.2 CF3	Safety	Allied MY 97 Air Bag (2F-2P-2L-S)	●	●	●	●	○	○
DELTA (111)	98 1.8 16V	Engine - Gearbox	Hitachi MPI injection (eng. 1.8 16V '98)	●	●	●	●	●	○
LYBRA	1.8	Engine - Gearbox	Hitachi MPI injection (eng. 1.8 16V '98)	●	●	●	●	●	○
K	99 3.0	Engine - Gearbox	Bosch Motronic ME2.1 injection (eng. V6 2.5 / 3.0)	●	●	●	●	●	○
LYBRA	2.0	Safety	Bosch 5.3 ASR ABS	●	●	●	●	●	○
LYBRA	2.4 JTD	Safety	Bosch 5.3 ASR ABS	●	●	●	●	●	○
Z	98 2.0 16V	Engine - Gearbox	Bosch Motronic MP7.3 injection	●	●	●	●	●	○
K	99 2.0	Engine - Gearbox	Bosch Motronic ME3.1 injection (eng. 2.0	●	●	●	●	●	○
K	99 2.4	Engine - Gearbox	Bosch Motronic ME3.1 injection (eng. 2.0	●	●	●	●	●	○
K	99 3.0	Engine - Gearbox	ZF 4HP20 Automatic Transmission	●	●	●	●	●	○
LYBRA	2.0	Engine - Gearbox	ATISIN TYP-SYSTEM Automatic Transmission	●	●	●	●	●	○
Z	00 2.0 JTD	Engine - Gearbox	Bosch EDC15 PSA Diesel Injection (2.0 8v v60 eng.)	●	●	●	●	○	○

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
K	99 2.0	Safety	TRW MY 97 airbag (2F-2P-2L)	●	●	●	●	○	○
K	99 2.4	Safety	TRW MY 97 airbag (2F-2P-2L)	●	●	●	●	○	○
K	99 3.0	Safety	TRW MY 97 airbag (2F-2P-2L)	●	●	●	●	○	○
LYBRA	2.0	Engine - Gearbox	Bosch Motronic ME3.1 injection (C.M./C.A./Cruise)	●	●	●	●	●	○
Z	00 2.0 16V	Engine - Gearbox	Magneti Marelli MM4.8P PSA injection	●	●	●	●	●	○
LYBRA	1.6	Safety	Allied MY 97 Airbag (2F-2P-I)	●	●	●	●	○	○
LYBRA	1.8	Safety	Allied MY 97 Airbag (2F-2P-I)	●	●	●	●	○	○
LYBRA	1.9 JTD	Safety	Allied MY 97 Airbag (2F-2P-I)	●	●	●	●	○	○
LYBRA	2.0	Safety	Allied MY 97 Airbag (2F-2P-I)	●	●	●	●	○	○
LYBRA	2.4 JTD	Safety	Allied MY 97 Airbag (2F-2P-I)	●	●	●	●	○	○
Y	1.1	Safety	Allied MY 97 Airbag (2F-2P-I)	●	●	●	●	○	○
Y	1.2	Safety	Allied MY 97 Airbag (2F-2P-I)	●	●	●	●	○	○
Y	1.2 16V	Safety	Allied MY 97 Airbag (2F-2P-I)	●	●	●	●	○	○
Y	1.2 16V CF3	Safety	Allied MY 97 Airbag (2F-2P-I)	●	●	●	●	○	○
Y	1.2 CF3	Safety	Allied MY 97 Airbag (2F-2P-I)	●	●	●	●	○	○
Y	1.4	Safety	Allied MY 97 Airbag (2F-2P-I)	●	●	●	●	○	○
LYBRA	1.6	Safety	Allied MY 97 Airbag (2F-2P-2L-I)	●	●	●	●	○	○
LYBRA	1.8	Safety	Allied MY 97 Airbag (2F-2P-2L-I)	●	●	●	●	○	○
LYBRA	1.9 JTD	Safety	Allied MY 97 Airbag (2F-2P-2L-I)	●	●	●	●	○	○
LYBRA	2.0	Safety	Allied MY 97 Airbag (2F-2P-2L-I)	●	●	●	●	○	○
LYBRA	2.4 JTD	Safety	Allied MY 97 Airbag (2F-2P-2L-I)	●	●	●	●	○	○
Y	1.1	Safety	Allied MY 97 Airbag (2F-2P-2L-I)	●	●	●	●	○	○
Y	1.2	Safety	Allied MY 97 Airbag (2F-2P-2L-I)	●	●	●	●	○	○
Y	1.2 16V	Safety	Allied MY 97 Airbag (2F-2P-2L-I)	●	●	●	●	○	○
Y	1.2 16V CF3	Safety	Allied MY 97 Airbag (2F-2P-2L-I)	●	●	●	●	○	○
Y	1.2 CF3	Safety	Allied MY 97 Airbag (2F-2P-2L-I)	●	●	●	●	○	○
Y	1.4	Safety	Allied MY 97 Airbag (2F-2P-2L-I)	●	●	●	●	○	○
Z	00 2.0 16V	Safety	Autoliv ACU airbag	●	●	●	●	○	○
Z	00 2.0 JTD	Safety	Autoliv ACU airbag	●	●	●	●	○	○
LYBRA	1.6	Safety	Allied Airbag MY 97 (2F-2P-2L-2T-I)	●	●	●	●	○	○
LYBRA	1.8	Safety	Allied Airbag MY 97 (2F-2P-2L-2T-I)	●	●	●	●	○	○
LYBRA	1.9 JTD	Safety	Allied Airbag MY 97 (2F-2P-2L-2T-I)	●	●	●	●	○	○
LYBRA	2.0	Safety	Allied Airbag MY 97 (2F-2P-2L-2T-I)	●	●	●	●	○	○
LYBRA	2.4 JTD	Safety	Allied Airbag MY 97 (2F-2P-2L-2T-I)	●	●	●	●	○	○
Z	00 2.0 16V	Engine - Gearbox	Siemens AL4 TA2000 PSA Automatic gearbox	●	●	●	●	○	○
YPSILON	1.2 16V	Safety	Autoliv MY 99 airbag (2F-2P-I)	●	●	●	●	●	○
YPSILON	1.2 8V	Safety	Autoliv MY 99 airbag (2F-2P-I)	●	●	●	●	●	○
YPSILON	1.3 JTD	Safety	Autoliv MY 99 airbag (2F-2P-I)	●	●	●	●	●	○
YPSILON	1.4 16V	Safety	Autoliv MY 99 airbag (2F-2P-I)	●	●	●	●	●	○
THESIS	2.0 20V TB	Safety	TRW MY 99 Airbag (2F-4P-4L-2T-I-S-C)	●	●	●	●	●	○
THESIS	2.4 20V	Safety	TRW MY 99 Airbag (2F-4P-4L-2T-I-S-C)	●	●	●	●	●	○
THESIS	2.4 JTD 10V	Safety	TRW MY 99 Airbag (2F-4P-4L-2T-I-S-C)	●	●	●	●	●	○
THESIS	2.4 JTD 20V	Safety	TRW MY 99 Airbag (2F-4P-4L-2T-I-S-C)	●	●	●	●	●	○
THESIS	3.0 V6 24V	Safety	TRW MY 99 Airbag (2F-4P-4L-2T-I-S-C)	●	●	●	●	●	○
THESIS	3.2 V6 24V	Safety	TRW MY 99 Airbag (2F-4P-4L-2T-I-S-C)	●	●	●	●	●	○
PHEDRA	2.0 16V	Engine - Gearbox	Siemens AL4 TA2000 V PSA Automatic Gearbox	●	●	●	●	○	0134
PHEDRA	2.0 JTD 16V	Engine - Gearbox	Siemens AL4 TA2000 V PSA Automatic Gearbox	●	●	●	●	○	0134

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
PHEdra (180)	2.0 JTD 16V	Engine - Gearbox	Siemens AL4 TA2000 V PSA Automatic Gearbox	●	●	●	●	○	0134
YPSILON	1.2 16V	Safety	Autoliv Airbag MY 99 (2F-2P-4L-2T-1G-I)	●	●	●	●	●	○
YPSILON	1.2 8V	Safety	Autoliv Airbag MY 99 (2F-2P-4L-2T-1G-I)	●	●	●	●	●	○
YPSILON	1.3 JTD	Safety	Autoliv Airbag MY 99 (2F-2P-4L-2T-1G-I)	●	●	●	●	●	○
YPSILON	1.4 16V	Safety	Autoliv Airbag MY 99 (2F-2P-4L-2T-1G-I)	●	●	●	●	●	○
LYBRA	1.6	Safety	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	●	●	●	●	●	○
LYBRA	1.8	Safety	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	●	●	●	●	●	○
LYBRA	1.9 JTD	Safety	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	●	●	●	●	●	○
LYBRA	2.0	Safety	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	●	●	●	●	●	○
LYBRA	2.4 JTD	Safety	SIEMENS MY 99 Airbag (2F-2P-2L-2T-I)	●	●	●	●	●	○
THESIS	3.0 V6 24V	Safety	TRW MY 99 Airbag (2F-4P-I-S-C)	●	●	●	●	●	○
YPSILON	1.2 16V	Safety	Autoliv Airbag MY 99 (2F-2P-2L-2T-I)	●	●	●	●	●	○
YPSILON	1.2 8V	Safety	Autoliv Airbag MY 99 (2F-2P-2L-2T-I)	●	●	●	●	●	○
YPSILON	1.3 JTD	Safety	Autoliv Airbag MY 99 (2F-2P-2L-2T-I)	●	●	●	●	●	○
YPSILON	1.4 16V	Safety	Autoliv Airbag MY 99 (2F-2P-2L-2T-I)	●	●	●	●	●	○
YPSILON	1.2 16V	Safety	Autoliv Airbag MY 99 (2F-2P-2L-2T-1G-I)	●	●	●	●	●	○
YPSILON	1.2 8V	Safety	Autoliv Airbag MY 99 (2F-2P-2L-2T-1G-I)	●	●	●	●	●	○
YPSILON	1.3 JTD	Safety	Autoliv Airbag MY 99 (2F-2P-2L-2T-1G-I)	●	●	●	●	●	○
YPSILON	1.4 16V	Safety	Autoliv Airbag MY 99 (2F-2P-2L-2T-1G-I)	●	●	●	●	●	○
YPSILON	1.2 16V	Safety	Autoliv Airbag MY 99 (2F-2P-2T-I)	●	●	●	●	●	○
YPSILON	1.2 8V	Safety	Autoliv Airbag MY 99 (2F-2P-2T-I)	●	●	●	●	●	○
YPSILON	1.3 JTD	Safety	Autoliv Airbag MY 99 (2F-2P-2T-I)	●	●	●	●	●	○
YPSILON	1.4 16V	Safety	Autoliv Airbag MY 99 (2F-2P-2T-I)	●	●	●	●	●	○
THESIS	2.0 20V TB	Safety	TRW MY 99 Airbag (2F-4P-2L-2T-I-S-C)	●	●	●	●	●	○
THESIS	2.4 20V	Safety	TRW MY 99 Airbag (2F-4P-2L-2T-I-S-C)	●	●	●	●	●	○
THESIS	2.4 JTD 10V	Safety	TRW MY 99 Airbag (2F-4P-2L-2T-I-S-C)	●	●	●	●	●	○
THESIS	2.4 JTD 20V	Safety	TRW MY 99 Airbag (2F-4P-2L-2T-I-S-C)	●	●	●	●	●	○
THESIS	3.0 V6 24V	Safety	TRW MY 99 Airbag (2F-4P-2L-2T-I-S-C)	●	●	●	●	●	○
THESIS	3.2 V6 24V	Safety	TRW MY 99 Airbag (2F-4P-2L-2T-I-S-C)	●	●	●	●	●	○
YPSILON	1.2 16V	Safety	Autoliv Airbag 99(A) (2F-2P-2L-I)	●	●	●	●	●	○
YPSILON	1.2 8V	Safety	Autoliv Airbag 99(A) (2F-2P-2L-I)	●	●	●	●	●	○
YPSILON	1.3 JTD	Safety	Autoliv Airbag 99(A) (2F-2P-2L-I)	●	●	●	●	●	○
YPSILON	1.4 16V	Safety	Autoliv Airbag 99(A) (2F-2P-2L-I)	●	●	●	●	●	○
THESIS	2.0 20V TB	Engine - Gearbox	Bosch Motronic Me7.3.1 EOBD injection (2 lambda sensors)	●	●	●	●	●	○
THESIS	3.2 V6 24V	Engine - Gearbox	Bosch Motronic Me7.3.1 EOBD injection	●	●	●	●	●	○
LYBRA	1.8	Engine - Gearbox	Hitachi EOBD injection	●	●	●	●	●	○
LYBRA	1.6	Engine - Gearbox	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD injection	●	●	●	●	●	
Y	1.2 CF3	Engine - Gearbox	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD injection	●	●	●	●	●	
YPSILON	06 1.2 8V	Engine - Gearbox	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD injection	●	●	●	●	●	
YPSILON	1.2 8V	Engine - Gearbox	Magneti Marelli IAW 4AF/4EF/59F/5AF EOBD injection	●	●	●	●	●	
LYBRA	2.0	Engine - Gearbox	Bosch Motronic Me3.1 EOBD injection (eng. 2.0/2.4 20V)	●	●	●	●	●	○

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
THESIS	2.4 20V	Engine - Gearbox	Bosch Motronic Me3.1 EOBD injection (eng. 2.0/2.4 20V)	●	●	●	●	●	○
THESIS	3.0 V6 24V	Engine - Gearbox	Bosch Motronic EOBD ME3.1 Injection (eng. 2.0/2.4 20V)	●	●	●	●	●	○
Y	1.2 16V CF3	Engine - Gearbox	Bosch Motronic ME7.3H4 EOBD injection	●	●	●	●	●	○
LYBRA	1.6	Other systems	Bosch discharge headlamp (left)	●	●	●	●	●	○
LYBRA	1.8	Other systems	Bosch discharge headlamp (left)	●	●	●	●	●	○
LYBRA	1.9 JTD	Other systems	Bosch discharge headlamp (left)	●	●	●	●	●	○
LYBRA	2.0	Other systems	Bosch discharge headlamp (left)	●	●	●	●	●	○
LYBRA	2.4 JTD	Other systems	Bosch discharge headlamp (left)	●	●	●	●	●	○
LYBRA	1.6	Other systems	Bosch discharge headlamp (right)	●	●	●	●	○	○
LYBRA	1.8	Other systems	Bosch discharge headlamp (right)	●	●	●	●	○	○
LYBRA	1.9 JTD	Other systems	Bosch discharge headlamp (right)	●	●	●	●	○	○
LYBRA	2.0	Other systems	Bosch discharge headlamp (right)	●	●	●	●	○	○
LYBRA	2.4 JTD	Other systems	Bosch discharge headlamp (right)	●	●	●	●	○	○
THESIS	2.0 20V TB	Comfort	Bitron driving seat	●	●	●	●	●	○
THESIS	2.4 20V	Comfort	Bitron driving seat	●	●	●	●	●	○
THESIS	2.4 JTD 10V	Comfort	Bitron driving seat	●	●	●	●	●	○
THESIS	2.4 JTD 20V	Comfort	Bitron driving seat	●	●	●	●	●	○
THESIS	3.0 V6 24V	Comfort	Bitron driving seat	●	●	●	●	●	○
THESIS	3.2 V6 24V	Comfort	Bitron driving seat	●	●	●	●	●	○
THESIS	2.0 20V TB	Comfort	Bitron passenger seat	●	●	●	●	●	○
THESIS	2.4 20V	Comfort	Bitron passenger seat	●	●	●	●	●	○
THESIS	2.4 JTD 10V	Comfort	Bitron passenger seat	●	●	●	●	●	○
THESIS	2.4 JTD 20V	Comfort	Bitron passenger seat	●	●	●	●	●	○
THESIS	3.0 V6 24V	Comfort	Bitron passenger seat	●	●	●	●	●	○
THESIS	3.2 V6 24V	Comfort	Bitron passenger seat	●	●	●	●	●	○
LYBRA	1.9 JTD	Engine - Gearbox	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	●	●	●	●	●	○
LYBRA	2.4 JTD	Engine - Gearbox	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	●	●	●	●	●	○
THESIS	2.4 JTD 10V	Engine - Gearbox	Bosch EDC15 CF3/EOBD Diesel Injection (eng. 1.9/2.4)	●	●	●	●	●	○
Z	00 2.0 JTD	Engine - Gearbox	Bosch EDC15 PSA Diesel Injection (eng. 2.0)	●	●	●	●	●	○
LYBRA	1.6	Safety	ESP TRW Lucas ABS	●	●	●	●	●	○
LYBRA	1.8	Safety	ESP TRW Lucas ABS	●	●	●	●	●	○
LYBRA	1.9 JTD	Safety	ESP TRW Lucas ABS	●	●	●	●	●	○
LYBRA	2.0	Safety	ESP TRW Lucas ABS	●	●	●	●	●	○
LYBRA	2.4 JTD	Safety	ESP TRW Lucas ABS	●	●	●	●	●	○
THESIS	2.0 20V TB	Safety	ESP TRW Lucas ABS	●	●	●	●	●	○
THESIS	2.4 20V	Safety	ESP TRW Lucas ABS	●	●	●	●	●	○
THESIS	2.4 JTD 10V	Safety	ESP TRW Lucas ABS	●	●	●	●	●	○
THESIS	2.4 JTD 20V	Safety	ESP TRW Lucas ABS	●	●	●	●	●	○
THESIS	3.0 V6 24V	Safety	ESP TRW Lucas ABS	●	●	●	●	●	○
THESIS	3.2 V6 24V	Safety	ESP TRW Lucas ABS	●	●	●	●	●	○
YPSILON	06 1.2 8V	Safety	ESP TRW Lucas ABS	●	●	●	●	●	○
YPSILON	06 1.3 JTD	Safety	ESP TRW Lucas ABS	●	●	●	●	●	○
YPSILON	06 1.4 16V	Safety	ESP TRW Lucas ABS	●	●	●	●	●	○
YPSILON	06 1.4 8V	Safety	ESP TRW Lucas ABS	●	●	●	●	●	○

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
YPSILON	1.2 16V	Safety	ESP TRW Lucas ABS	●	●	●	●	●	○
YPSILON	1.2 8V	Safety	ESP TRW Lucas ABS	●	●	●	●	●	○
YPSILON	1.3 JTD	Safety	ESP TRW Lucas ABS	●	●	●	●	●	○
YPSILON	1.4 16V	Safety	ESP TRW Lucas ABS	●	●	●	●	●	○
THESIS	2.0 20V TB	Other systems	Marelli Boot	●	●	●	●	●	○
THESIS	2.4 20V	Other systems	Marelli Boot	●	●	●	●	●	○
THESIS	2.4 JTD 10V	Other systems	Marelli Boot	●	●	●	●	●	○
THESIS	2.4 JTD 20V	Other systems	Marelli Boot	●	●	●	●	●	○
THESIS	3.0 V6 24V	Other systems	Marelli Boot	●	●	●	●	●	○
THESIS	3.2 V6 24V	Other systems	Marelli Boot	●	●	●	●	●	○
THESIS	2.0 20V TB	Other systems	Marelli Passenger Door	●	●	●	●	●	○
THESIS	2.4 20V	Other systems	Marelli Passenger Door	●	●	●	●	●	○
THESIS	2.4 JTD 10V	Other systems	Marelli Passenger Door	●	●	●	●	●	○
THESIS	2.4 JTD 20V	Other systems	Marelli Passenger Door	●	●	●	●	●	○
THESIS	3.0 V6 24V	Other systems	Marelli Passenger Door	●	●	●	●	●	○
THESIS	3.2 V6 24V	Other systems	Marelli Passenger Door	●	●	●	●	●	○
THESIS	2.0 20V TB	Other systems	Marelli Driver's Door	●	●	●	●	●	○
THESIS	2.4 20V	Other systems	Marelli Driver's Door	●	●	●	●	●	○
THESIS	2.4 JTD 10V	Other systems	Marelli Driver's Door	●	●	●	●	●	○
THESIS	2.4 JTD 20V	Other systems	Marelli Driver's Door	●	●	●	●	●	○
THESIS	3.0 V6 24V	Other systems	Marelli Driver's Door	●	●	●	●	●	○
THESIS	3.2 V6 24V	Other systems	Marelli Driver's Door	●	●	●	●	●	○
THESIS	2.0 20V TB	Instrumentation	Nippon Seiki instrument panel (Thesis)	●	●	●	●	●	○
THESIS	2.4 20V	Instrumentation	Nippon Seiki instrument panel (Thesis)	●	●	●	●	●	○
THESIS	2.4 JTD 10V	Instrumentation	Nippon Seiki instrument panel (Thesis)	●	●	●	●	●	○
THESIS	2.4 JTD 20V	Instrumentation	Nippon Seiki instrument panel (Thesis)	●	●	●	●	●	○
THESIS	3.0 V6 24V	Instrumentation	Nippon Seiki instrument panel (Thesis)	●	●	●	●	●	○
THESIS	3.2 V6 24V	Instrumentation	Nippon Seiki instrument panel (Thesis)	●	●	●	●	●	○
THESIS	2.0 20V TB	Other systems	Hella discharge headlamps	●	●	●	●	●	○
THESIS	2.4 20V	Other systems	Hella discharge headlamps	●	●	●	●	●	○
THESIS	2.4 JTD 10V	Other systems	Hella discharge headlamps	●	●	●	●	●	○
THESIS	2.4 JTD 20V	Other systems	Hella discharge headlamps	●	●	●	●	●	○
THESIS	3.0 V6 24V	Other systems	Hella discharge headlamps	●	●	●	●	●	○
THESIS	3.2 V6 24V	Other systems	Hella discharge headlamps	●	●	●	●	●	○
THESIS	2.0 20V TB	Safety	Lucas parking brake	●	●	●	●	●	○
THESIS	2.4 20V	Safety	Lucas parking brake	●	●	●	●	●	○
THESIS	2.4 JTD 10V	Safety	Lucas parking brake	●	●	●	●	●	○
THESIS	2.4 JTD 20V	Safety	Lucas parking brake	●	●	●	●	●	○
THESIS	3.0 V6 24V	Safety	Lucas parking brake	●	●	●	●	●	○
THESIS	3.2 V6 24V	Safety	Lucas parking brake	●	●	●	●	●	○
LYBRA	1.6	Engine - Gearbox	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	●	●	●	●	●	
YPSILON	06 1.2 8V	Engine - Gearbox	Injection - Magneti Marelli IAW 4AF/4EF/59F/5AF Outside EEC	●	●	●	●	●	
THESIS	3.2 V6 24V	Engine - Gearbox	Injection - Bosch Motronic Me7.3.1 Outside	●	●	●	●	●	○
LYBRA	2.0	Engine - Gearbox	Injection - Bosch Motronic Me3.1 eng. 2.0/2.4 20v) Outside EEC	●	●	●	●	●	○
PHEDRA	2.0 16V	Comfort	Clarion CD Changer	●	●	●	●	●	○

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
PHEDRA	2.0 JTD 16V	Comfort	Clarion CD Changer	●	●	●	●	●	○
PHEDRA	2.2 JTD 16V	Comfort	Clarion CD Changer	●	●	●	●	●	○
PHEDRA	3.0 V6 24V	Comfort	Clarion CD Changer	●	●	●	●	●	○
THESIS	2.4 20V	Engine - Gearbox	AISIN YLII 5 Automatic Gearbox	●	●	●	●	●	○
THESIS	2.4 JTD 20V	Engine - Gearbox	AISIN YLII 5 Automatic Gearbox	●	●	●	●	●	○
THESIS	3.0 V6 24V	Engine - Gearbox	AISIN YLII 5 Automatic Gearbox	●	●	●	●	●	○
THESIS	3.2 V6 24V	Engine - Gearbox	AISIN YLII 5 Automatic Gearbox	●	●	●	●	●	○
PHEDRA	2.0 16V	Instrumentation	Sagem multi-function screen	●	●	●	●	●	○
PHEDRA	2.0 JTD 16V	Instrumentation	Sagem multi-function screen	●	●	●	●	●	○
PHEDRA	2.2 JTD 16V	Instrumentation	Sagem multi-function screen	●	●	●	●	●	○
PHEDRA	3.0 V6 24V	Instrumentation	Sagem multi-function screen	●	●	●	●	●	○
PHEDRA	2.0 16V	Safety	Sagem Body Computer	●	●	●	●	●	○
PHEDRA	2.0 JTD 16V	Safety	Sagem Body Computer	●	●	●	●	●	○
PHEDRA	2.2 JTD 16V	Safety	Sagem Body Computer	●	●	●	●	●	○
PHEDRA	3.0 V6 24V	Safety	Sagem Body Computer	●	●	●	●	●	○
THESIS	2.0 20V TB	Comfort	Bosch Adaptive Cruise Control	●	●	●	●	●	○
THESIS	2.4 20V	Comfort	Bosch Adaptive Cruise Control	●	●	●	●	●	○
THESIS	2.4 JTD 10V	Comfort	Bosch Adaptive Cruise Control	●	●	●	●	●	○
THESIS	2.4 JTD 20V	Comfort	Bosch Adaptive Cruise Control	●	●	●	●	●	○
THESIS	3.0 V6 24V	Comfort	Bosch Adaptive Cruise Control	●	●	●	●	●	○
THESIS	3.2 V6 24V	Comfort	Bosch Adaptive Cruise Control	●	●	●	●	●	○
PHEDRA	2.0 16V	Instrumentation	Marelli PSA instrument panel	●	●	●	●	●	○
PHEDRA	2.0 JTD 16V	Instrumentation	Marelli PSA instrument panel	●	●	●	●	●	○
PHEDRA	2.2 JTD 16V	Instrumentation	Marelli PSA instrument panel	●	●	●	●	●	○
PHEDRA	3.0 V6 24V	Instrumentation	Marelli PSA instrument panel	●	●	●	●	●	○
PHEDRA	2.0 16V	Comfort	Clarion/Philips sound system	●	●	●	●	●	○
PHEDRA	2.0 JTD 16V	Comfort	Clarion/Philips sound system	●	●	●	●	●	○
PHEDRA	2.2 JTD 16V	Comfort	Clarion/Philips sound system	●	●	●	●	●	○
PHEDRA	3.0 V6 24V	Comfort	Clarion/Philips sound system	●	●	●	●	●	○
PHEDRA	2.0 16V	Other systems	Valeo PSA discharge headlamp (RH)	●	●	●	●	●	○
PHEDRA	2.0 JTD 16V	Other systems	Valeo PSA discharge headlamp (RH)	●	●	●	●	●	○
PHEDRA	2.2 JTD 16V	Other systems	Valeo PSA discharge headlamp (RH)	●	●	●	●	●	○
PHEDRA	3.0 V6 24V	Other systems	Valeo PSA discharge headlamp (RH)	●	●	●	●	●	○
PHEDRA (180)	2.0 JTD 16V	Other systems	Valeo PSA discharge headlamp (RH)	●	●	●	●	●	○
PHEDRA (180)	2.2 JTD 16V	Other systems	Valeo PSA discharge headlamp (RH)	●	●	●	●	●	○
THESIS	3.0 V6 24V	Safety	TRW Tyre Pressure check	●	●	●	●	●	
THESIS	3.2 V6 24V	Safety	TRW Tyre Pressure check	●	●	●	●	●	
YPSILON	1.2 16V	Other systems	BITRON driver's door	●	●	●	●	●	○
YPSILON	1.2 8V	Other systems	BITRON driver's door	●	●	●	●	●	○
YPSILON	1.3 JTD	Other systems	BITRON driver's door	●	●	●	●	●	○
YPSILON	1.4 16V	Other systems	BITRON driver's door	●	●	●	●	●	○
THESIS	2.0 20V TB	Safety	Marelli Full Body computer	●	●	●	●	●	○
THESIS	2.4 20V	Safety	Marelli Full Body computer	●	●	●	●	●	○
THESIS	2.4 JTD 10V	Safety	Marelli Full Body computer	●	●	●	●	●	○
THESIS	2.4 JTD 20V	Safety	Marelli Full Body computer	●	●	●	●	●	○
THESIS	3.0 V6 24V	Safety	Marelli Full Body computer	●	●	●	●	●	○
THESIS	3.2 V6 24V	Safety	Marelli Full Body computer	●	●	●	●	●	○
THESIS	2.0 20V TB	Safety	Marelli Easy-go Body computer	●	●	●	●	●	○

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
THESIS	2.4 20V	Safety	Marelli Easy-go Body computer	●	●	●	●	●	○
THESIS	2.4 JTD 10V	Safety	Marelli Easy-go Body computer	●	●	●	●	●	○
THESIS	2.4 JTD 20V	Safety	Marelli Easy-go Body computer	●	●	●	●	●	○
THESIS	3.0 V6 24V	Safety	Marelli Easy-go Body computer	●	●	●	●	●	○
THESIS	3.2 V6 24V	Safety	Marelli Easy-go Body computer	●	●	●	●	●	○
THESIS	2.0 20V TB	Safety	SAGEM SpeedPro power steering	●	●	●	●	○	○
THESIS	2.4 20V	Safety	SAGEM SpeedPro power steering	●	●	●	●	○	○
THESIS	2.4 JTD 10V	Safety	SAGEM SpeedPro power steering	●	●	●	●	○	○
THESIS	2.4 JTD 20V	Safety	SAGEM SpeedPro power steering	●	●	●	●	○	○
THESIS	3.0 V6 24V	Safety	SAGEM SpeedPro power steering	●	●	●	●	○	○
THESIS	3.2 V6 24V	Safety	SAGEM SpeedPro power steering	●	●	●	●	○	○
THESIS	2.0 20V TB	Instrumentation	Siemens Connect	●	●	●	●	●	○
THESIS	2.4 20V	Instrumentation	Siemens Connect	●	●	●	●	●	○
THESIS	2.4 JTD 10V	Instrumentation	Siemens Connect	●	●	●	●	●	○
THESIS	2.4 JTD 20V	Instrumentation	Siemens Connect	●	●	●	●	●	○
THESIS	3.0 V6 24V	Instrumentation	Siemens Connect	●	●	●	●	●	○
THESIS	3.2 V6 24V	Instrumentation	Siemens Connect	●	●	●	●	●	○
PHEDRA	2.0 JTD 16V	Other systems	Marelli diesel additive check	●	●	●	●	●	
PHEDRA	2.2 JTD 16V	Other systems	Marelli diesel additive check	●	●	●	●	●	
PHEDRA	2.0 16V	Safety	Texton alarm 2	●	●	●	○	●	○
PHEDRA	2.0 JTD 16V	Safety	Texton alarm 2	●	●	●	○	●	○
PHEDRA	2.2 JTD 16V	Safety	Texton alarm 2	●	●	●	○	●	○
PHEDRA	3.0 V6 24V	Safety	Texton alarm 2	●	●	●	○	●	○
THESIS	2.0 20V TB	Safety	DELPHI FL Passive Entry	●	●	●	●	●	○
THESIS	2.4 20V	Safety	DELPHI FL Passive Entry	●	●	●	●	●	○
THESIS	2.4 JTD 10V	Safety	DELPHI FL Passive Entry	●	●	●	●	●	○
THESIS	2.4 JTD 20V	Safety	DELPHI FL Passive Entry	●	●	●	●	●	○
THESIS	3.0 V6 24V	Safety	DELPHI FL Passive Entry	●	●	●	●	●	○
THESIS	3.2 V6 24V	Safety	DELPHI FL Passive Entry	●	●	●	●	●	○
YPSILON	1.2 16V	Safety	DELPHI MF Passive Entry	●	●	●	●	●	○
YPSILON	1.2 8V	Safety	DELPHI MF Passive Entry	●	●	●	●	●	○
YPSILON	1.3 JTD	Safety	DELPHI MF Passive Entry	●	●	●	●	●	○
YPSILON	1.4 16V	Safety	DELPHI MF Passive Entry	●	●	●	●	●	○
YPSILON	1.2 16V	Other systems	BITRON passenger door	●	●	●	●	●	○
YPSILON	1.2 8V	Other systems	BITRON passenger door	●	●	●	●	●	○
YPSILON	1.3 JTD	Other systems	BITRON passenger door	●	●	●	●	●	○
YPSILON	1.4 16V	Other systems	BITRON passenger door	●	●	●	●	●	○
MUSA	1.3 JTD	Comfort	Valeo Parking control unit	●	●	●	●	○	○
MUSA	1.4 16V	Comfort	Valeo Parking control unit	●	●	●	●	○	○
MUSA	1.4 8V	Comfort	Valeo Parking control unit	●	●	●	●	○	○
MUSA	1.6 MJET 16V	Comfort	Valeo Parking control unit	●	●	●	●	○	○
MUSA	1.9 JTD	Comfort	Valeo Parking control unit	●	●	●	●	○	○
THESIS	2.0 20V TB	Comfort	Valeo Parking control unit	●	●	●	●	○	○
THESIS	2.4 20V	Comfort	Valeo Parking control unit	●	●	●	●	○	○
THESIS	2.4 JTD 10V	Comfort	Valeo Parking control unit	●	●	●	●	○	○
THESIS	2.4 JTD 20V	Comfort	Valeo Parking control unit	●	●	●	●	○	○
THESIS	3.0 V6 24V	Comfort	Valeo Parking control unit	●	●	●	●	○	○
THESIS	3.2 V6 24V	Comfort	Valeo Parking control unit	●	●	●	●	○	○

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
PHEDRA	2.0 16V	Instrumentation	Marelli PSA Connect	●	●	●	●	●	
PHEDRA	2.0 JTD 16V	Instrumentation	Marelli PSA Connect	●	●	●	●	●	
PHEDRA	2.2 JTD 16V	Instrumentation	Marelli PSA Connect	●	●	●	●	●	
PHEDRA	3.0 V6 24V	Instrumentation	Marelli PSA Connect	●	●	●	●	●	
THESIS	2.0 20V TB	Comfort	Sachs CDC Suspension	●	●	●	●	○	○
THESIS	2.4 20V	Comfort	Sachs CDC Suspension	●	●	●	●	○	○
THESIS	2.4 JTD 10V	Comfort	Sachs CDC Suspension	●	●	●	●	○	○
THESIS	2.4 JTD 20V	Comfort	Sachs CDC Suspension	●	●	●	●	○	○
THESIS	3.0 V6 24V	Comfort	Sachs CDC Suspension	●	●	●	●	○	○
THESIS	3.2 V6 24V	Comfort	Sachs CDC Suspension	●	●	●	●	○	○
PHEDRA	2.0 16V	Instrumentation	Marelli odometer w. lamps (BTO)	●	●	●	●	●	○
PHEDRA	2.0 JTD 16V	Instrumentation	Marelli odometer w. lamps (BTO)	●	●	●	●	●	○
PHEDRA	2.2 JTD 16V	Instrumentation	Marelli odometer w. lamps (BTO)	●	●	●	●	●	○
PHEDRA	3.0 V6 24V	Instrumentation	Marelli odometer w. lamps (BTO)	●	●	●	●	●	○
THESIS	2.0 20V TB	Safety	Brake Assistant control unit	●	●	●	●	○	○
THESIS	2.4 20V	Safety	Brake Assistant control unit	●	●	●	●	○	○
THESIS	2.4 JTD 10V	Safety	Brake Assistant control unit	●	●	●	●	○	○
THESIS	2.4 JTD 20V	Safety	Brake Assistant control unit	●	●	●	●	○	○
THESIS	3.0 V6 24V	Safety	Brake Assistant control unit	●	●	●	●	○	○
THESIS	3.2 V6 24V	Safety	Brake Assistant control unit	●	●	●	●	○	○
PHEDRA	2.0 16V	Other systems	Texton sliding doors	●	●	●	●	●	○
PHEDRA	2.0 JTD 16V	Other systems	Texton sliding doors	●	●	●	●	●	○
PHEDRA	2.2 JTD 16V	Other systems	Texton sliding doors	●	●	●	●	●	○
PHEDRA	3.0 V6 24V	Other systems	Texton sliding doors	●	●	●	●	●	○
PHEDRA	2.0 16V	Other systems	Inalfa front sunroof	●	●	●	●	●	○
PHEDRA	2.0 JTD 16V	Other systems	Inalfa front sunroof	●	●	●	●	●	○
PHEDRA	2.2 JTD 16V	Other systems	Inalfa front sunroof	●	●	●	●	●	○
PHEDRA	3.0 V6 24V	Other systems	Inalfa front sunroof	●	●	●	●	●	○
YPSILON	1.2 16V	Safety	TRW steering lock	●	●	●	●	●	○
YPSILON	1.2 8V	Safety	TRW steering lock	●	●	●	●	●	○
YPSILON	1.3 JTD	Safety	TRW steering lock	●	●	●	●	●	○
YPSILON	1.4 16V	Safety	TRW steering lock	●	●	●	●	●	○
THESIS	2.0 20V TB	Other systems	Marelli roof panel	●	●	●	●	●	○
THESIS	2.4 20V	Other systems	Marelli roof panel	●	●	●	●	●	○
THESIS	2.4 JTD 10V	Other systems	Marelli roof panel	●	●	●	●	●	○
THESIS	2.4 JTD 20V	Other systems	Marelli roof panel	●	●	●	●	●	○
THESIS	3.0 V6 24V	Other systems	Marelli roof panel	●	●	●	●	●	○
THESIS	3.2 V6 24V	Other systems	Marelli roof panel	●	●	●	●	●	○
MUSA	1.4 16V	Engine - Gearbox	Bosch Motronic ME7.3H4M EOBD Injection	●	●	●	●	●	○
YPSILON	06 1.4 16V	Engine - Gearbox	Bosch Motronic ME7.3H4M EOBD Injection	●	●	●	●	●	○
YPSILON	1.2 16V	Engine - Gearbox	Bosch Motronic ME7.3H4M EOBD Injection	●	●	●	●	●	○
YPSILON	1.4 16V	Engine - Gearbox	Bosch Motronic ME7.3H4M EOBD Injection	●	●	●	●	●	○
PHEDRA	2.0 16V	Comfort	Marelli PSA climate control	●	●	●	●	●	○
PHEDRA	2.0 JTD 16V	Comfort	Marelli PSA climate control	●	●	●	●	●	○
PHEDRA	2.2 JTD 16V	Comfort	Marelli PSA climate control	●	●	●	●	●	○
PHEDRA	3.0 V6 24V	Comfort	Marelli PSA climate control	●	●	●	●	●	○
THESIS	2.0 20V TB	Comfort	Borletti/Hella climate control	●	●	●	●	●	○
THESIS	2.4 20V	Comfort	Borletti/Hella climate control	●	●	●	●	●	○

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
THESIS	2.4 JTD 10V	Comfort	Borletti/Hella climate control	●	●	●	●	●	○
THESIS	2.4 JTD 20V	Comfort	Borletti/Hella climate control	●	●	●	●	●	○
THESIS	3.0 V6 24V	Comfort	Borletti/Hella climate control	●	●	●	●	●	○
THESIS	3.2 V6 24V	Comfort	Borletti/Hella climate control	●	●	●	●	●	○
PHEDRA	2.0 16V	Other systems	Eaton multi-switch stalk unit (COM2000)	●	●	○	●	○	○
PHEDRA	2.0 JTD 16V	Other systems	Eaton multi-switch stalk unit (COM2000)	●	●	○	●	○	○
PHEDRA	2.2 JTD 16V	Other systems	Eaton multi-switch stalk unit (COM2000)	●	●	○	●	○	○
PHEDRA	3.0 V6 24V	Other systems	Eaton multi-switch stalk unit (COM2000)	●	●	○	●	○	○
PHEDRA	2.0 16V	Comfort	Valeo PSA Parking Control unit	●	●	●	●	●	○
PHEDRA	2.0 JTD 16V	Comfort	Valeo PSA Parking Control unit	●	●	●	●	●	○
PHEDRA	2.2 JTD 16V	Comfort	Valeo PSA Parking Control unit	●	●	●	●	●	○
PHEDRA	3.0 V6 24V	Comfort	Valeo PSA Parking Control unit	●	●	●	●	●	○
PHEDRA	2.0 16V	Instrumentation	Marelli DAV PSA Connect control	●	●	○	●	○	○
PHEDRA	2.0 JTD 16V	Instrumentation	Marelli DAV PSA Connect control	●	●	○	●	○	○
PHEDRA	2.2 JTD 16V	Instrumentation	Marelli DAV PSA Connect control	●	●	○	●	○	○
PHEDRA	3.0 V6 24V	Instrumentation	Marelli DAV PSA Connect control	●	●	○	●	○	○
PHEDRA	2.0 16V	Comfort	Bitron PSA driver's seat	●	●	●	●	●	○
PHEDRA	2.0 JTD 16V	Comfort	Bitron PSA driver's seat	●	●	●	●	●	○
PHEDRA	2.2 JTD 16V	Comfort	Bitron PSA driver's seat	●	●	●	●	●	○
PHEDRA	3.0 V6 24V	Comfort	Bitron PSA driver's seat	●	●	●	●	●	○
PHEDRA	2.0 16V	Other systems	Inalfa central sunroof	●	●	●	●	●	○
PHEDRA	2.0 JTD 16V	Other systems	Inalfa central sunroof	●	●	●	●	●	○
PHEDRA	2.2 JTD 16V	Other systems	Inalfa central sunroof	●	●	●	●	●	○
PHEDRA	3.0 V6 24V	Other systems	Inalfa central sunroof	●	●	●	●	●	○
PHEDRA	2.0 16V	Other systems	Inalfa rear sunroof	●	●	●	●	●	○
PHEDRA	2.0 JTD 16V	Other systems	Inalfa rear sunroof	●	●	●	●	●	○
PHEDRA	2.2 JTD 16V	Other systems	Inalfa rear sunroof	●	●	●	●	●	○
PHEDRA	3.0 V6 24V	Other systems	Inalfa rear sunroof	●	●	●	●	●	○
PHEDRA	2.0 16V	Safety	Temic airbag	●	●	●	●	●	○
PHEDRA	2.0 JTD 16V	Safety	Temic airbag	●	●	●	●	●	○
PHEDRA	2.2 JTD 16V	Safety	Temic airbag	●	●	●	●	●	○
PHEDRA	3.0 V6 24V	Safety	Temic airbag	●	●	●	●	●	○
PHEDRA	2.0 16V	Other systems	Marelli PSA Driver's Door	●	●	○	●	●	○
PHEDRA	2.0 JTD 16V	Other systems	Marelli PSA Driver's Door	●	●	○	●	●	○
PHEDRA	2.2 JTD 16V	Other systems	Marelli PSA Driver's Door	●	●	○	●	●	○
PHEDRA	3.0 V6 24V	Other systems	Marelli PSA Driver's Door	●	●	○	●	●	○
PHEDRA	2.0 16V	Other systems	Marelli PSA Passenger's Door	●	●	○	●	●	○
PHEDRA	2.0 JTD 16V	Other systems	Marelli PSA Passenger's Door	●	●	○	●	●	○
PHEDRA	2.2 JTD 16V	Other systems	Marelli PSA Passenger's Door	●	●	○	●	●	○
PHEDRA	3.0 V6 24V	Other systems	Marelli PSA Passenger's Door	●	●	○	●	●	○
PHEDRA	2.0 16V	Safety	Bosch 5.7 ESP PSA ABS	●	●	●	●	●	
PHEDRA	2.0 JTD 16V	Safety	Bosch 5.7 ESP PSA ABS	●	●	●	●	●	
PHEDRA	2.2 JTD 16V	Safety	Bosch 5.7 ESP PSA ABS	●	●	●	●	●	
PHEDRA	3.0 V6 24V	Safety	Bosch 5.7 ESP PSA ABS	●	●	●	●	●	
PHEDRA	3.0 V6 24V	Engine - Gearbox	Bosch Motronic Me7.4.6 PSA Injection	●	●	●	●	●	○
PHEDRA	3.0 V6 24V	Engine - Gearbox	ZF 4HP20 PSA Automatic Gearbox	●	●	●	●	○	○
PHEDRA	2.0 JTD 16V	Engine - Gearbox	Bosch EDC15 PSA diesel injection (eng. 16v)	●	●	●	●	●	○
PHEDRA	2.2 JTD 16V	Engine - Gearbox	Bosch EDC15 PSA diesel injection (eng. 16v)	●	●	●	●	●	○

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
PHEdra (180)	2.0 JTD 16V	Engine - Gearbox	Bosch EDC15 PSA diesel injection (eng. 16v)	●	●	●	●	●	○
PHEdra (180)	2.2 JTD 16V	Engine - Gearbox	Bosch EDC15 PSA diesel injection (eng. 16v)	●	●	●	●	●	○
Z	00 2.0 JTD	Engine - Gearbox	Bosch EDC15 PSA diesel injection (eng. 16v)	●	●	●	●	●	○
PHEdra	2.0 16V	Engine - Gearbox	Magneti Marelli MM4MP2 PSA Injection	●	●	●	●	●	○
THESIS	2.4 JTD 20V	Engine - Gearbox	Bosch EDC16 CF3/EOBD Diesel Injection (1.9/2.4 eng.)	●	●	●	●	●	○
MUSA	1.3 JTD	Engine - Gearbox	Marelli 6JF EOBD Diesel injection (eng. 1.3 JTD)	●	●	●	●	●	○
YPSILON	1.3 JTD	Engine - Gearbox	Marelli 6JF EOBD Diesel injection (eng. 1.3 JTD)	●	●	●	●	●	○
YPSILON	06 1.2 8V	Instrumentation	Siemens instrument panel	●	●	●	●	●	0070 0064 0066 0065 0034
YPSILON	06 1.3 JTD	Instrumentation	Siemens instrument panel	●	●	●	●	●	0070 0064 0066 0065 0034
YPSILON	06 1.4 16V	Instrumentation	Siemens instrument panel	●	●	●	●	●	0070 0064 0066 0065 0034
YPSILON	06 1.4 8V	Instrumentation	Siemens instrument panel	●	●	●	●	●	0070 0064 0066 0065 0034
YPSILON	1.2 16V	Instrumentation	Siemens instrument panel	●	●	●	●	●	0070 0064 0066 0065 0034
YPSILON	1.2 8V	Instrumentation	Siemens instrument panel	●	●	●	●	●	0070 0064 0066 0065 0034
YPSILON	1.3 JTD	Instrumentation	Siemens instrument panel	●	●	●	●	●	0070 0064 0066 0065 0034
YPSILON	1.4 16V	Instrumentation	Siemens instrument panel	●	●	●	●	●	0070 0064 0066 0065 0034
MUSA	1.3 JTD	Other systems	Single BITRON Driver's Door	●	●	●	●	●	○
MUSA	1.4 16V	Other systems	Single BITRON Driver's Door	●	●	●	●	●	○
MUSA	1.9 JTD	Other systems	Single BITRON Driver's Door	●	●	●	●	●	○
YPSILON	1.2 16V	Other systems	Single BITRON Driver's Door	●	●	●	●	●	○
YPSILON	1.2 8V	Other systems	Single BITRON Driver's Door	●	●	●	●	●	○
YPSILON	1.3 JTD	Other systems	Single BITRON Driver's Door	●	●	●	●	●	○
YPSILON	1.4 16V	Other systems	Single BITRON Driver's Door	●	●	●	●	●	○
YPSILON	06 1.2 8V	Comfort	Bosch Parking Control Unit	●	●	●	●	●	○
YPSILON	06 1.3 JTD	Comfort	Bosch Parking Control Unit	●	●	●	●	●	○
YPSILON	06 1.4 16V	Comfort	Bosch Parking Control Unit	●	●	●	●	●	○
YPSILON	06 1.4 8V	Comfort	Bosch Parking Control Unit	●	●	●	●	●	○
YPSILON	1.2 16V	Comfort	Bosch Parking Control Unit	●	●	●	●	●	○
YPSILON	1.2 8V	Comfort	Bosch Parking Control Unit	●	●	●	●	●	○
YPSILON	1.3 JTD	Comfort	Bosch Parking Control Unit	●	●	●	●	●	○
YPSILON	1.4 16V	Comfort	Bosch Parking Control Unit	●	●	●	●	●	○
MUSA	1.3 JTD	Instrumentation	Marelli instrument panel (Comfort)	●	●	●	●	●	0070 0064 0066 0065 0034
MUSA	1.4 16V	Instrumentation	Marelli instrument panel (Comfort)	●	●	●	●	●	0070 0064 0066 0065 0034
MUSA	1.4 8V	Instrumentation	Marelli instrument panel (Comfort)	●	●	●	●	●	0070 0064 0066 0065 0034
MUSA	1.6 MJET 16V	Instrumentation	Marelli instrument panel (Comfort)	●	●	●	●	●	0070 0064 0066 0065 0034
MUSA	1.9 JTD	Instrumentation	Marelli instrument panel (Comfort)	●	●	●	●	●	0070 0064 0066 0065 0034
YPSILON	06 1.2 8V	Comfort	Denso Climate Control (Two-zone)	●	●	●	●	●	○
YPSILON	06 1.3 JTD	Comfort	Denso Climate Control (Two-zone)	●	●	●	●	●	○
YPSILON	06 1.4 16V	Comfort	Denso Climate Control (Two-zone)	●	●	●	●	●	○
YPSILON	06 1.4 8V	Comfort	Denso Climate Control (Two-zone)	●	●	●	●	●	○
YPSILON	1.2 16V	Comfort	Denso Climate Control (Two-zone)	●	●	●	●	●	○
YPSILON	1.2 8V	Comfort	Denso Climate Control (Two-zone)	●	●	●	●	●	○
YPSILON	1.3 JTD	Comfort	Denso Climate Control (Two-zone)	●	●	●	●	●	○
YPSILON	1.4 16V	Comfort	Denso Climate Control (Two-zone)	●	●	●	●	●	○
MUSA	1.4 16V	Engine - Gearbox	Marelli SELESPEED CFC228F Automatic Gearbox	●	●	●	●	●	○
YPSILON	06 1.4 16V	Engine - Gearbox	Marelli SELESPEED CFC228F Automatic Gearbox	●	●	●	●	●	○

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
YPSILON	1.4 16V	Engine - Gearbox	Marelli SELESPEED CFC228F Automatic Gearbox	●	●	●	●	●	○
YPSILON	06 1.2 8V	Safety	DELPHI Electric Steering	●	●	●	●	○	
YPSILON	06 1.3 JTD	Safety	DELPHI Electric Steering	●	●	●	●	○	
YPSILON	06 1.4 16V	Safety	DELPHI Electric Steering	●	●	●	●	○	
YPSILON	06 1.4 8V	Safety	DELPHI Electric Steering	●	●	●	●	○	
YPSILON	1.2 16V	Safety	DELPHI Electric Steering	●	●	●	●	○	
YPSILON	1.2 8V	Safety	DELPHI Electric Steering	●	●	●	●	○	
YPSILON	1.3 JTD	Safety	DELPHI Electric Steering	●	●	●	●	○	
YPSILON	1.4 16V	Safety	DELPHI Electric Steering	●	●	●	●	○	
MUSA	1.3 JTD	Safety	Bosch 8 ABS	●	●	●	●	●	○
MUSA	1.4 16V	Safety	Bosch 8 ABS	●	●	●	●	●	○
MUSA	1.4 8V	Safety	Bosch 8 ABS	●	●	●	●	●	○
MUSA	1.6 MJET 16V	Safety	Bosch 8 ABS	●	●	●	●	●	○
MUSA	1.9 JTD	Safety	Bosch 8 ABS	●	●	●	●	●	○
MUSA	1.3 JTD	Safety	Bosch 8 VDC ABS	●	●	●	●	●	○
MUSA	1.4 16V	Safety	Bosch 8 VDC ABS	●	●	●	●	●	○
MUSA	1.4 8V	Safety	Bosch 8 VDC ABS	●	●	●	●	●	○
MUSA	1.6 MJET 16V	Safety	Bosch 8 VDC ABS	●	●	●	●	●	○
MUSA	1.9 JTD	Safety	Bosch 8 VDC ABS	●	●	●	●	●	○
YPSILON	1.2 16V	Safety	Marelli/Finmek Body Computer	●	●	●	●	●	○
YPSILON	1.2 8V	Safety	Marelli/Finmek Body Computer	●	●	●	●	●	○
YPSILON	1.3 JTD	Safety	Marelli/Finmek Body Computer	●	●	●	●	●	○
YPSILON	1.4 16V	Safety	Marelli/Finmek Body Computer	●	●	●	●	●	○
MUSA	1.3 JTD	Other systems	G.E. PROCOND Passenger Door	●	●	●	●	●	○
MUSA	1.4 16V	Other systems	G.E. PROCOND Passenger Door	●	●	●	●	●	○
MUSA	1.4 8V	Other systems	G.E. PROCOND Passenger Door	●	●	●	●	●	○
MUSA	1.6 MJET 16V	Other systems	G.E. PROCOND Passenger Door	●	●	●	●	●	○
MUSA	1.9 JTD	Other systems	G.E. PROCOND Passenger Door	●	●	●	●	●	○
YPSILON	1.2 16V	Other systems	G.E. PROCOND Passenger Door	●	●	●	●	●	○
YPSILON	1.2 8V	Other systems	G.E. PROCOND Passenger Door	●	●	●	●	●	○
YPSILON	1.3 JTD	Other systems	G.E. PROCOND Passenger Door	●	●	●	●	●	○
YPSILON	1.4 16V	Other systems	G.E. PROCOND Passenger Door	●	●	●	●	●	○
MUSA	1.3 JTD	Other systems	G.E. PROCOND Driver's Door	●	●	●	●	●	○
MUSA	1.4 16V	Other systems	G.E. PROCOND Driver's Door	●	●	●	●	●	○
MUSA	1.4 8V	Other systems	G.E. PROCOND Driver's Door	●	●	●	●	●	○
MUSA	1.6 MJET 16V	Other systems	G.E. PROCOND Driver's Door	●	●	●	●	●	○
MUSA	1.9 JTD	Other systems	G.E. PROCOND Driver's Door	●	●	●	●	●	○
YPSILON	1.2 16V	Other systems	G.E. PROCOND Driver's Door	●	●	●	●	●	○
YPSILON	1.2 8V	Other systems	G.E. PROCOND Driver's Door	●	●	●	●	●	○
YPSILON	1.3 JTD	Other systems	G.E. PROCOND Driver's Door	●	●	●	●	●	○
YPSILON	1.4 16V	Other systems	G.E. PROCOND Driver's Door	●	●	●	●	●	○
PHEDRA	2.0 16V	Engine - Gearbox	Magneti Marelli MM6LP PSA Injection	●	●	●	●	●	○
MUSA	1.3 JTD	Other systems	G.E. PROCOND boot	●	●	●	●	●	○
MUSA	1.4 16V	Other systems	G.E. PROCOND boot	●	●	●	●	●	○
MUSA	1.4 8V	Other systems	G.E. PROCOND boot	●	●	●	●	●	○
MUSA	1.6 MJET 16V	Other systems	G.E. PROCOND boot	●	●	●	●	●	○
MUSA	1.9 JTD	Other systems	G.E. PROCOND boot	●	●	●	●	●	○
MUSA	1.3 JTD	Safety	TRW 1 Power Steering	●	●	●	●	○	

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MUSA	1.4 16V	Safety	TRW 1 Power Steering	●	●	●	●	○	
MUSA	1.4 8V	Safety	TRW 1 Power Steering	●	●	●	●	○	
MUSA	1.6 MJET 16V	Safety	TRW 1 Power Steering	●	●	●	●	○	
MUSA	1.9 JTD	Safety	TRW 1 Power Steering	●	●	●	●	○	
MUSA	1.3 JTD	Safety	TRW MY 03 Airbag (2F-2P-2L-2T-I)	●	●	●	●	●	○
MUSA	1.4 16V	Safety	TRW MY 03 Airbag (2F-2P-2L-2T-I)	●	●	●	●	●	○
MUSA	1.4 8V	Safety	TRW MY 03 Airbag (2F-2P-2L-2T-I)	●	●	●	●	●	○
MUSA	1.6 MJET 16V	Safety	TRW MY 03 Airbag (2F-2P-2L-2T-I)	●	●	●	●	●	○
MUSA	1.9 JTD	Safety	TRW MY 03 Airbag (2F-2P-2L-2T-I)	●	●	●	●	●	○
MUSA	1.3 JTD	Safety	Marelli Body Computer 1	●	●	●	●	●	○
MUSA	1.4 16V	Safety	Marelli Body Computer 1	●	●	●	●	●	○
MUSA	1.4 8V	Safety	Marelli Body Computer 1	●	●	●	●	●	○
MUSA	1.9 JTD	Safety	Marelli Body Computer 1	●	●	●	●	●	○
MUSA	1.3 JTD	Comfort	Denso Climate Control 1 (Two-zone)	●	●	●	●	●	○
MUSA	1.4 16V	Comfort	Denso Climate Control 1 (Two-zone)	●	●	●	●	●	○
MUSA	1.4 8V	Comfort	Denso Climate Control 1 (Two-zone)	●	●	●	●	●	○
MUSA	1.6 MJET 16V	Comfort	Denso Climate Control 1 (Two-zone)	●	●	●	●	●	○
MUSA	1.9 JTD	Comfort	Denso Climate Control 1 (Two-zone)	●	●	●	●	●	○
MUSA	1.3 JTD	Safety	TRW MY 03 Airbag (2F-2P-2T-I)	●	●	●	●	●	○
MUSA	1.4 16V	Safety	TRW MY 03 Airbag (2F-2P-2T-I)	●	●	●	●	●	○
MUSA	1.4 8V	Safety	TRW MY 03 Airbag (2F-2P-2T-I)	●	●	●	●	●	○
MUSA	1.6 MJET 16V	Safety	TRW MY 03 Airbag (2F-2P-2T-I)	●	●	●	●	●	○
MUSA	1.9 JTD	Safety	TRW MY 03 Airbag (2F-2P-2T-I)	●	●	●	●	●	○
MUSA	1.3 JTD	Safety	TRW MY 03 Airbag (2F-2P-I)	●	●	●	●	●	○
MUSA	1.4 16V	Safety	TRW MY 03 Airbag (2F-2P-I)	●	●	●	●	●	○
MUSA	1.4 8V	Safety	TRW MY 03 Airbag (2F-2P-I)	●	●	●	●	●	○
MUSA	1.6 MJET 16V	Safety	TRW MY 03 Airbag (2F-2P-I)	●	●	●	●	●	○
MUSA	1.9 JTD	Safety	TRW MY 03 Airbag (2F-2P-I)	●	●	●	●	●	○
MUSA	1.3 JTD	Instrumentation	Marelli instrument panel (Modal)	●	●	●	●	●	
MUSA	1.4 16V	Instrumentation	Marelli instrument panel (Modal)	●	●	●	●	●	
MUSA	1.4 8V	Instrumentation	Marelli instrument panel (Modal)	●	●	●	●	●	
MUSA	1.6 MJET 16V	Instrumentation	Marelli instrument panel (Modal)	●	●	●	●	●	
MUSA	1.9 JTD	Instrumentation	Marelli instrument panel (Modal)	●	●	●	●	●	
MUSA	1.3 JTD	Other systems	Single Driver's Door G.E. PROCOND	●	●	●	●	●	○
MUSA	1.4 16V	Other systems	Single Driver's Door G.E. PROCOND	●	●	●	●	●	○
MUSA	1.4 8V	Other systems	Single Driver's Door G.E. PROCOND	●	●	●	●	●	○
MUSA	1.6 MJET 16V	Other systems	Single Driver's Door G.E. PROCOND	●	●	●	●	●	○
MUSA	1.9 JTD	Other systems	Single Driver's Door G.E. PROCOND	●	●	●	●	●	○
YPSILON	1.2 16V	Other systems	Single Driver's Door G.E. PROCOND	●	●	●	●	●	○
YPSILON	1.2 8V	Other systems	Single Driver's Door G.E. PROCOND	●	●	●	●	●	○
YPSILON	1.3 JTD	Other systems	Single Driver's Door G.E. PROCOND	●	●	●	●	●	○
YPSILON	1.4 16V	Other systems	Single Driver's Door G.E. PROCOND	●	●	●	●	●	○
LYBRA	1.6	Safety	TRW Lucas ABS	●	●	●	●	●	○
LYBRA	1.8	Safety	TRW Lucas ABS	●	●	●	●	●	○
LYBRA	1.9 JTD	Safety	TRW Lucas ABS	●	●	●	●	●	○
LYBRA	2.0	Safety	TRW Lucas ABS	●	●	●	●	●	○
LYBRA	2.4 JTD	Safety	TRW Lucas ABS	●	●	●	●	●	○
YPSILON	06 1.2 8V	Safety	TRW Lucas ABS	●	●	●	●	●	○

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
YPSILON	06 1.3 JTD	Safety	TRW Lucas ABS	●	●	●	●	●	○
YPSILON	06 1.4 16V	Safety	TRW Lucas ABS	●	●	●	●	●	○
YPSILON	06 1.4 8V	Safety	TRW Lucas ABS	●	●	●	●	●	○
YPSILON	1.2 16V	Safety	TRW Lucas ABS	●	●	●	●	●	○
YPSILON	1.2 8V	Safety	TRW Lucas ABS	●	●	●	●	●	○
YPSILON	1.3 JTD	Safety	TRW Lucas ABS	●	●	●	●	●	○
YPSILON	1.4 16V	Safety	TRW Lucas ABS	●	●	●	●	●	○
MUSA	1.9 JTD	Engine - Gearbox	Bosch EDC16C9 CF3/E0BD Diesel Injection (1.9 eng.)	●	●	●	●	●	
MUSA	1.3 JTD	Engine - Gearbox	Marelli Automatic Gearbox SELESPEED CFC208F	●	●	●	●	●	
YPSILON	06 1.3 JTD	Engine - Gearbox	Marelli Automatic Gearbox SELESPEED CFC208F	●	●	●	●	●	
YPSILON	1.3 JTD	Engine - Gearbox	Marelli Automatic Gearbox SELESPEED CFC208F	●	●	●	●	●	
MUSA	1.3 JTD	Safety	SCHRADER Tyre Pressure Check	●	●	●	●	○	
MUSA	1.4 16V	Safety	SCHRADER Tyre Pressure Check	●	●	●	●	○	
MUSA	1.4 8V	Safety	SCHRADER Tyre Pressure Check	●	●	●	●	○	
MUSA	1.6 MJET 16V	Safety	SCHRADER Tyre Pressure Check	●	●	●	●	○	
MUSA	1.9 JTD	Safety	SCHRADER Tyre Pressure Check	●	●	●	●	○	
MUSA	1.9 JTD	Engine - Gearbox	Bosch EDC16C9 CF4/E0BD Diesel Injection (1.9 eng.)	●	●	●	●	●	
THESIS	2.4 JTD 20V	Engine - Gearbox	Bosch Diesel Injection EDC16C39 CF4/E0BD (eng. 1.9/2.4)	●	●	●	●	●	0043 0014 0063 0054 0053 0037 0002 0020 0052 0047 0046
MUSA	1.3 JTD	Instrumentation	Marelli 3 Connect (multi-model)	●	●	●	●	●	○
MUSA	1.4 16V	Instrumentation	Marelli 3 Connect (multi-model)	●	●	●	●	●	○
MUSA	1.4 8V	Instrumentation	Marelli 3 Connect (multi-model)	●	●	●	●	●	○
MUSA	1.6 MJET 16V	Instrumentation	Marelli 3 Connect (multi-model)	●	●	●	●	●	○
MUSA	1.9 JTD	Instrumentation	Marelli 3 Connect (multi-model)	●	●	●	●	●	○
YPSILON	06 1.2 8V	Instrumentation	Marelli 3 Connect (multi-model)	●	●	●	●	●	○
YPSILON	06 1.3 JTD	Instrumentation	Marelli 3 Connect (multi-model)	●	●	●	●	●	○
YPSILON	06 1.4 16V	Instrumentation	Marelli 3 Connect (multi-model)	●	●	●	●	●	○
YPSILON	06 1.4 8V	Instrumentation	Marelli 3 Connect (multi-model)	●	●	●	●	●	○
YPSILON	1.2 16V	Instrumentation	Marelli 3 Connect (multi-model)	●	●	●	●	●	○
YPSILON	1.2 8V	Instrumentation	Marelli 3 Connect (multi-model)	●	●	●	●	●	○
YPSILON	1.3 JTD	Instrumentation	Marelli 3 Connect (multi-model)	●	●	●	●	●	○
YPSILON	1.4 16V	Instrumentation	Marelli 3 Connect (multi-model)	●	●	●	●	●	○
MUSA	1.4 8V	Engine - Gearbox	Magneti Marelli Injection IAW 5SF CF4/E0BD (eng. 1.4 8v)	●	●	●	●	●	
YPSILON	06 1.4 8V	Engine - Gearbox	Magneti Marelli Injection IAW 5SF CF4/E0BD (eng. 1.4 8v)	●	●	●	●	●	
PHEDRA (180)	2.0 JTD 16V	Other systems	Delphi multi-switch (COM2003)	●	●	●	●	●	○
PHEDRA (180)	2.2 JTD 16V	Other systems	Delphi multi-switch (COM2003)	●	●	●	●	●	○
PHEDRA (180)	2.0 JTD 16V	Comfort	PSA Bitron driver's seat (CAN)	●	●	●	●	●	○
PHEDRA (180)	2.2 JTD 16V	Comfort	PSA Bitron driver's seat (CAN)	●	●	●	●	●	○
PHEDRA (180)	2.0 JTD 16V	Safety	Delphi Alarm	●	●	●	●	●	
PHEDRA (180)	2.2 JTD 16V	Safety	Delphi Alarm	●	●	●	●	●	
PHEDRA (180)	2.0 JTD 16V	Comfort	Blaupunkt radio	●	●	●	●	●	○
PHEDRA (180)	2.2 JTD 16V	Comfort	Blaupunkt radio	●	●	●	●	●	○

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MUSA	1.3 JTD	Engine - Gearbox	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	●	●	●	●	●	0043 0014 0063 0050 0054 0053 0037 0002 0020 0052 0047 0046 0072
YPSILON	06 1.3 JTD	Engine - Gearbox	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	●	●	●	●	●	0043 0014 0063 0050 0054 0053 0037 0002 0020 0052 0047 0046 0072
YPSILON	1.3 JTD	Engine - Gearbox	Marelli Diesel Injection 6F3 EOBD (eng. 1.3 JTD)	●	●	●	●	●	0043 0014 0063 0050 0054 0053 0037 0002 0020 0052 0047 0046 0072
DELTA (181)	1.4 TURBO 16V	Safety	Tyre Pressure Control TRW 2	●	●	●	●	●	
DELTA (181)	1.6 MJET 16V	Safety	Tyre Pressure Control TRW 2	●	●	●	●	●	
DELTA (181)	1.8 JTS TB 16V	Safety	Tyre Pressure Control TRW 2	●	●	●	●	●	
DELTA (181)	1.9 MJET 16V	Safety	Tyre Pressure Control TRW 2	●	●	●	●	●	
DELTA (181)	2.0 MJET 16V	Safety	Tyre Pressure Control TRW 2	●	●	●	●	●	
PHEDRA (180)	2.0 JTD 16V	Other systems	Brose passenger door	●	●	●	●	●	○
PHEDRA (180)	2.2 JTD 16V	Other systems	Brose passenger door	●	●	●	●	●	○
DELTA (181)	1.8 JTS TB 16V	Engine - Gearbox	Automatic Gearbox AISIN AF40-6	●	●	●	●	●	○
PHEDRA (180)	2.0 JTD 16V	Comfort	Clarion CD Magazine (CAN)	●	●	●	●	●	
PHEDRA (180)	2.2 JTD 16V	Comfort	Clarion CD Magazine (CAN)	●	●	●	●	●	
PHEDRA (180)	2.0 JTD 16V	Other systems	Brose Driver's Door	●	●	●	●	●	○
PHEDRA (180)	2.2 JTD 16V	Other systems	Brose Driver's Door	●	●	●	●	●	○
PHEDRA (180)	2.0 JTD 16V	Instrumentation	PSA Marelli Connect (CAN)	●	●	●	●	●	○
PHEDRA (180)	2.2 JTD 16V	Instrumentation	PSA Marelli Connect (CAN)	●	●	●	●	●	○
PHEDRA (180)	2.0 JTD 16V	Comfort	Bosch luminosity/rain sensor	●	●	●	●	○	○
PHEDRA (180)	2.2 JTD 16V	Comfort	Bosch luminosity/rain sensor	●	●	●	●	○	○
PHEDRA (180)	2.0 JTD 16V	Safety	Siemens Tyre Pressure Control	●	●	●	●	○	
PHEDRA (180)	2.2 JTD 16V	Safety	Siemens Tyre Pressure Control	●	●	●	●	○	
PHEDRA (180)	2.0 JTD 16V	Safety	BOSCH/TEMIC Airbag (CAN)	●	●	●	●	○	○
PHEDRA (180)	2.2 JTD 16V	Safety	BOSCH/TEMIC Airbag (CAN)	●	●	●	●	○	○
PHEDRA (180)	2.0 JTD 16V	Instrumentation	Johnson / Borg multi-function screen	●	●	●	●	●	
PHEDRA (180)	2.2 JTD 16V	Instrumentation	Johnson / Borg multi-function screen	●	●	●	●	●	
PHEDRA (180)	2.0 JTD 16V	Safety	HPI Power steering	●	●	●	●	●	○
PHEDRA (180)	2.2 JTD 16V	Safety	HPI Power steering	●	●	●	●	●	○
PHEDRA (180)	2.0 JTD 16V	Other systems	Inalfa front sunroof (CAN)	●	●	●	●	●	○
PHEDRA (180)	2.2 JTD 16V	Other systems	Inalfa front sunroof (CAN)	●	●	●	●	●	○
PHEDRA (180)	2.0 JTD 16V	Other systems	Inalfa centre sunroof (CAN)	●	●	●	●	●	○
PHEDRA (180)	2.2 JTD 16V	Other systems	Inalfa centre sunroof (CAN)	●	●	●	●	●	○
PHEDRA (180)	2.0 JTD 16V	Other systems	Inalfa rear sunroof (CAN)	●	●	●	●	●	○
PHEDRA (180)	2.2 JTD 16V	Other systems	Inalfa rear sunroof (CAN)	●	●	●	●	●	○
PHEDRA (180)	2.0 JTD 16V	Instrumentation	PSA Marelli cluster (CAN)	●	●	●	●	●	○
PHEDRA (180)	2.2 JTD 16V	Instrumentation	PSA Marelli cluster (CAN)	●	●	●	●	●	○
PHEDRA (180)	2.0 JTD 16V	Instrumentation	Marelli odometer warning lamps (BTO CAN)	●	●	●	●	●	
PHEDRA (180)	2.2 JTD 16V	Instrumentation	Marelli odometer warning lamps (BTO CAN)	●	●	●	●	●	
PHEDRA (180)	2.0 JTD 16V	Other systems	Texton sliding doors (CAN)	●	●	●	●	●	
PHEDRA (180)	2.2 JTD 16V	Other systems	Texton sliding doors (CAN)	●	●	●	●	●	
DELTA (181)	1.4 TURBO 16V	Instrumentation	Marelli/Microsoft Convergence	●	●	●	●	●	○
DELTA (181)	1.6 MJET 16V	Instrumentation	Marelli/Microsoft Convergence	●	●	●	●	●	○
DELTA (181)	1.8 JTS TB 16V	Instrumentation	Marelli/Microsoft Convergence	●	●	●	●	●	○

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
DELTA (181)	1.9 MJET 16V	Instrumentation	Marelli/Microsoft Convergence	●	●	●	●	●	○
DELTA (181)	2.0 MJET 16V	Instrumentation	Marelli/Microsoft Convergence	●	●	●	●	●	○
MUSA	1.3 JTD	Instrumentation	Marelli/Microsoft Convergence	●	●	●	●	●	○
MUSA	1.4 16V	Instrumentation	Marelli/Microsoft Convergence	●	●	●	●	●	○
MUSA	1.4 8V	Instrumentation	Marelli/Microsoft Convergence	●	●	●	●	●	○
MUSA	1.6 MJET 16V	Instrumentation	Marelli/Microsoft Convergence	●	●	●	●	●	○
MUSA	1.9 JTD	Instrumentation	Marelli/Microsoft Convergence	●	●	●	●	●	○
YPSILON	06 1.2 8V	Instrumentation	Marelli/Microsoft Convergence	●	●	●	●	●	○
YPSILON	06 1.3 JTD	Instrumentation	Marelli/Microsoft Convergence	●	●	●	●	●	○
YPSILON	06 1.4 16V	Instrumentation	Marelli/Microsoft Convergence	●	●	●	●	●	○
YPSILON	06 1.4 8V	Instrumentation	Marelli/Microsoft Convergence	●	●	●	●	●	○
PHEDRA (180)	2.0 JTD 16V	Safety	PSA Bosch ABS 8 ESP (CAN)	●	●	●	●	●	
PHEDRA (180)	2.2 JTD 16V	Safety	PSA Bosch ABS 8 ESP (CAN)	●	●	●	●	●	
PHEDRA (180)	2.0 JTD 16V	Instrumentation	PSA DAV Connect Command (CAN)	●	○	○	●	○	○
PHEDRA (180)	2.2 JTD 16V	Instrumentation	PSA DAV Connect Command (CAN)	●	○	○	●	○	○
MUSA	1.3 JTD	Engine - Gearbox	Marelli Diesel Injection 8DF CF5/EOBD (eng. 1.3 JTD)	●	●	●	●	●	0102 0212 0213 0198 0199
YPSILON	06 1.3 JTD	Engine - Gearbox	Marelli Diesel Injection 8DF CF5/EOBD (eng. 1.3 JTD)	●	●	●	●	●	0102 0212 0213 0198 0199
PHEDRA (180)	2.0 JTD 16V	Comfort	PSA Valeo Parking Control Unit (CAN)	●	●	●	●	●	○
PHEDRA (180)	2.2 JTD 16V	Comfort	PSA Valeo Parking Control Unit (CAN)	●	●	●	●	●	○
PHEDRA (180)	2.0 JTD 16V	Other systems	Marelli Diesel additive control (CAN)	●	●	●	●	●	
PHEDRA (180)	2.2 JTD 16V	Other systems	Marelli Diesel additive control (CAN)	●	●	●	●	●	
PHEDRA (180)	2.0 JTD 16V	Comfort	PSA Denso Climate Control (CAN)	●	●	●	●	●	○
PHEDRA (180)	2.2 JTD 16V	Comfort	PSA Denso Climate Control (CAN)	●	●	●	●	●	○
PHEDRA (180)	2.0 JTD 16V	Safety	Valeo Body Computer (BSI CAN)	●	●	●	●	●	0110
PHEDRA (180)	2.2 JTD 16V	Safety	Valeo Body Computer (BSI CAN)	●	●	●	●	●	0110
DELTA (181)	1.4 TURBO 16V	Safety	TRW 3 Electric Steering	●	●	●	●	○	○
DELTA (181)	1.6 MJET 16V	Safety	TRW 3 Electric Steering	●	●	●	●	○	○
DELTA (181)	1.8 JTS TB 16V	Safety	TRW 3 Electric Steering	●	●	●	●	○	○
DELTA (181)	1.9 MJET 16V	Safety	TRW 3 Electric Steering	●	●	●	●	○	○
DELTA (181)	2.0 MJET 16V	Safety	TRW 3 Electric Steering	●	●	●	●	○	○
MUSA	1.3 JTD	Safety	TRW 3 Electric Steering	●	●	●	●	○	○
MUSA	1.4 16V	Safety	TRW 3 Electric Steering	●	●	●	●	○	○
MUSA	1.4 8V	Safety	TRW 3 Electric Steering	●	●	●	●	○	○
MUSA	1.6 MJET 16V	Safety	TRW 3 Electric Steering	●	●	●	●	○	○
MUSA	1.9 JTD	Safety	TRW 3 Electric Steering	●	●	●	●	○	○
DELTA (181)	1.4 TURBO 16V	Instrumentation	Marelli/Microsoft C3 Convergence	●	●	●	●	●	○
DELTA (181)	1.6 MJET 16V	Instrumentation	Marelli/Microsoft C3 Convergence	●	●	●	●	●	○
DELTA (181)	1.8 JTS TB 16V	Instrumentation	Marelli/Microsoft C3 Convergence	●	●	●	●	●	○
DELTA (181)	1.9 MJET 16V	Instrumentation	Marelli/Microsoft C3 Convergence	●	●	●	●	●	○
DELTA (181)	2.0 MJET 16V	Instrumentation	Marelli/Microsoft C3 Convergence	●	●	●	●	●	○
MUSA	1.4 16V	Engine - Gearbox	Marelli SELESPEED CFC328 Automatic Gearbox	●	●	●	●	●	0164 0172
PHEDRA (180)	2.0 JTD 16V	Engine - Gearbox	Siemens Diesel Injection SID803 CF4/EOBD (eng. 16v)	●	●	●	●	●	
DELTA (181)	1.6 MJET 16V	Engine - Gearbox	Marelli SELESPEED CFC300 Automatic Gearbox	●	●	●	●	●	0164 0172
DELTA (181)	1.4 TURBO 16V	Instrumentation	Marelli instrument panel 3	●	●	●	●	●	0070 0064 0066 0065 0044 0034

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
DELTA (181)	1.6 MJET 16V	Instrumentation	Marelli instrument panel 3	●	●	●	●	●	0070 0064 0066 0065 0044 0034
DELTA (181)	1.8 JTS TB 16V	Instrumentation	Marelli instrument panel 3	●	●	●	●	●	0070 0064 0066 0065 0044 0034
DELTA (181)	1.9 MJET 16V TWINTB	Instrumentation	Marelli instrument panel 3	●	●	●	●	●	0070 0064 0066 0065 0044 0034
DELTA (181)	2.0 MJET 16V	Instrumentation	Marelli instrument panel 3	●	●	●	●	●	0070 0064 0066 0065 0044 0034
MUSA	1.3 JTD	Safety	Marelli 7 Body Computer	●	●	●	●	●	○
MUSA	1.4 16V	Safety	Marelli 7 Body Computer	●	●	●	●	●	○
MUSA	1.4 8V	Safety	Marelli 7 Body Computer	●	●	●	●	●	○
MUSA	1.6 MJET 16V	Safety	Marelli 7 Body Computer	●	●	●	●	●	○
MUSA	1.9 JTD	Safety	Marelli 7 Body Computer	●	●	●	●	●	○
YPSILON	06 1.2 8V	Safety	Marelli 7 Body Computer	●	●	●	●	●	○
YPSILON	06 1.3 JTD	Safety	Marelli 7 Body Computer	●	●	●	●	●	○
YPSILON	06 1.4 16V	Safety	Marelli 7 Body Computer	●	●	●	●	●	○
YPSILON	06 1.4 8V	Safety	Marelli 7 Body Computer	●	●	●	●	●	○
PHEDRA (180)	2.0 JTD 16V	Other systems	Delphi multi-function switch (COM2005)	●	●	●	●	●	○
YPSILON	06 1.2 8V	Safety	Autoliv 1 Airbag (Proxi)	●	●	●	●	●	○
YPSILON	06 1.3 JTD	Safety	Autoliv 1 Airbag (Proxi)	●	●	●	●	●	○
YPSILON	06 1.4 16V	Safety	Autoliv 1 Airbag (Proxi)	●	●	●	●	●	○
YPSILON	06 1.4 8V	Safety	Autoliv 1 Airbag (Proxi)	●	●	●	●	●	○
DELTA (181)	1.4 TURBO 16V	Safety	SIEMENS Airbag 1 (Proxi)	●	●	●	●	●	○
DELTA (181)	1.6 MJET 16V	Safety	SIEMENS Airbag 1 (Proxi)	●	●	●	●	●	○
DELTA (181)	1.8 JTS TB 16V	Safety	SIEMENS Airbag 1 (Proxi)	●	●	●	●	●	○
DELTA (181)	1.9 MJET 16V	Safety	SIEMENS Airbag 1 (Proxi)	●	●	●	●	●	○
DELTA (181)	2.0 MJET 16V	Safety	SIEMENS Airbag 1 (Proxi)	●	●	●	●	●	○
DELTA (181)	1.4 TURBO 16V	Safety	Marelli Body Computer 8	●	●	●	●	●	○
DELTA (181)	1.6 MJET 16V	Safety	Marelli Body Computer 8	●	●	●	●	●	○
DELTA (181)	1.8 JTS TB 16V	Safety	Marelli Body Computer 8	●	●	●	●	●	○
DELTA (181)	1.9 MJET 16V	Safety	Marelli Body Computer 8	●	●	●	●	●	○
DELTA (181)	2.0 MJET 16V	Safety	Marelli Body Computer 8	●	●	●	●	●	○
DELTA (181)	1.4 TURBO 16V	Engine - Gearbox	Bosch Motronic Injection Me7.9.10 CF5/EOBD (eng. 1.4)	●	●	●	●	●	
MUSA	1.4 16V	Engine - Gearbox	Bosch Motronic Injection Me7.9.10 CF5/EOBD (eng. 1.4)	●	●	●	●	●	
DELTA (181)	1.4 TURBO 16V	Comfort	Driver's seat Lear 3	●	●	●	●	●	○
DELTA (181)	1.6 MJET 16V	Comfort	Driver's seat Lear 3	●	●	●	●	●	○
DELTA (181)	1.8 JTS TB 16V	Comfort	Driver's seat Lear 3	●	●	●	●	●	○
DELTA (181)	1.9 MJET 16V	Comfort	Driver's seat Lear 3	●	●	●	●	●	○
DELTA (181)	2.0 MJET 16V	Comfort	Driver's seat Lear 3	●	●	●	●	●	○
DELTA (181)	1.4 TURBO 16V	Comfort	Passenger's seat Lear 3	●	●	●	●	●	○
DELTA (181)	1.6 MJET 16V	Comfort	Passenger's seat Lear 3	●	●	●	●	●	○
DELTA (181)	1.8 JTS TB 16V	Comfort	Passenger's seat Lear 3	●	●	●	●	●	○
DELTA (181)	1.9 MJET 16V	Comfort	Passenger's seat Lear 3	●	●	●	●	●	○
DELTA (181)	2.0 MJET 16V	Comfort	Passenger's seat Lear 3	●	●	●	●	●	○
PHEDRA (180)	2.2 JTD 16V	Engine - Gearbox	Bosch Diesel Injection EDC16CP39 CF4/EOBD (2.2 eng.)	●	●	●	●	●	

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
PHEDRA (180)	2.0 JTD 16V	Safety	Bosch ABS 8.1 ESP PSA (CAN)	●	●	●	●	●	
PHEDRA (180)	2.2 JTD 16V	Safety	Bosch ABS 8.1 ESP PSA (CAN)	●	●	●	●	●	
DELTA (181)	1.6 MJET 16V	Engine - Gearbox	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	●	●	●	●	●	0043 0014 0022 0080 0054 0057 0003 0020 0052 0047 0062 0046 0198 0199
DELTA (181)	1.9 MJET 16V TWINTB	Engine - Gearbox	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	●	●	●	●	●	0043 0014 0022 0080 0054 0057 0003 0020 0052 0047 0062 0046 0198 0199
DELTA (181)	2.0 MJET 16V	Engine - Gearbox	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	●	●	●	●	●	0043 0014 0022 0080 0054 0057 0003 0020 0052 0047 0062 0046 0198 0199
MUSA	1.6 MJET 16V	Engine - Gearbox	Bosch Diesel Injection EDC16C39 CF5/EOBD (1.6/1.9/2.0 eng.)	●	●	●	●	●	0043 0014 0022 0080 0054 0057 0003 0020 0052 0047 0062 0046 0198 0199
PHEDRA (180)	2.2 JTD 16V	Engine - Gearbox	AISIN AM6 Automatic Gearbox	●	●	●	●	●	0179 0041
DELTA (181)	1.4 TURBO 16V	Other systems	Automotive Lighting discharge headlamps	●	●	●	●	●	○
DELTA (181)	1.6 MJET 16V	Other systems	Automotive Lighting discharge headlamps	●	●	●	●	●	○
DELTA (181)	1.8 JTS TB 16V	Other systems	Automotive Lighting discharge headlamps	●	●	●	●	●	○
DELTA (181)	1.9 MJET 16V	Other systems	Automotive Lighting discharge headlamps	●	●	●	●	●	○
DELTA (181)	2.0 MJET 16V	Other systems	Automotive Lighting discharge headlamps	●	●	●	●	●	○
DELTA (181)	1.4 TURBO 16V	Comfort	Valeo 2 Parking control unit	●	●	●	●	○	○
DELTA (181)	1.6 MJET 16V	Comfort	Valeo 2 Parking control unit	●	●	●	●	○	○
DELTA (181)	1.8 JTS TB 16V	Comfort	Valeo 2 Parking control unit	●	●	●	●	○	○
DELTA (181)	1.9 MJET 16V	Comfort	Valeo 2 Parking control unit	●	●	●	●	○	○
DELTA (181)	2.0 MJET 16V	Comfort	Valeo 2 Parking control unit	●	●	●	●	○	○
DELTA (181)	1.4 TURBO 16V	Comfort	Denso 3 climate control (Two-zone)	●	●	●	●	●	○
DELTA (181)	1.6 MJET 16V	Comfort	Denso 3 climate control (Two-zone)	●	●	●	●	●	○
DELTA (181)	1.8 JTS TB 16V	Comfort	Denso 3 climate control (Two-zone)	●	●	●	●	●	○
DELTA (181)	1.9 MJET 16V	Comfort	Denso 3 climate control (Two-zone)	●	●	●	●	●	○
DELTA (181)	2.0 MJET 16V	Comfort	Denso 3 climate control (Two-zone)	●	●	●	●	●	○
DELTA (181)	1.4 TURBO 16V	Safety	TRW Lane Control Control Unit (HALF)	●	●	●	●	●	○
DELTA (181)	1.6 MJET 16V	Safety	TRW Lane Control Control Unit (HALF)	●	●	●	●	●	○
DELTA (181)	1.8 JTS TB 16V	Safety	TRW Lane Control Control Unit (HALF)	●	●	●	●	●	○
DELTA (181)	1.9 MJET 16V	Safety	TRW Lane Control Control Unit (HALF)	●	●	●	●	●	○
DELTA (181)	2.0 MJET 16V	Safety	TRW Lane Control Control Unit (HALF)	●	●	●	●	●	○
DELTA (181)	1.4 TURBO 16V	Safety	TRW ABS ESP	●	●	●	●	●	○
DELTA (181)	1.6 MJET 16V	Safety	TRW ABS ESP	●	●	●	●	●	○
DELTA (181)	1.8 JTS TB 16V	Safety	TRW ABS ESP	●	●	●	●	●	○
DELTA (181)	1.9 MJET 16V	Safety	TRW ABS ESP	●	●	●	●	●	○
DELTA (181)	2.0 MJET 16V	Safety	TRW ABS ESP	●	●	●	●	●	○
PHEDRA (180)	2.0 JTD 16V	Safety	Johnson EV Body Computer (BSI CAN) 2	●	●	●	●	●	0110
PHEDRA (180)	2.2 JTD 16V	Safety	Johnson EV Body Computer (BSI CAN) 2	●	●	●	●	●	0110
DELTA (181)	1.8 JTS TB 16V	Engine - Gearbox	Bosch Injection Motronic MeD17.3.1 CF5/EOBD (eng. 1.8)	●	●	●	●	●	0102 0014
DELTA (181)	1.4 TURBO 16V	Comfort	Marelli Radio Navigator	●	●	●	●	●	○
DELTA (181)	1.6 MJET 16V	Comfort	Marelli Radio Navigator	●	●	●	●	●	○
DELTA (181)	1.8 JTS TB 16V	Comfort	Marelli Radio Navigator	●	●	●	●	●	○
DELTA (181)	1.9 MJET 16V	Comfort	Marelli Radio Navigator	●	●	●	●	●	○

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
DELTA (181)	2.0 MJET 16V	Comfort	Marelli Radio Navigator	●	●	●	●	●	○
DELTA (181)	1.4 TURBO 16V	Comfort	Valeo Semi-automatic Parking Control Unit	●	●	●	●	●	○
DELTA (181)	1.6 MJET 16V	Comfort	Valeo Semi-automatic Parking Control Unit	●	●	●	●	●	○
DELTA (181)	1.8 JTS TB 16V	Comfort	Valeo Semi-automatic Parking Control Unit	●	●	●	●	●	○
DELTA (181)	1.9 MJET 16V	Comfort	Valeo Semi-automatic Parking Control Unit	●	●	●	●	●	○
DELTA (181)	2.0 MJET 16V	Comfort	Valeo Semi-automatic Parking Control Unit	●	●	●	●	●	○
PHEDRA (180)	2.0 JTD 16V	Instrumentation	Marelli Connect PSA RT5 (CAN)	●	●	●	●	●	○
PHEDRA (180)	2.2 JTD 16V	Instrumentation	Marelli Connect PSA RT5 (CAN)	●	●	●	●	●	○
MUSA	1.3 JTD	Engine - Gearbox	Automatic Gearbox Marelli SELESPEED CFC308F	●	●	●	●	●	0164 0172
DELTA (181)	1.4 TURBO 16V	Comfort	Magneti Marelli Suspensions	●	●	●	●	●	○
DELTA (181)	1.6 MJET 16V	Comfort	Magneti Marelli Suspensions	●	●	●	●	●	○
DELTA (181)	1.8 JTS TB 16V	Comfort	Magneti Marelli Suspensions	●	●	●	●	●	○
DELTA (181)	1.9 MJET 16V	Comfort	Magneti Marelli Suspensions	●	●	●	●	●	○
DELTA (181)	2.0 MJET 16V	Comfort	Magneti Marelli Suspensions	●	●	●	●	●	○
DELTA (181)	1.4 TURBO 16V	Engine - Gearbox	Injection Landi Renzo LC02 Gas	●	●	●	●	●	○
MUSA	1.4 8V	Engine - Gearbox	Injection Landi Renzo LC02 Gas	●	●	●	●	●	○
YPSILON	06 1.4 8V	Engine - Gearbox	Injection Landi Renzo LC02 Gas	●	●	●	●	●	○
YPSILON	06 1.2 8V	Engine - Gearbox	Magneti Marelli Injection IAW 5SF8 CF5/EOBD (eng. 8v)	●	●	●	●	●	○
DELTA (181)	1.4 TURBO 16V	Engine - Gearbox	Magneti Marelli Injection IAW 8GMF CF5/EOBD (eng. 1.4)	●	●	●	●	●	0102 0207
DELTA (181)	1.4 TURBO 16V	Safety	Convergence Lauberhorn C1	●	●	●	●	●	○
DELTA (181)	1.6 MJET 16V	Safety	Convergence Lauberhorn C1	●	●	●	●	●	○
DELTA (181)	1.8 JTS TB 16V	Safety	Convergence Lauberhorn C1	●	●	●	●	●	○
DELTA (181)	1.9 MJET 16V	Safety	Convergence Lauberhorn C1	●	●	●	●	●	○
DELTA (181)	2.0 MJET 16V	Safety	Convergence Lauberhorn C1	●	●	●	●	●	○
MUSA	1.3 JTD	Safety	Convergence Lauberhorn C1	●	●	●	●	●	○
MUSA	1.4 16V	Safety	Convergence Lauberhorn C1	●	●	●	●	●	○
MUSA	1.4 8V	Safety	Convergence Lauberhorn C1	●	●	●	●	●	○
MUSA	1.6 MJET 16V	Safety	Convergence Lauberhorn C1	●	●	●	●	●	○
MUSA	1.9 JTD	Safety	Convergence Lauberhorn C1	●	●	●	●	●	○
YPSILON	06 1.2 8V	Safety	Convergence Lauberhorn C1	●	●	●	●	●	○
YPSILON	06 1.3 JTD	Safety	Convergence Lauberhorn C1	●	●	●	●	●	○
YPSILON	06 1.4 16V	Safety	Convergence Lauberhorn C1	●	●	●	●	●	○
YPSILON	06 1.4 8V	Safety	Convergence Lauberhorn C1	●	●	●	●	●	○
Ypsilon	2011		AHM	▲	▲	▲	▲	▲	F0052
Ypsilon	2011		ORC	▲	▲	▲	▲	○	
Ypsilon	2011		CMM	▲	▲	▲	▲	○	
Ypsilon	2011		CTM	▲	▲	▲	▲	▲	F0053 F0054
Ypsilon	2011		EPS	▲	▲	▲	▲	○	F007D
Ypsilon	2011		HVAC	▲	▲	▲	▲	▲	F007C
Ypsilon	2011		ABS	▲	▲	▲	▲	▲	F00A3 F00A4 F0009 F0124
Ypsilon	2011		BCM	▲	▲	▲	▲	▲	F0059 F0057 F0058
Ypsilon	2011		PAM	▲	▲	▲	▲	▲	F0126 F0127 F0050 F0051
Ypsilon	2011		IPC	▲	▲	▲	▲	▲	F0003 F0001 F0004 F0005 F0006

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Ypsilon	2011		ECM	▲	▲	▲	▲	▲	F009F F00A1 F0129 F0071 F002F F0128 F000B F0022 F0011 F0073 F0038 F0072 F001F F0034 F0036 F0067 F001E F006A F0031 F000E F0068 F0069 F0032 F0021 F0025 F002B F0012 F0013 F0014 F0015 F000C F0016 F0024 F000D F0017 F002D F002C F009C F0075 F0033 F0035
Ypsilon	2011		TCM	▲	▲	▲	▲	▲	F0011 F003F F003D F003B F003C F0042 F003A F0039
Flavia	2012		PDM	▲	▲	▲	▲	▲	F015D
Flavia	2012		AMP	▲	▲	▲	▲	○	F0116 F0115
Flavia	2012		PCM	▲	▲	▲	▲	▲	F00D8 F00DD F00D9 F00DE F00DA F00DF F00DB F00FE F00D4 F00E2 F00E6 F00FF F00EC F00EA F00F3 F00E8 F00F4 F00DC F00E0 F00D6 F00ED F00EE F00F9 F00FB F00F7 F00E7 F00E5 F00C4 F00FD F00D5 F00E1 F00D1 F00D2 F00D0 F00D3 F00F8 F00F2 F00FA F00D7 F00F6 F00F0 F00F1 F0100 F0101 F00E3 F00EB F00E9 F00E4 F00EF F00FC F00F5
Flavia	2012		HVAC	▲	▲	▲	▲	▲	F0117 F0118 F0134 F0119 F015E
Flavia	2012		ABS	▲	▲	▲	▲	▲	F00B8 F015F F0160
Flavia	2012		ORC	▲	▲	▲	▲	○	F00B4
Flavia	2012		TIPMCGW	▲	▲	▲	▲	▲	F010A F0109 F0111 F0108 F016E F0168 F0169 F016B F016C F005A F016D F016A F0172 F0163 F016F F0166 F0165 F0170 F0162 F0171 F0114 F0112 F0164 F0161 F0167
Flavia	2012		CCN	▲	▲	▲	▲	▲	F0173 F0113 F0177 F0174 F0176 F0178 F0175
Flavia	2012		HFM	▲	▲	▲	▲	▲	F00BA
Flavia	2012		SAS	▲	▲	▲	▲	○	
Flavia	2012		DDM	▲	▲	▲	▲	▲	F015D
Flavia	2012		RADIO	▲	▲	▲	▲	▲	F017A F0179 F0121 F017B F017D F017C
Flavia	2012		WCM	▲	▲	▲	▲	○	F017E F0182 F017F F0181 F0184

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Flavia	2012		PTCM	▲	▲	▲	▲	○	
Thema	2012		ORC	▲	▲	▲	▲	○	F0185 F00B6
Thema	2012		TGW	▲	▲	▲	▲	○	F0120 F0121 F0123 F0122
Thema	2012		HVAC	▲	▲	▲	▲	▲	F0117 F0118 F011A F0119
Thema	2012		ICS	▲	▲	▲	▲	▲	
Thema	2012		TCM	▲	▲	▲	▲	○	F0186 F0030 F0188
Thema	2012		ESM	▲	▲	▲	▲	▲	
Thema	2012		AFLS	▲	▲	▲	▲	▲	F00AE
Thema	2012		PDM	▲	▲	▲	▲	▲	
Thema	2012		PCM	▲	▲	▲	▲	▲	F00C9 F00C4 F00CD F00C8 F00CF F00CA F00C7 F00CB F00C6 F00CE F00C5 F00CC F00D8 F00DD F0100 F00D9 F00DE F0101 F00DA F00DF F00E3 F00DB F00FE F00D4 F00E2 F00E6 F00FF F00EC F00EA F00EB F00F3 F00E8 F00E9 F00F4 F00DC F00E0 F00E4 F00D6 F00ED F00EE F00EF F00F9 F00FB F00FC F00F7 F00E7 F00E5 F00FD F00D5 F00E1 F00D1 F00D2 F00D0 F00D3 F00F8 F00F2 F00FA F00D7 F00F5 F00F6 F00F0 F00F1
Thema	2012		DDM	▲	▲	▲	▲	▲	
Thema	2012		AMP	▲	▲	▲	▲	○	F0116 F0115
Thema	2012		PTS	▲	▲	▲	▲	▲	F011B F011C
Thema	2012		ABS	▲	▲	▲	▲	▲	F00B7 F00B8 F00B9
Thema	2012		IPC	▲	▲	▲	▲	▲	F00BB F0189
Thema	2012		SCCM	▲	▲	▲	▲	○	
Thema	2012		ITM	▲	▲	▲	▲	▲	F0105 F0104 F0103 F0106 F0102
Thema	2012		TPM	▲	▲	▲	▲	○	F011E F011D F008B F008A F008C F0088 F011F
Thema	2012		HSM	▲	▲	▲	▲	▲	
Thema	2012		EPS	▲	▲	▲	▲	○	
Thema	2012		RFH	▲	▲	▲	▲	▲	F00C0 F00BD F00BF F015B F00BE F00C1 F015A F00BC F00C2 F015C
Thema	2012		MSM	▲	▲	▲	▲	▲	F0190 F018C F018F F018B F018E F018D F018A
Thema	2012		DTCM	▲	▲	▲	▲	▲	
Thema	2012		ACC	▲	▲	▲	▲	○	
Thema	2012		BCM	▲	▲	▲	▲	▲	F010A F0107 F0109 F0111 F0108 F0110 F0113 F010C F005A F010E F010B F0114 F0112

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Thema	2012		HFM	▲	▲	▲	▲	○	F00BA
Thema	2012		BSM	▲	▲	▲	▲	○	F0192
Thema	2012		ADCM	▲	▲	▲	▲	○	
Voyager	2012		DVD	▲	▲	▲	▲	○	
Voyager	2012		BSM	▲	▲	▲	▲	○	F0192
Voyager	2012		HVAC	▲	▲	▲	▲	▲	F019B F015E F019C F019D F019E F0119 F0117 F0118 F011A F0134
Voyager	2012		PLGM	▲	▲	▲	▲	▲	F019F F01A0 F01A1
Voyager	2012		SAS	▲	▲	▲	▲	○	
Voyager	2012		DMFL	▲	▲	▲	▲	▲	
Voyager	2012		CCN	▲	▲	▲	▲	▲	F0173 F0174 F0176 F0175
Voyager	2012		SUNR	▲	▲	▲	▲	▲	
Voyager	2012		PCM	▲	▲	▲	▲	▲	F00CD F00C4 F01A7 F01A9 F01A3 F00CA F01A2 F01A6 F00CB F01A5 F01A4 F00CC F01A8 F00D8 F00DD F0100 F00D9 F00DE F0101 F00DA F00DF F00E3 F00DB F00FE F00D4 F00E2 F00E6 F00FF F00EC F00EA F00EB F00F3 F00E8 F00E9 F00F4 F00DC F00E0 F00E4 F00D6 F00ED F00EE F00EF F00F9 F00FB F00FC F00F7 F00E7 F00E5 F00FD F00D5 F00E1 F00D1 F00D2 F00D0 F00D3 F00F8 F00F2 F00FA F00D7 F00F5 F00F6 F00F0 F00F1
Voyager	2012		RADIO	▲	▲	▲	▲	▲	F017A F0179 F0121 F017B F017D F017C
Voyager	2012		DMRL	▲	▲	▲	▲	▲	F01AA F01AB F01AC
Voyager	2012		TPM	▲	▲	▲	▲	○	F008D F008B F008A F008C F0088
Voyager	2012		TCM	▲	▲	▲	▲	▲	F0156 F0152 F0153 F0154 F00DC F00FD F0158 F0157 F0155
Voyager	2012		PEM	▲	▲	▲	▲	○	F00C0 F01AD F00BF F01AE
Voyager	2012		VES3	▲	▲	▲	▲	▲	
Voyager	2012		ORC	▲	▲	▲	▲	○	F00B4 F00B6 F00B5
Voyager	2012		EPPM	▲	▲	▲	▲	○	F0159
Voyager	2012		PSDML	▲	▲	▲	▲	○	F01B2 F01B0 F01B1 F01AF F01A1
Voyager	2012		FSM	▲	▲	▲	▲	▲	F01B5 F01B6 F01B3 F01B4
Voyager	2012		HFM	▲	▲	▲	▲	▲	F00BA
Voyager	2012		ABS	▲	▲	▲	▲	▲	F00B7 F00B8 F015F F0160
Voyager	2012		PTS	▲	▲	▲	▲	▲	F011B F011C

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Voyager	2012		PSDMR	▲	▲	▲	▲	○	F01B2 F01B0 F01B1 F01AF F01A1
Voyager	2012		WCM	▲	▲	▲	▲	▲	F017E F017F F01B7 F0181 F01B9 F01B8
Voyager	2012		ITM	▲	▲	▲	▲	▲	F01BD F0105 F01BC F01BB F0106
Voyager	2012		HSM	▲	▲	▲	▲	▲	F01BE
Voyager	2012		DMRR	▲	▲	▲	▲	▲	F01AA F01AB F01AC
Voyager	2012		DMFR	▲	▲	▲	▲	▲	
Voyager	2012		HIDT	▲	▲	▲	▲	▲	F01BF
Voyager	2012		VES2	▲	▲	▲	▲	▲	
Voyager	2012		AHBM	▲	▲	▲	▲	○	F010C F0173
Voyager	2012		TIPMCGW	▲	▲	▲	▲	▲	F010A F01C4 F0109 F0111 F0108 F0110 F016E F0168 F0169 F0113 F0177 F01C1 F005A F01C3 F0163 F0166 F0165 F0162 F0171 F0114 F0112 F0164 F0161 F01C2 F0167
Voyager	2012		MSMD	▲	▲	▲	▲	▲	F0190 F018C F018D F018F F018B F018E F018A
Voyager	2012		AMP	▲	▲	▲	▲	○	F0116 F0115
Flavia	2013		CCN	▲	▲	▲	▲	▲	F0173 F0113 F0177 F0174 F0176 F0178 F0175
Flavia	2013		DDM	▲	▲	▲	▲	▲	F015D
Flavia	2013		ABS	▲	▲	▲	▲	▲	F015F F0160 F00B8
Flavia	2013		PTCM	▲	▲	▲	▲	○	
Flavia	2013		HFM	▲	▲	▲	▲	▲	F00BA
Flavia	2013		PCM	▲	▲	▲	▲	▲	F00D8 F00DD F00D9 F00DE F00DA F00DF F00DB F00FE F00D4 F00E2 F00E6 F00FF F00EC F00EA F00F3 F00E8 F00F4 F00DC F00E0 F00D6 F00ED F00EE F00F9 F00FB F00F7 F00E7 F00E5 F00C4 F00FD F00D5 F00E1 F00D1 F00D2 F00D0 F00D3 F00F8 F00F2 F00FA F00D7 F00F6 F00F0 F00F1 F01C7 F01CA F01C6 F01C8 F01C9 F01CB
Flavia	2013		SAS	▲	▲	▲	▲	○	
Flavia	2013		ESM	▲	▲	▲	▲	▲	
Flavia	2013		PDM	▲	▲	▲	▲	▲	F015D
Flavia	2013		WCM	▲	▲	▲	▲	○	F017E F0182 F017F F0181 F0184
Flavia	2013		HVAC	▲	▲	▲	▲	▲	F0117 F015E F0134 F0119 F0118
Flavia	2013		AMP	▲	▲	▲	▲	○	F0116 F0115

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Flavia	2013		RADIO	▲	▲	▲	▲	▲	F017A F0179 F0121 F017B F017D F017C
Flavia	2013		TCM	▲	▲	▲	▲	▲	F0142 F0141 F013E F0045 F0140 F013F
Flavia	2013		TIPMCGW	▲	▲	▲	▲	▲	F010A F0109 F0111 F0108 F016E F0168 F0169 F016B F016C F005A F016D F016A F0172 F0163 F016F F0166 F0165 F0170 F0162 F0171 F0114 F0112 F0164 F0161 F0167
Flavia	2013		ORC	▲	▲	▲	▲	○	F00B4
Thema	2013		HSM	▲	▲	▲	▲	▲	
Thema	2013		BCM	▲	▲	▲	▲	▲	F010A F0107 F0109 F0111 F0108 F0110 F0113 F010C F005A F010E F010B F0114 F0112
Thema	2013		IPC	▲	▲	▲	▲	▲	F00BB F0189
Thema	2013		HFM	▲	▲	▲	▲	○	F00BA
Thema	2013		AMP	▲	▲	▲	▲	○	F0116 F0115
Thema	2013		ACC	▲	▲	▲	▲	○	
Thema	2013		HVAC	▲	▲	▲	▲	▲	F0117 F0118 F011A F0119
Thema	2013		RBSS	▲	▲	▲	▲	○	
Thema	2013		PCM	▲	▲	▲	▲	▲	F00D8 F00DD F00D9 F00DE F00DA F00DF F00DB F00FE F00D4 F00E2 F00E6 F00FF F00EC F00EA F00F3 F00E8 F00F4 F00DC F00E0 F00D6 F00ED F00EE F00F9 F00FB F00F7 F00E7 F00E5 F00C4 F00FD F00D5 F00E1 F00D1 F00D2 F00D0 F00D3 F00F8 F00F2 F00FA F00D7 F00F6 F00F0 F00F1 F00C9 F00CD F00C8 F00CF F00CA F00C7 F00CB F00C6 F00CE F00C5 F00CC F01C7 F01CA F01C6 F01C8 F01C9 F01CB
Thema	2013		EPS	▲	▲	▲	▲	○	
Thema	2013		RFH	▲	▲	▲	▲	▲	F00C0 F00BD F00BF F015B F00BE F00C1 F015A F00BC F00C2 F015C
Thema	2013		TCM	▲	▲	▲	▲	○	F0186 F0030 F0188
Thema	2013		ABS	▲	▲	▲	▲	▲	F00B7 F00B8 F00B9
Thema	2013		TGW	▲	▲	▲	▲	○	F0120 F0121 F0123 F0122
Thema	2013		MSM	▲	▲	▲	▲	▲	F0190 F018C F018F F018B F018E F018D F018A

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Thema	2013		TPM	▲	▲	▲	▲	○	F011E F011D F008B F008A F008C F0088 F011F
Thema	2013		ITM	▲	▲	▲	▲	▲	F0105 F0104 F0103 F0106 F0102
Thema	2013		LBSS	▲	▲	▲	▲	○	
Thema	2013		SCCM	▲	▲	▲	▲	○	
Thema	2013		PDM	▲	▲	▲	▲	▲	
Thema	2013		ORC	▲	▲	▲	▲	○	F0185 F00B6
Thema	2013		ICS	▲	▲	▲	▲	▲	
Thema	2013		DDM	▲	▲	▲	▲	▲	
Thema	2013		AFLS	▲	▲	▲	▲	▲	F00AE
Thema	2013		PTS	▲	▲	▲	▲	▲	F011B F011C
Thema	2013		ESM	▲	▲	▲	▲	▲	
Thema	2013		ADCM	▲	▲	▲	▲	○	
Thema	2013		DTCM	▲	▲	▲	▲	▲	
Voyager	2013		TPM	▲	▲	▲	▲	○	F008D F008B F008A F008C F0088
Voyager	2013		AMP	▲	▲	▲	▲	○	F0116 F0115
Voyager	2013		EPPM	▲	▲	▲	▲	○	F0159
Voyager	2013		ABS	▲	▲	▲	▲	▲	F00B8 F015F F00B7 F0160
Voyager	2013		HSM	▲	▲	▲	▲	▲	F01BE
Voyager	2013		HFM	▲	▲	▲	▲	▲	F00BA
Voyager	2013		DMRR	▲	▲	▲	▲	▲	F01AA F01AB F01AC
Voyager	2013		FSM	▲	▲	▲	▲	▲	F01B5 F01B6 F01B3 F01B4
Voyager	2013		VES2	▲	▲	▲	▲	▲	
Voyager	2013		PSDMR	▲	▲	▲	▲	○	F01B2 F01B0 F01B1 F01AF F01A1
Voyager	2013		PLGM	▲	▲	▲	▲	▲	F019F F01A0 F01A1
Voyager	2013		LBSS	▲	▲	▲	▲	○	
Voyager	2013		PSDML	▲	▲	▲	▲	○	F01B2 F01B0 F01B1 F01AF F01A1
Voyager	2013		AHBM	▲	▲	▲	▲	▲	F01CF
Voyager	2013		ORC	▲	▲	▲	▲	○	F00B4 F00B6
Voyager	2013		ITM	▲	▲	▲	▲	▲	F01BD F0105 F01BC F01BB F0106
Voyager	2013		DMRL	▲	▲	▲	▲	▲	F01AA F01AB F01AC
Voyager	2013		RADIO	▲	▲	▲	▲	▲	F017A F0179 F0121 F017B F017D F017C

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Voyager	2013		PCM	▲	▲	▲	▲	▲	F00D8 F00DD F00D9 F00DE F00DA F00DF F00DB F01C7 F01CA F00FE F00D4 F00E2 F00E6 F00FF F00EC F00EA F00F3 F00E8 F00F4 F00DC F00E0 F00D6 F00ED F00EE F00F9 F00FB F00F7 F01C6 F00E7 F00E5 F00C4 F00FD F01C8 F01C9 F00D5 F00E1 F00D1 F00D2 F00D0 F00D3 F00F8 F00F2 F00FA F00D7 F00F6 F01CB F00F0 F00F1 F00CD F01A7 F01A9 F01A3 F00CA F01A2 F01A6 F00CB F01A5 F01A4 F00CC F01A8
Voyager	2013		CCN	▲	▲	▲	▲	▲	F0173 F0174 F0176 F0175
Voyager	2013		TIPMCGW	▲	▲	▲	▲	▲	F010A F01C4 F0109 F0111 F0108 F0110 F016E F0168 F0169 F0113 F0177 F01C1 F005A F01C3 F0163 F0166 F0165 F0162 F0171 F0114 F0112 F0164 F0161 F01C2 F0167
Voyager	2013		SAS	▲	▲	▲	▲	○	
Voyager	2013		HVAC	▲	▲	▲	▲	▲	F019B F015E F019C F019D F019E F0119 F0117 F0118 F011A F0134
Voyager	2013		RBSS	▲	▲	▲	▲	○	
Voyager	2013		WCM	▲	▲	▲	▲	▲	F017E F017F F01B7 F0181 F01B9 F01B8
Voyager	2013		VES3	▲	▲	▲	▲	▲	
Voyager	2013		DMFR	▲	▲	▲	▲	▲	
Voyager	2013		DVD	▲	▲	▲	▲	○	
Voyager	2013		SUNR	▲	▲	▲	▲	▲	
Voyager	2013		PEM	▲	▲	▲	▲	○	F00C0 F01AD F00BF F01AE
Voyager	2013		PTS	▲	▲	▲	▲	▲	F011B F011C
Voyager	2013		MSMD	▲	▲	▲	▲	▲	F0190 F018C F018D F018F F018B F018E F018A
Voyager	2013		DMFL	▲	▲	▲	▲	▲	
Voyager	2013		HIDT	▲	▲	▲	▲	▲	F01BF
Voyager	2013		TCM	▲	▲	▲	▲	▲	F0156 F0152 F0153 F0154 F00DC F00FD F0158 F0157 F0155
Thema	2014		HVAC	▲	▲	▲	▲	▲	F0117 F0118 F011A F0119
Thema	2014		ITM	▲	▲	▲	▲	▲	F0105 F0104 F0103 F0106 F0102

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Thema	2014		RFH	▲	▲	▲	▲	▲	F00C0 F00BD F00BF F015B F00BE F00C1 F015A F00BC F00C2 F015C
Thema	2014		IPC	▲	▲	▲	▲	▲	F00BB F0189
Thema	2014		ADCM	▲	▲	▲	▲	○	
Thema	2014		AMP	▲	▲	▲	▲	○	F0116 F0115
Thema	2014		TGW	▲	▲	▲	▲	○	F0120 F0121 F0123 F0122
Thema	2014		DDM	▲	▲	▲	▲	▲	
Thema	2014		TCM	▲	▲	▲	▲	○	F0186 F0030 F0188
Thema	2014		RBSS	▲	▲	▲	▲	○	
Thema	2014		PCM	▲	▲	▲	▲	▲	F00D8 F00DD F00D9 F00DE F00DA F00DF F00DB F01CA F00FE F00D4 F00E2 F00E6 F00FF F00EC F00EA F00F3 F00E8 F00F4 F00DC F00E0 F00D6 F00ED F00EE F00F9 F00FB F00F7 F01C6 F00E7 F00E5 F00C4 F00FD F01C9 F00D5 F00E1 F00D1 F00D2 F00D0 F00D3 F00F8 F00F2 F00FA F00D7 F00F6 F00F0 F00F1 F01C7 F00C9 F00CD F00C8 F00CF F00CA F00C7 F00CB F00C6 F00CE F00C5 F00CC
Thema	2014		MSM	▲	▲	▲	▲	▲	F0190 F018C F018F F018B F018E F018D F018A
Thema	2014		ACC	▲	▲	▲	▲	○	
Thema	2014		DTCM	▲	▲	▲	▲	▲	
Thema	2014		PTS	▲	▲	▲	▲	▲	F011B F011C
Thema	2014		HFM	▲	▲	▲	▲	○	F00BA
Thema	2014		ESM	▲	▲	▲	▲	▲	
Thema	2014		PDM	▲	▲	▲	▲	▲	
Thema	2014		ABS	▲	▲	▲	▲	▲	F00B7 F00B8 F00B9
Thema	2014		BCM	▲	▲	▲	▲	▲	F010A F0107 F0109 F0111 F0108 F0110 F0113 F010C F005A F010E F010B F0114 F0112
Thema	2014		AFLS	▲	▲	▲	▲	▲	F00AE
Thema	2014		ORC	▲	▲	▲	▲	○	F0185 F00B6
Thema	2014		EPS	▲	▲	▲	▲	○	
Thema	2014		HSM	▲	▲	▲	▲	▲	
Thema	2014		ICS	▲	▲	▲	▲	▲	
Thema	2014		LBSS	▲	▲	▲	▲	○	
Thema	2014		SCCM	▲	▲	▲	▲	○	
Thema	2014		TPM	▲	▲	▲	▲	○	F011E F011D F008B F008A F008C F0088 F011F
Voyager	2014		SAS	▲	▲	▲	▲	○	

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Voyager	2014		RBSS	▲	▲	▲	▲	○	
Voyager	2014		ORC	▲	▲	▲	▲	○	F00B4 F00B6
Voyager	2014		AMP	▲	▲	▲	▲	○	F0116 F0115
Voyager	2014		SUNR	▲	▲	▲	▲	▲	
Voyager	2014		HSM	▲	▲	▲	▲	▲	F01BE
Voyager	2014		HFM	▲	▲	▲	▲	▲	F00BA
Voyager	2014		FSM	▲	▲	▲	▲	▲	F01B5 F01B6 F01B3 F01B4
Voyager	2014		DMFR	▲	▲	▲	▲	▲	
Voyager	2014		AHBM	▲	▲	▲	▲	▲	F01CF
Voyager	2014		VES2	▲	▲	▲	▲	▲	
Voyager	2014		PSDML	▲	▲	▲	▲	○	F01B2 F01B0 F01B1 F01AF F01A1
Voyager	2014		EPPM	▲	▲	▲	▲	○	F0159
Voyager	2014		MSMD	▲	▲	▲	▲	▲	F0190 F018C F018D F018F F018B F018E F018A
Voyager	2014		HIDT	▲	▲	▲	▲	▲	F01BF
Voyager	2014		TPM	▲	▲	▲	▲	○	F008D F008B F008A F008C F0088
Voyager	2014		WCM	▲	▲	▲	▲	▲	F017E F017F F01B7 F0181 F01B9 F01B8
Voyager	2014		ITM	▲	▲	▲	▲	▲	F01BD F0105 F01BC F01BB F0106
Voyager	2014		VES3	▲	▲	▲	▲	▲	
Voyager	2014		PLGM	▲	▲	▲	▲	▲	F019F F01A0 F01A1
Voyager	2014		PEM	▲	▲	▲	▲	○	F00C0 F01AD F00BF F01AE
Voyager	2014		ABS	▲	▲	▲	▲	▲	F00B7 F00B8
Voyager	2014		LBSS	▲	▲	▲	▲	○	
Voyager	2014		PSDMR	▲	▲	▲	▲	○	F01B2 F01B0 F01B1 F01AF F01A1
Voyager	2014		RADIO	▲	▲	▲	▲	▲	F017A F0179 F0121 F017B F017D F017C
Voyager	2014		TCM	▲	▲	▲	▲	▲	F0156 F0152 F0153 F0154 F00DC F00FD F0158 F0157 F0155
Voyager	2014		DMFL	▲	▲	▲	▲	▲	
Voyager	2014		PTS	▲	▲	▲	▲	▲	F011B F011C
Voyager	2014		HVAC	▲	▲	▲	▲	▲	F019B F015E F019C F019D F019E F0119 F0117 F0118 F0134 F011A
Voyager	2014		DVD	▲	▲	▲	▲	○	
Voyager	2014		DMRL	▲	▲	▲	▲	▲	F01AA F01AB F01AC

Model	Version	Group	System	ECU info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Voyager	2014		PCM	▲	▲	▲	▲	▲	F00CD F00C4 F01A7 F01A9 F01A3 F00CA F01A2 F01A6 F00CB F01A5 F01A4 F00CC F01A8 F00D8 F00DD F00D9 F00DE F00DA F00DF F00DB F01CA F00FE F00D4 F00E2 F00E6 F00FF F00EC F00EA F00F3 F00E8 F00F4 F00DC F00E0 F00D6 F00ED F00EE F00F9 F00FB F00F7 F01C6 F00E7 F00E5 F00FD F01C9 F00D5 F00E1 F00D1 F00D2 F00D0 F00D3 F00F8 F00F2 F00FA F00D7 F00F6 F00F0 F00F1 F01C7
Voyager	2014		DMRR	▲	▲	▲	▲	▲	F01AA F01AB F01AC
Voyager	2014		TIPMCGW	▲	▲	▲	▲	▲	F010A F01C4 F0109 F0111 F0108 F0110 F016E F0168 F0169 F0113 F0177 F01C1 F005A F01C3 F0163 F0166 F0165 F0162 F0171 F0114 F0112 F0164 F0161 F01C2 F0167

Special_Function

Index	Specil Function Name	Index	Specil Function Name
0001	Air conditioner Learn	0002	Air flow meter replacement (only for version with Lambda sensor)
0003	Air flow meter sensor replacement	0004	Air flow sensor replacement
0005	Alarm deletion	0006	Alarm state check
0007	Antenna replacement	0008	Automatic Configuration Read
0009	Automatic Configuration Write	0010	Brake bleed
0011	Cam edges zeroing (VVT)	0012	Control unit activation
0013	Control unit deactivation	0014	Control unit replacement
0015	Cruise Control Learn	0016	Cyl. 1 injector classification
0017	Cyl. 2 injector classification	0018	Cyl. 3 injector classification
0019	Cyl. 4 injector classification	0020	Differential pressure sensor replacement (only for version with DPF)
0021	EGR valve learn	0022	EGR valve replacement
0023	Engine - Control Unit Group Replacement	0024	Engine type configuration
0025	FAP Replacement	0026	Fuel supply system
0027	Headlamp pos. correct.	0028	Injector classification (4 cyl. bank)
0029	Injector codes read	0030	Injector replacement (per bank)
0031	Inputs status	0032	Inspection service value
0033	Instrument panel lighting	0034	Instrument panel replacement
0035	Knock counter reset	0036	Lambda sensor check
0037	Lambda sensor replacement (only for version with Lambda sensor)	0038	LED colours configuration
0039	Longit. acc. sensor calibration	0040	Looks for faulty wheel transmitter
0041	Manual System Configuration	0042	Odometer write
0043	Oil change (only for version with DPF)	0044	Oil change servicing information delete
0045	Overboost counter reset	0046	Particulate filter regeneration (only for version
0047	Particulate filter replacement (only for version with	0048	Phase sensor learn zeroing
0049	Phonic wheel learn reset	0050	Phonic wheel replacement
0051	Position sensor calibration	0052	Pre-catalyser replacement (only for version with DPF)
0053	Rail pressure sensor and injector/s replacement	0054	Rail pressure sensor replacement
0055	Replacement injector cyl. 5	0056	Replacement injectors (4 cyl. bank)
0057	Replacement Lambda sensor	0058	Replacement of injector cyl. 1
0059	Replacement of injector cyl. 2	0060	Replacement of injector cyl. 3
0061	Replacement of injector cyl. 4	0062	Replacement of particulate filter with built-in pre-catalyzer (only for versions with DPF)
0063	Replacment of control unit and injector/s	0064	Reset odometer
0065	Seat belts alarm Enable	0066	Seat belts alarm exclusion
0067	Secondary wheel identification deletion	0068	Self-learnt functions reset
0069	Services Interval KM message	0070	Servicing information delete
0071	Servo Mechanism Group Replacement	0072	Speed limit setting
0073	Startup with Code Card	0074	Steering angle calibration
0075	Steering angle reset	0076	System configuration
0077	Throttle learn storage	0078	Tow hook presence disable
0079	Tow hook presence enable	0080	Variable geometry turbo replacement
0081	Vehicle configuration deletion	0082	Vehicle type learn reset
0083	Wheel identification check	0084	Wheel transmitters learning
0085	Zeroing of self-adaption parameters	0086	Engine control unit programming
0087	System calibration	0088	Total additive quantity
0089	Part. Filter regeneration	0090	Customer mode
0091	Mounting check	0092	Tyre Pressure check
0093	Control Unit Replacement	0094	Additive type configuration
0095	RH distribution flap learn	0096	LH distribution flap learn
0097	LH mixing flap learn	0098	RH mixing flap learn
0099	United Kingdom (Thatcham std)	0100	Date daylight time changed
0101	Fuel level regulat.	0102	Oil change
0103	Self-adaptive parameters	0104	Phonic wheel learn
0105	Injector classification	0106	Recognition of speed sensor type
0107	Actuator tests	0108	Self-adaptation Parameter erasure
0109	Sensor vibration time too long	0110	Dist. To Next Service Zeroing (Coupon)
0111	Maintenance Services Config.	0112	Call buttons configuration
0113	Clutch replacement	0114	KIT/Gearbox replacement
0115	Electropump replacement	0116	Statistical data deletion
0117	Tunnel lever replacement	0118	Steering wheel levers replacement
0119	KIT/Pump replacement	0120	Pump relay replacement
0121	AUTO switch replacement	0122	Key storage
0123	System Configuration Read	0124	System Configuration Write

Index	Specil Function Name	Index	Specil Function Name
0125	Reset self-adapt. param. and idle act.	0126	Electronic Key control unit programming
0127	Engine Control + Electronic Key control units	0128	Clutch bleed
0129	Accumulator depressurisation	0130	Clutch self-calibration enable
0131	End of line / service self-calibration	0132	New actuators
0133	Flap actuators learning test	0134	Oil Counter Write
0135	Engagement lever pin securing screw diagnosis	0136	Selection lever return diagnosis
0137	Memory mode write	0138	Control Unit Unlock
0139	Calculation of clutch degradation index	0140	Test limit speed disable
0141	Test limit speed restore	0142	VIN Code Configuration
0143	Personal data deletion	0144	Cyl. 5 injector classification
0145	Injector classification (5 cyl. bank)	0146	Deletion of statistical data relating to errors
0147	CITY switch replacement	0148	SPORT switch replacement
0149	Activation/Deactivation 'Auxiliary video input'	0150	Cruise control learn zeroing
0151	Zeroing fan mode learn	0152	Borg Warner sol. valves compatibility
0153	Self-adapting parameters zeroing (air)	0154	Self-adapting parameters zeroing (knock)
0155	Gearbox Lever Position Learn	0156	Deletion stored buttons
0157	Audio System Test	0158	Convergence System Restart
0159	CAN Network Activation	0160	Deletion of air temperature sensor data
0161	High pressure pump replacement	0162	Additional diesel circuit filling
0163	Gearbox replacement	0164	Gearbox oil accumulator replacement
0165	Pilot injection learn	0166	ECO switch replacement
0167	End of line self-calibration	0168	Forced trim correction
0169	Vehicle geometry height setting	0170	Pneumatic circuit filling
0171	Pneumatic circuit unloading	0172	Longitudinal acceleration signal learn
0173	JukeBox data deletion	0174	ECO/SPORT switch replacement
0175	'UP Function' switch replacement	0176	Services Interval KM write (only 1.6 MJET 16V 105 hp
0177	Automatic gearbox replacement	0178	Automatic gearbox and Control unit replacement
0179	Automatic gearbox oil replacement	0180	Services Interval KM write (only for 1.4 TURBO 16v 120/150 bhp eng.)
0181	Static test	0182	C.P.H control unit programming
0183	C.P.H. control unit and engine control unit	0184	Remote control programming
0185	Key programming	0186	New vehicle preparation
0187	Reset distance till next servicing	0188	FAP Temperature Probe presence configuration
0189	Replacement of particulate filter and interventions on diesel additive circuit.	0190	Replacement of the additive, or the pump, or the tubes.
0191	System configuration via Examiner Web	0192	Performance limiting deactivation
0193	Volumetric sensors automatic diagnosis	0194	Neutral signal learn
0195	Hydraulic Kit replacement	0196	Sensors module replacement
0197	Selection and/or engagement clutch electrovalve	0198	Resetting distance travelled with Water Temp. w. lamp
0199	Resetting distance travelled with Water in diesel w. lamp ON	0200	Accelerometer calibration
0201	Control unit Replacement / Reprogramming	0202	Motorised throttle replacement
0203	Upstream lambda sensor replacement	0204	MultiAir Rolling finger replacement
0205	Timing sensor and/or cam replacement	0206	Rpm sensor and/or distribution belt replacement
0207	Oil temperature sensor replacement	0208	UniAir module replacement
0209	Supercharging system components replacement	0210	Downstream lambda sensor and/or catalyzer and/or Injectors replacement
0211	Differential pressure sensor replacement	0212	Particulate filter with integrated pre-cat
0213	Particulate filter regeneration	0214	Mechanical waste-gate valve replacement
0215	Replacement of variable geometry turbo and/or turbo posit. sensor	0216	Lateral and longitud. acceleration sensor calibration
0217	Pressure sensor calibration	0218	Load valves calibration
0219	Pilot valves calibration	0220	Longitudinal acceleration sensor replacement
0221	Even no. gear clutch pressure sensor replacement	0222	Odd no. gear clutch position sensor replacement
0223	Odd and/or even gear clutch replacement	0224	Electropump drive unit replacement
0225	Gearbox button panel replacement	0226	Replacement injectors
0227	Additive quantity volume	0228	Air flow meter replacement
0229	Air metering unit replacement	0230	Supercharg. air cooling SV replacement
0231	Replacement of Lambda sensor	0232	Homologation number
0233	Speed limit	0234	Levers on steering wheel learn
0235	Gearbox and hydraulic KIT replacement	0236	Parking manoeuvre status
0237	Phonic wheel and/or phase sensor and/or rev sensor replacement	0238	Replacement of lambda sensor and/or spark plugs and/or injectors
0239	Replacement of pressure/temperature sensor in methane	0240	Pre-catalyzer replacement
0241	Particulate filter replacement	0242	Alcohol fuel setting
0243	Petrol fuel setting	0244	Air/Fuel learn setting
F0003	Disable seat belts reminder	F00E5	Check PCM Odometer
F0001	Ecu Replacement	F00FD	Clear Learned Variable Line Pressure (VLP) Counters
F0004	Enable seat belts reminder	F00D5	Enable Emissions Rolls Test Mode (PowerNet)
F0005	Reset Odometer	F00E1	Enable Emissions Rolls Test Mode (TIPM)

Index	Specil Function Name	Index	Specil Function Name
F0006	Reset Service Information	F00D1	Exhaust Phaser 1 Cleaning
F0007	Instrument Panel Cluster Replacement	F00D2	Exhaust Phaser 2 Cleaning
F0008	Longitudinal G-Sensor Calibration Test	F00D0	Intake Phaser 1 Cleaning
F0009	Static test	F00D3	Intake Phaser 2 Cleaning
F000A	Steering angle sensor calibration	F00F8	Learn ETC
F0011	Self-learnt functions reset	F00F2	New Engine Installed
F0010	Speed limit setting	F00FA	Quicklearn (62TE)
F0012	Cylinder 1 injector replacement	F00D7	Quicklearn (Non-RFE)
F0013	Cylinder 2 injector replacement	F00F5	Quicklearn (RFE)
F0014	Cylinder 3 injector replacement	F00F6	Reset Memory
F0015	Cylinder 4 injector replacement	F00F0	TCC Break-In (62TE)
F000C	Injector codes read	F00F1	TCC Break-In (Non-RFE)
F0016	Injector replacement (per bank)	F0105	ITM and Siren Communication Test
F000D	Oil change	F0104	ITM Self Test
F000E	Phonic wheel replacement	F0103	ITM Siren Test
F0019	Pre-catalyzer replacement	F0106	Ultrasonic Motion Detection Test
F0017	Rail pressure sensor replacement	F0102	Initialize Siren
F000B	Startup with CODE CARD	F010A	View Last Successful Remote Start Event Data
F0022	Fan cooling activation	F0107	View Last VTA Trigger Cause Data
F0021	Resetting distance travelled with Water in diesel warning lamp ON	F0109	View Remote Start Abort Data
F0025	Air flow meter sensor replacement	F0111	View Remote Start Enable Data
F001E	Intelligent alternator (TAM) replacement	F0108	View Remote Start Inhibit Data
F0024	Lambda sensor replacement	F0110	View VTA Enable Data
F001F	Neutral signal learning	F0113	Auto Door Lock
F002B	Clutch group and/or clutch potentiometer replacement	F010C	Auto High Beam Aim Test
F002C	Fuel press. regulator replacement (high press. pump)	F010E	Exit Shipping Mode
F002D	Rail overpressure waste gate valve replacement	F010B	Light Rain Sensor Re-Adaption
F0030	Reset Learned Adaptives	F0114	Program Tire Size
F002F	Reset vehicle configuration	F0112	Remote Start Temporary Disable
F0033	Adaptive parameters reset	F0116	Amp Input Test
F0035	Vehicle Configuration reset	F0115	Amp Software Test
F0031	Motorised throttle replacement	F0117	Actuator Calibration Test
F0034	Phonic wheel Reset	F0118	HVAC Cool Down Test
F0032	Timing sensor and/or cam replacement	F011A	First Pass Cool Down Test Results
F0036	Self-adaptive parameters reset	F0119	Most Recent Cool Down Test Results
F0038	Fuel supply system components replacement	F011B	System Wiring Test
F003F	Clutch Replacement	F011C	Configure License Plate Size
F0043	ECO function switch Replacement	F011E	Sensor Rolls Test
F003D	Electropump replacement	F011D	Activate TPM High Gain Mode
F003B	Gearbox oil accumulator replacement	F011F	TPM Sensor Position Parameter Update
F003C	Gearbox replacement	F0120	Anti-Theft Override Test
F0041	Longitudinal acceleration sensor replacement	F0121	Enable/Disable Front Seat Video
F003A	Pump Relay Replacement	F0123	ROW Map Configuration
F0039	Tunnel lever replacement	F0122	TGW Tone Test
F004D	Accumulator Oil replacement	F0124	Wheel speed sensor type test
F0046	Clutch bleed	F0126	tow hook enabled
F0048	Clutch group replacement	F0127	tow hook exclusion
F0044	Clutch self-calibration enable	F0129	Reset learning gear neutral position value
F004E	Hydraulic pressure depressurisation	F0128	Self learning throttle body
F004A	Kit replacement	F009C	Control unit reprogramming
F004B	Levers at wheel replacement	F012B	Steering Angle Sensor
F0045	New actuators	F012F	Body Blinking Lights Configuration
F0049	Pump replacement	F0130	TPM FGA Proxi Configuration
F0047	Reset statistical data	F0132	Pressure sensor calibration
F004C	Switich AUTO replacement	F0131	Reset gear configuration
F0050	Trailer Hook presence disabling	F0133	Program Keys TRM 343
F0051	Trailer Hook presence enabling	F0134	First Passed Cool Down Test Results
F0052	Self Learning Working Mode	F0136	IPC Disable Seatbelt Minder Chime
F0053	Audio System Test	F0135	IPC Enable Seatbelt Minder Chime
F0054	ECU Restart routine	F0137	Proxi Configuration
F0059	Blinking Lights Configuration	F0139	CTM Proxi Configuration
F005A	Change Country Code	F013A	Clear Steering Pull Compensation
F0057	Exit Logistic Mode	F013B	Initialize EPS
F0058	Fire Protection System Activate	F013C	Clear Self Learning data
F005C	LIN Anti-tilt Sensor Check	F013D	Neutral Position Self-Learning
F005D	LIN Line Request Check	F0142	Bleed Hydraulic Circuit
F005E	LIN Ultrasonic Sensors Check	F0141	Hydraulic Circuit Depressurization
F0061	Modify lateral anti-tilt sensor	F013E	Learn Clutches Contact Point
F0062	Modify longitudinal anti-tilt sensor	F0143	Learn Long Acceleration Signal

Index	Specil Function Name	Index	Specil Function Name
F0060	Modify volumetric sensors sensibility	F0140	Quick Learn
F0064	Self adaptive parameters reset	F013F	Reset of Data Group
F0066	Megaknock counter reset	F0144	ABS Static Test
F0065	Over boost counter reset	F0147	Enable Front Fog Lamp Output
F0067	Deactivation of the Power Limitation function	F0146	Initialize Power Top
F006A	Lambda sensor and/or catalytic convertor replacement	F0149	RADIO Proxi Configuration
F0068	Rpm sensor and/or timing chain replacement	F014E	Air-Conditioning Self Learning
F0069	Supercharging system components replacement	F014D	Brake Switch Learn
F006F	Lambda sensor and/or catalytic convertor and/or injector replacement	F0150	Clear Misfire TLC
F0020	Resetting distance travelled with water temperature warning lamp ON	F014F	Clutch Pedal Learn
F0073	Clutch pedal learning	F0151	Emissions Rolls Test Mode
F0072	Motorized Throttle learning	F014B	Reset Accelerator Pedal Adaptives
F0071	Reset phases front	F014A	Reset ECU
F0074	Overboost counter Reset	F014C	Throttle Body Self Learning
F0075	Neutral Signal learning with engine off	F0156	1st Gear Clutch Test 62TE
F0078	Power Down	F0152	2nd Gear Clutch Test 62TE
F0077	Power on and Disable User Inputs	F0153	3rd Gear Clutch Test 62TE
F0076	Reset Parameters to Default	F0154	4th Gear Clutch Test 62TE
F0079	X65 Multi Package Factory Activation - Query Routine	F0158	Quicklearn (62TE - PCM Var16)
F007A	X65 Multi Package Factory Activation - Select Routine	F0157	Quicklearn (62TE - PCM Var17)
F007B	X65 Multi Package Factory Activation - Validate	F0155	TCC Break-In
F007C	Flap actuators learning test	F0159	Initialize EPPM
F007D	Steering Angle Calibration	F015B	Clear Multi-Module VIN Handshake Immobilizer Failure
F0080	Alarms deletion	F015A	ESCL Replaced
F0081	Antenna replacement	F015C	View Recent Multi-Module VIN Handshake Immobilizer
F0082	Control unit activation	F015D	Denormalize Window
F0083	Control unit deactivation	F015E	Cool Down Test
F0084	Manual System Configuration	F015F	Bleed Brakes
F0086	Wheel trasmitters learning	F0160	Initialize ABS
F008D	TPM Sensor Rolls Test	F016E	Accessory Delay Time
F0089	Clear TPM Sensor Rolls Test Results	F0168	Actuate Engine Battery Feed
F0090	Clear TPM Warnings	F0169	Actuate Transmission Relay
F008B	Program Left Front Tire Sensor ID	F016B	Acutate Fuel Pump
F008A	Program Left Rear Tire Sensor ID	F016C	Add Navigation Radio
F008C	Program Right Front Tire Sensor ID	F016D	Combined Rear Lighting
F0088	Program Right Rear Tire Sensor ID	F016A	Enable/Disable DRL
F008E	Update Front and Rear Axle Nominal Tire Pressure	F0172	Enable/Disable Front Fog Lamp
F0092	Electric pump drive unit command	F0163	Flash Hazard Lamps on Lock
F0093	Engagement electrovalve PPV1 command	F016F	Hard Top / Soft Top Configuration
F0094	Engagement electrovalve PPV2 command	F0166	Headlamps Delay Time
F0096	Even gear clutch (K2) control solenoid valve command	F0165	Headlamps On With Wipers
F0098	Lever release solenoid command	F0170	Horn Chirp Duration
F0095	Odd gear clutch (K1) control solenoid valve command	F0162	Illuminated Entry Time
F0097	Range selection electrovalve command (PPVS)	F0171	Program Network Configuration
F0091	Electropump drive unit replacement	F0164	Sound Horn on Lock
F009B	Even no. gear clutch pressure sensor replacement	F0161	Tip Start Temporary Disable
F009D	Hydraulic circuit depressurisation	F0167	Update Radio Market Select and DVD Region Code
F0042	Hydraulic Kit replacement	F0173	Self Test
F0099	Odd and/or even gear clutch replacement	F0177	Auto Door Unlock
F009A	Odd no. gear clutch position sensor replacement	F0174	Change Language Preference
F003E	Selection and/or engagement clutch electrovalve	F0176	Seatbelt Alert Minder
F0040	Sensors module replacement	F0178	Unlock Driver Door On 1st Press
F009E	Reversing lights command	F0175	Update Measurement Unit
F009F	Reset adaptative parameter	F017A	Radio Anti Theft Override Test
F00A0	Motorized throttle replacement	F0179	RADIO Tone Test
F00A1	Reset learn flag wheel tooth	F017B	Radio Hard-drive Back-up
F00A3	Longitudinal and Lateral sensor calibration	F017D	Radio Anti-Theft Override Test
F00A4	Longitudinal and Lateral sensor decalibration	F017C	Radio Enable/Diable Front Video
F00A5	Self Learning Motor Test	F017E	Antenna Loop Test
F00A8	Brake pressure sensor calibration	F0182	TPM Trigger Module Test
F00A6	Inlet Valve Calibration	F017F	ELV Replaced
F00A7	Pilot Valve calibration	F0181	PCM Replaced
F00A9	Steering wheel angle sensor offset calibration	F0184	WCM Replaced
F00AA	TPMS calibration	F0185	View Satellite Sensor Information
F00AD	Engine replacement	F0186	Reset Adaptive Values
F00AE	AFLS Calibration	F0188	Store Learned Adaptives
F00AF	Anti tilt sensor check	F0189	Disable/Enable Seatbelt Minder Chime
F00B0	LIN line check request	F0190	Actuate Seat Recall

Index	Specil Function Name	Index	Specil Function Name
F00B1	Rain Lights Sensors and Automatic Lights Sensors	F018C	MSMD Self Test
F00B2	Siren check	F018F	Clear All Learned Seat Parameters
F00B3	Ultrasonic sensors check	F018B	Easy Entry/Exit
F00B4	Activate Driver and Passenger Head Restraint	F018E	Key Fobs Linked to Memory
F00B6	Initialize ORC	F018D	Standardization
F00B5	Rollover Detection	F018A	Tilt Mirrors in Reverse
F00B7	ABS Bleed Brakes	F0192	Sensor Connectivity and HMI Test
F00B8	ABS Initialization	F0194	Disable tow hook presence
F00B9	Brake Pedal Calibration	F0193	Enable tow hook presence
F00BA	HFM Self Test	F0195	Reset Adaptative Parameters
F00BB	IPC Self Test	F0196	Deactivation of Power Limitation
F00C0	Door Handle Verification Test	F0197	Phonic wheel learning
F00BD	Immobilizer Antenna Test	F0199	Injector/s replacement
F00BF	Locate Learned Keys	F019B	Actuator Calibration
F00BE	ELV Replace	F019C	Front Blower State
F00C1	Erase Ignition FOBIKs	F019D	Rear Blower State
F00BC	Program Ignition FOBIKs	F019E	First Passed Cooldown Test Results
F00C2	RF-HUB Replace	F019F	Calibrate Liftgate Full Close Position
F00C9	Air Flow Meter Replace	F01A0	Calibrate Liftgate Full Open Position
F00C4	Check PCM VIN	F01A1	Ramp Van Configuration
F00CD	Compression Test	F01A7	Diesel Particulate Filter Replacement
F00C8	DPF Reset Option	F01A9	Fuel Mean Value Adaption Initialization
F00CF	ECU Replacement With Value Transfer	F01A3	IMA Quick Calibration
F00CA	Injector Quantity Adjustment	F01A2	Lambda Sensor 1 Initialization
F00C7	Lambda Sensor Replace	F01A6	Oxidation Catalyst Initialization
F00CB	Program Variant Coding	F01A5	Rail Pressure Control Switchover
F00C6	Reset of Lambda Values	F01A4	Request Anti-Slugging For Air Condition Compressor
F00CE	Reset Oil Change Indicator	F01A8	TIPM Enable Emissions Rolls Test Mode
F00C5	Reset Zero Fuel Quantity Calibration	F01AA	Latch Cinch Test
F00CC	Service Diesel Particulate Filter Regeneration	F01AB	Latch Release Test
F00D8	1st Gear Clutch Test (62TE)	F01AC	Learn Latch Sector Home
F00DD	1st Gear Clutch Test (Non-RFE)	F01AD	LF Antenna Verification Test
F0100	1st Gear Clutch Test (RFE)	F01AE	PEM Replace
F00D9	2nd Gear Clutch Test (62TE)	F01B2	Actuate Drive Clutch Engage
F00DE	2nd Gear Clutch Test (Non-RFE)	F01B0	Sliding Door Close Test
F0101	2nd Gear Clutch Test (RFE)	F01B1	Sliding Door Open Test
F00DA	3rd Gear Clutch Test (62TE)	F01AF	Learn Side Identifier
F00DF	3rd Gear Clutch Test (Non-RFE)	F01B5	Calibrate Full Recline
F00E3	3rd Gear Clutch Test (RFE)	F01B6	Calibrate Stow
F00DB	4th Gear Clutch Test (62TE)	F01B3	Write Left Rear Seat Position
F00FE	EGR System Test	F01B4	Write Right Rear Seat Position
F00D4	Electric Vacuum Pump Test	F01B7	LRSM Re-adaption
F00E2	ESIM Forced Monitor Test	F01B9	Reset WIN Configuration
F00E6	ETC Throttle Follower Test	F01B8	WIN Replaced
F00FF	Injector Kill Test	F01BD	Siren Test
F00EC	Neutral Gate Test (62TE)	F01BC	ITM Initialize
F00EA	Neutral Gate Test (Non-RFE)	F01BB	ITM Initialize Siren
F00EB	Neutral Gate Test (RFE)	F01BE	Heated Steering Wheel Configuration
F00F3	O2 System Heater Test	F01BF	HIDT Calibration
F00E8	Overdrive Switch Test (Non-RFE)	F01C4	View Last VTA Trigger Cause
F00E9	Overdrive Switch Test (RFE)	F01C1	Auto Wipers
F00F4	Purge Vapors System Test	F01C3	Disable Radio Clock Display
F00DC	Reverse Gear Clutch Test (62TE)	F01C2	Unlock All Doors First Press
F00E0	Reverse Gear Clutch Test (Non-RFE)	F01C5	VTM transport mode status
F00E4	Reverse Gear Clutch Test (RFE)	F01C7	Active Grille Shutter Test
F00D6	Set Engine RPM	F01CA	Coolant Three Way Valve Test
F00ED	Shift Lever Position Test (62TE)	F01C6	Active Grille Shutter Replaced
F00EE	Shift Lever Position Test (Non-RFE)	F01C8	Clear Stored Accumulated Fuel Mass
F00EF	Shift Lever Position Test (RFE)	F01C9	Coolant Three Way Valve Replaced
F00F9	Thermistor Test (62TE)	F01CB	Reset VCM Adaptives
F00FB	Thermistor Test (Non-RFE)	F01CD	ECU SERIAL NUMBER Management
F00FC	Thermistor Test (RFE)	F01CE	Write Front and Rear nominal tire pressure values
F00F7	VVT System Test	F01CF	Aim Test
F00E7	Cam Crank Relearn		