

MaxiSys_SsangYong_V1.22 Function List (Note:For reference only)

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

Vehicle Type	System Name	Sub System	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
MUSSO	ECM	2.3 MSE/RATIO	●	●	●	●	●	0037
MUSSO	ECM	3.2 MSE/RATIO	●	●	●	●	●	0037
MUSSO	TCM	BTRA 4	●	●	●	●	○	0039
MUSSO	TCM	BTR BOSCH	●	●	●	●	○	
MUSSO	ABS	ABS 5.0	●	●	●	●	●	
MUSSO	ABS	ABS-ABD 5.0	●	●	●	●	●	
MUSSO	ABS	ABS-EBD 5.3	●	●	●	●	●	
MUSSO	ABS	ABD-EBD 5.3	●	●	●	●	●	
MUSSO	ABS	ABS 5.3(Running Change)	●	●	●	●	●	
MUSSO	ECS	ALL	●	●	●	●	●	
MUSSO	AIRBAG	ALL	○	●	●	○	○	
MUSSO	TOD	ALL	○	●	●	○	○	
MUSSO	TCCU(P/T)	ALL	●	○	○	○	○	0008, 0051
MUSSO	Huber EGR	ALL	●	●	●	○	○	0041, 0043, 0045
KORANDO	ECM	2.3 MSE/RATIO	●	●	●	●	●	0037
KORANDO	ECM	3.2 MSE/RATIO	●	●	●	●	●	0037
KORANDO	TCM	BTRA 4	●	●	●	●	○	0039
KORANDO	TCM	BTR BOSCH	●	●	●	●	○	
KORANDO	ABS	ABS 5.0	●	●	●	●	●	
KORANDO	ABS	ABS-ABD 5.0	●	●	●	●	●	
KORANDO	ABS	ABS-EBD 5.3	●	●	●	●	●	
KORANDO	ABS	ABD-EBD 5.3	●	●	●	●	●	
KORANDO	ABS	ABS 5.3(Running Change)	●	●	●	●	●	
KORANDO	ECS	ALL	●	●	●	●	●	
KORANDO	AIRBAG	ALL	○	●	●	○	○	
KORANDO	TOD	ALL	○	●	●	○	○	
KORANDO	TCCU(P/T)	ALL	●	○	○	○	○	0008, 0051
KORANDO	Huber EGR	ALL	●	●	●	○	○	0041, 0043, 0045
ISTANA	ECM	2.3 MSE/RATIO	●	●	●	●	●	0037
ISTANA	ABS	ABS 5.0 Free Running	●	●	●	●	●	
ISTANA	ABS	ABS (TEVES)	●	●	●	●	●	0011, 0013, 0015, 0017, 0019, 0021, 0023, 0025, 0027, 0029, 0031

Vehicle Type	System Name	Sub System	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
CHAIRMAN	ECM	3. 6 BOSCH	●	●	●	●	●	0037
CHAIRMAN	ECM	3. 2 DOHC BOSCH		●	●	●		
CHAIRMAN	ECM	2. 3 MSE/RATIO	●	●	●	●	●	0037
CHAIRMAN	ECM	2. 8 MSE/RATIO	●	●	●	●	●	0037
CHAIRMAN	ECM	3. 2 MSE/RATIO	●	●	●	●	●	0037
CHAIRMAN	TCM	BTRA 4	●	●	●	●	○	0039
CHAIRMAN	TCM	NAG 5 A/T	○	●	●	○	○	
CHAIRMAN	TCM	DC 5 A/T	●	●	●	●	○	0004, 0006
CHAIRMAN	ABS	ABS 5. 3(Running Change)	●	●	●	●	●	
CHAIRMAN	ABS	ABD 5. 3	●	●	●	●	●	
CHAIRMAN	ABS	ASR 5. 3	●	●	●	●	●	
CHAIRMAN	ABS	TEVES (ABS/ESP)	●	●	●	●	●	0011, 0013, 0015, 0017, 0019, 0021, 0023, 0025, 0027, 0029, 0031
CHAIRMAN	ABS	TEVES (ABS)	●	●	●	●	●	0011, 0013, 0015, 0017, 0019, 0021, 0023, 0025, 0027, 0029, 0031
CHAIRMAN	ECS	VDO	●	●	●	●	○	
CHAIRMAN	ECS	SACHS	●	●	●	●	○	
CHAIRMAN	AIRBAG	BOSCH	○	●	●	○	○	
CHAIRMAN	AIRBAG	BOSCH	○	●	●	○	○	
CHAIRMAN	AIRBAG	SRE-NCS	○	●	●	○	○	
CHAIRMAN	Power Trank	CHAIRMAN ALL	●	●	●	○	○	
CHAIRMAN	TPMS	CHAIRMAN ALL	●	●	●	●	○	
CHAIRMAN	Dual Rekes	CHAIRMAN ALL	○	●	●	○	○	
CHAIRMAN	IMMOBILIZER	GASOLINE	○	○	○	○	○	0008, 0051
CHAIRMAN	IMMOBILIZER	DIESEL	○	○	○	○	○	0012, 0010
REXTON	ECM	2. 3 MSE	●	●	●	●	●	0037
REXTON	ECM	2. 8 MSE	●	●	●	●	●	0037
REXTON	ECM	3. 2 MSE	●	●	●	●	●	0037
REXTON	ECM	DSL 2. 7 (C2I)	●	●	●	●	●	0033, 0035, 0047, 0049
REXTON	ECM	DSL 2. 7 (C3I)	●	●	●	●	●	0014, 0018, 0020
REXTON	TCM	BTRA 4	●	●	●	●	○	0039
REXTON	TCM	DC 5 A/T	●	●	●	●	○	0004, 0006
REXTON	ABS	TEVES (ABS/ESP)	●	●	●	●	●	0011, 0013, 0015, 0017, 0019, 0021, 0023, 0025, 0027, 0029, 0031
REXTON	ABS	Bosch	●	●	●	●	●	0001, 0005, 0007, 0009
REXTON	AIRBAG	SRE-NCS	○	●	●	○	○	
REXTON	AIRBAG	SRE-SMART	●	●	●	○	○	
REXTON	TOD	OLD	○	●	●	○	○	
REXTON	TOD	NEW	○	●	●	●	○	
REXTON	TCCU	OLD	●	○	○	○	○	0008, 0051
REXTON	TCCU	NEW	●	●	●	●	○	

Vehicle Type	System Name	Sub System	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
REXTON	Huber EGR	All	●	●	●	○	○	0041, 0043, 0045
REXTON	SSPS	All	●	●	●	○	○	
REXTON	TPMS	All	●	●	●	●	○	
REXTON	TGS Lever	All	●	●	●	○	○	
REXTON	IMMOBILIZER	GASOLINE	○	○	○	○	○	0008, 0051
REXTON	IMMOBILIZER	DIESEL	○	○	○	○	○	0012, 0010
RODIUS/STAVIC	ECM	DSL D27DT (C2I)	●	●	●	●	●	0014, 0018, 0020
RODIUS/STAVIC	ECM	DSL D27DT (C2I)	●	●	●	●	●	0033, 0035, 0047, 0049
RODIUS/STAVIC	ECM	DSL D27DT (C3I)	●	●	●	●	●	0014, 0018, 0020
RODIUS/STAVIC	ECM	DSL D27DT (C3I)	●	●	●	●	●	0033, 0035, 0047, 0049
RODIUS/STAVIC	ECM	3. 2 MSE/RATIO	●	●	●	●	●	0037
RODIUS/STAVIC	TCM	DC 5 A/T	●	●	●	●		0004, 0006
RODIUS/STAVIC	ABS	TEVES (ABS/ESP)	●	●	●	●	●	0011, 0013, 0015, 0017, 0019, 0021, 0023, 0025, 0027, 0029, 0031
RODIUS/STAVIC	AIRBAG	SRE-SMART	●	●	●	○	○	
RODIUS/STAVIC	TOD	NEW		●	●	●	○	
RODIUS/STAVIC	TCCU	NEW	●	●	●	●	○	
RODIUS/STAVIC	TGS Lever	All	●	●	●	○	○	
RODIUS/STAVIC	IMMOBILIZER	GASOLINE	○	○	○	○	○	0008, 0051
RODIUS/STAVIC	IMMOBILIZER	DIESEL	○	○	○	○	○	0012, 0010
KYRON	ECM	2. 3 MSE	●	●	●	●	●	0037
KYRON	ECM	3. 2 MSE	●	●	●	●	●	0037
KYRON	ECM	DSL 2. 0 (C2I)	●	●	●	●	●	0033, 0035, 0002, 0049
KYRON	ECM	DSL 2. 0 (C3I)	●	●	●	●	●	0016, 0018, 0020
KYRON	ECM	DSL 2. 7 (C2I)	●	●	●	●	●	0033, 0035, 0047, 0049
KYRON	ECM	DSL 2. 7 (C3I)	●	●	●	●	●	0014, 0018, 0020
KYRON	TCM	BTRA 4	●	●	●	●	○	0039
KYRON	TCM	DC 5 A/T	●	●	●	●	○	0004, 0006
KYRON	ABS	TEVES (ABS/ESP)	●	●	●	●	●	0011, 0013, 0015, 0017, 0019, 0021, 0023, 0025, 0027, 0029, 0031
KYRON	AIRBAG	SRE-SMART	●	●	●	○	○	
KYRON	TCCU	ALL	●	●	●	●	○	
KYRON	SSPS	ALL	●	●	●	○	○	
KYRON	TGS Lever	ALL	●	●	●	○	○	
KYRON	IMMOBILIZER	GASOLINE	○	○	○	○	○	0008, 0051
KYRON	IMMOBILIZER	DIESEL	○	○	○	○	○	0012, 0010
ACTYON	ECM	2. 3 MSE	●	●	●	●	●	0037
ACTYON	ECM	DSL 2. 0 (C2I)	●	●	●	●	●	0033, 0035, 0002, 0049
ACTYON	ECM	DSL 2. 0 (C3I)	●	●	●	●	●	0016, 0018, 0020
ACTYON	TCM	BTRA 4	●	●	●	●	○	0039

Vehicle Type	System Name	Sub System	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
ACTYON	TCM	DC 5 A/T	●	●	●	●	○	0004, 0006
ACTYON	ABS	TEVES (ABS/ESP)	●	●	●	●	●	0011, 0013, 0015, 0017, 0019, 0021, 0023, 0025, 0027, 0029, 0031
ACTYON	AIRBAG	SRE-SMART	●	●	●	○	○	
ACTYON	TCCU	ALL	●	●	●	●	○	
ACTYON	SSPS	ALL	●	●	●	○	○	
ACTYON	IMMOBILIZER	GASOLINE	○	○	○	○	○	0008, 0051
ACTYON	IMMOBILIZER	DIESEL	○	○	○	○	○	0012, 0010
KORANDO C	ECM	ALL	●	●	●	●	●	0032, 0034, 0036, 0038, 0040, 0042, 0044, 0046, 0048
KORANDO C	TCM	ALL	○	●	●	●	○	0028, 0030
KORANDO C	ABS/ESP	ALL	●	●	●	●	●	0024, 0026, 0050
KORANDO C	E-Coupling	ALL	●	●	●	●	○	
KORANDO C	EPS	ALL	●	●	●	●	○	0022
KORANDO C	BCM	ALL	●	●	●	●	○	
KORANDO C	SKM	ALL	●	○	○	●	○	

Special_Function

Index	Special Function Name	Index	Special Function Name
0001	Air Bleeding	0002	Injector Coding
0003	Rear right line Air Bleeding(RR)	0004	Reset Adaption
0005	Rear left line Air Bleeding(LR)	0006	Read and Write Adaption
0007	Front left line Air Bleeding(LF)	0008	Finger Data
0009	Front right line Air Bleeding(RF)	0010	Key Coding
0011	Select Sensor Reset Item	0012	Key Coding Status
0013	Pitch G-Sensor (4WD only)	0014	C3I 5 Injector Corrections
0015	Yaw G-sensor	0016	C3I 4 Injector Corrections
0017	Pressure Sensor	0018	Engine Variant Coding
0019	All listed sensors	0020	Chassis Variant Coding
0021	CLEAR VARIANT CODE	0022	Steering Reset
0023	AIR BLEEDING(TEVES)	0024	Coding Erase
0025	Air Bleeding(TEVES) Rear right line	0026	Longitudinal acceleration sensor
0027	Air Bleeding(TEVES) Rear left line	0028	TCU Adaptation Reset
0029	Air Bleeding(TEVES) Front left line	0030	TCU Initial hydraulic calibration
0031	Air Bleeding(TEVES) Front right line	0032	Injector Coding
0033	Leak Detection	0034	Engine Variant Coding
0035	Rail Pressure Reset	0036	Chassis Variant Coding
0037	ECU RESET	0038	EGR Position Relearning
0039	TPS VALUE CLEAR(DIESEL ONLY)	0040	Throttle Position Relearning
0041	Huber EGR VIN Write	0042	Swirl Valve Relearning
0043	Huber EGR Initial	0044	Rail Pressure Initialization
0045	Huber EGR System Reset	0046	O2 Sensor Initialization
0047	Injector Coding	0048	VIN Write
0049	Variant Coding	0050	Air Bleeding
0051	Key Coding		