

## MaxiSysPro\_Bugatti\_v7.50 Function List (Note:For reference only)

**NOTES:**

- This function is supported.                      ✘ This function may be supported which depends on the actual condition of the vehicle.
- This function is not supported.                ▲ This function is the new feature in this version.

**As for special function please refer to the special function table.**

Control Unit	Ecu Info.	Read Codes	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
ABS Brakes	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0006 0009
Auto Dist. Reg	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0006 0009
Engine	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0008
Auto Trans	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0006 0009
Auto HVAC	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0006 0009
Cent. Elect.	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0006 0009
Park/Steer Assist	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0006 0009
Airbags	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0006 0009
Steering wheel	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0006 0009
Instruments	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0006 0009
Aux. Heat	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0006 0009
CAN Gateway	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0006 0009
Engine II	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0006 0009
Engine III	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0006 0009
AWD	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0006 0009
Immobilizer	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0006 0009
Centr. Locks	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0006 0009
Navigation	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0006 0009
Inter. Monitor	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0006 0009
Central Conv.	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0006 0009
Xenon Range	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0006 0009
Radio	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0006 0009
Engine Conjunct.	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0006 0009
Diesel pump	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0006 0009
Electric drive	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0006 0009
Battery Regul.	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0006 0009
Battery charger	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0006 0009
Clutch	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0006 0009
Differential Locks	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0006 0009
Door Elect Driver	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0006 0009
Door Elect Pass.	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0006 0009
Door Rear Left	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0006 0009
Door Rear Right	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0006 0009
Braker Booster	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0006 0009
Braker Boost.Assi.	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0006 0009
Parking Brake	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0006 0009
Entry Assist Driver	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0006 0009
Entry Assist Passenger	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0006 0009
Steering Angle	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0006 0009
Susp. Elect.	●	●	●	●	✘	●	0001 0002 0003 0004 0005 0006 0009

Control Unit	Ecu Info.	Read Codes	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
Anti Slip	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Level Control	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Steering assistance	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Rear spoiler	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Stabilizers	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Chassis Control	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Acc/Start Auth.	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Tire pressure monitoring	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Telematics	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Seat Mem. Pass	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Auto Roof	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Seat Mem. Driver	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Seat Rear PS	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Parking aid	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Control Head	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Sound system	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
TV-Tuner	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Voice Control	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Telephone	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
HVAC Rear	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Roof Electronics	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Seat Rear DS	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Auxiliary Fuel Tank	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Wiper Electr.	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Left light control	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Right light control	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Auto. Lighting switch	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Towing Protection	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Trailer Function	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Sec.Air Heating	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Active Steering	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Position Sensing	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Lane Change	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Tire Pressure II	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Lane Maintain	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Back-up Cam.	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Sliding Door Left	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Driver Ident.	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Intercom	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Special Function	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Data Transfer	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Operations	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Trunk Elect.	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Auxiliary Heater	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Media Player 1	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Media Player 2	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Media Player 3	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Media Player 4	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Ctrl Head RR	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009

Control Unit	Ecu Info.	Read Codes	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
Ctrl Head LR	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Ctrl Head Roof	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Ctrl Head Dash	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Digital Radio	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Digital TV	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Centr. Electr. II	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Information Electr.	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Centr. Conv. II	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009
Inform. Electr. II	●	●	●	●	※	●	0001 0002 0003 0004 0005 0006 0009

## Specil\_Function

Index	Specil Function Name	Index	Specil Function Name
0001	Coding	0002	Basic Settings
0003	Adaptation	0004	Security Access
0005	AdvancedDataStream	0006	Single Reading
0007	Login CodingII	0008	Readiness
0009	Advanced ID	000A	OilReset
000B	EPB	000C	Write Vin
000D	Read login password	000E	DPF
000F	Coding Online(This function may be supported which depends on the actual condition of the vehicle)	000G	Key matching