

MaxiSysPro_LT3_V7.50 Function List (Note:For reference only)

NOTES:

- This function is supported. ※ This function may be supported which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.**

Control Unit	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Special Function
Engine Control Module 1	●	●	●	●	※	0001 0002 0003 0004 0006 0009
Engine Control Module LT3	●	●	●	●	※	0001 0002 0003 0004 0006 0009
Transmission Electronics LT3	●	●	●	●	※	0001 0002 0003 0004 0006 0009
Immobilizer LT3	●	●	●	●	※	0001 0002 0003 0004 0006 0009
Airbag LT3	●	●	●	●	※	0001 0002 0003 0004 0006 0009
Electronic Stability Program LT3	●	●	●	●	※	0001 0002 0003 0004 0006 0009
Dash Board LT3	●	●	●	●	※	0001 0002 0003 0004 0006 0009
Tachograph LT3	●	●	●	●	※	0001 0002 0003 0004 0006 0009
Tire Pressure Monitoring LT3	●	●	●	●	※	0001 0002 0003 0004 0006 0009
Electronic Ignition Starter Switch LT3	●	●	●	●	※	0001 0002 0003 0004 0006 0009
Remote Control LT3	●	●	●	●	※	0001 0002 0003 0004 0006 0009
Door Electronics Driver Side LT3	●	●	●	●	※	0001 0002 0003 0004 0006 0009
Air Conditioning LT3	●	●	●	●	※	0001 0002 0003 0004 0006 0009
Auxiliary Heater Fuel LT3	●	●	●	●	※	0001 0002 0003 0004 0006 0009
Auxiliary Heater Electric LT3	●	●	●	●	※	0001 0002 0003 0004 0006 0009
Parking Heater Water LT3	●	●	●	●	※	0001 0002 0003 0004 0006 0009
Radio Audio 5 LT3	●	●	●	●	※	0001 0002 0003 0004 0006 0009
Navigation LT3	●	●	●	●	※	0001 0002 0003 0004 0006 0009
Compact Disc Changer LT3	●	●	●	●	※	0001 0002 0003 0004 0006 0009
Telephone LT3	●	●	●	●	※	0001 0002 0003 0004 0006 0009
Display Control Unit Roof LT3	●	●	●	●	※	0001 0002 0003 0004 0006 0009
Upper Operationg Field LT3	●	●	●	●	※	0001 0002 0003 0004 0006 0009
Parking Aid LT3	●	●	●	●	※	0001 0002 0003 0004 0006 0009
Trailer Function LT3	●	●	●	●	※	0001 0002 0003 0004 0006 0009
Vehicle Electrical System Control Module LT3	●	●	●	●	※	0001 0002 0003 0004 0006 0009
Programmable Special Module LT3	●	●	●	●	※	0001 0002 0003 0004 0006 0009
Steering Column Tube Switch Module LT3	●	●	●	●	※	0001 0002 0003 0004 0006 0009
Battery Regulation LT3	●	●	●	●	※	0001 0002 0003 0004 0006 0009
Sliding Door Left LT3	●	●	●	●	※	0001 0002 0003 0004 0006 0009
Sliding Door Right LT3	●	●	●	●	※	0001 0002 0003 0004 0006 0009

Specil_Function

Index	Specil Function Name	Index	Specil Function Name
0001	Coding	0002	Basic Settings
0003	Adaptation	0004	Security Access
0005	AdvancedDataStream	0006	Single Reading
0007	Login CodingII	0008	Readiness
0009	Advanced ID	000A	OilReset
000B	EPB	000C	Write Vin
000D	Read login password	000E	DPF
000F	Coding Online(This function may be supported which depends on the actual condition of the vehicle)	000G	Key matching