

MaxiSysPro_Rolls-Royce_V9.80 Function List (Note:For reference only)

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.**

| Model Series | Part | Systems | Ecu Info. | Read DTC | Freeze Frame | Erase DTC | Live Data | Component activation | Physical HW |
|--------------|---------|---|-----------|----------|--------------|-----------|-----------|----------------------|-------------|
| RR1/RR2/RR3 | Drive | CAS Car Access System | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Drive | DME Motor Electronics | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Drive | DME Digital Motor Electronics 2 | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Drive | EGS transmission management | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Drive | EKPS Fuel-pump control | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Drive | VTC Valvetronic | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Drive | VTC2 Valvetronic 2 | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Chassis | ACC Active Cruise Control | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Chassis | ACC2 Active cruise control 2 | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Chassis | ARS Dynamic Drive | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Chassis | ARS Dynamic Drive 2 | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Chassis | CIM Chassis Integration Module | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Chassis | CIM2 Chassis Integration Module 2 | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Chassis | DSC Dynamic Stability Control | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Chassis | EDC Damper Control | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Chassis | EHC Electronic Ride-Height Control | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Chassis | EMF Parking brake | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Chassis | RDC Tyre pressure control | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | CEM Clean Energy Module | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | AHL Adaptive directional headlights | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | AHM Trailer module | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | AMP Amplifier | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | ANT Aerial/antenna tuner | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | ASK Audio system controller | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | BZM Control centre,centre console | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | FBZM Rear compartment,control centre,centre console | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | CD Control Display | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | CD-GW Control Display(Gateway) | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | SG-FD Control unit,rear-compartment display | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | SG-FD-GW Control unit,rear-compartment display(gateway) | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | FD Rear-compartment display | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | CDC CD Changer | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | CON Controller | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | FCON Rear compartment controller | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | DWA anti-theft alarm system | ● | ● | ● | ● | ● | ● | ○ |

| Model Series | Part | Systems | Ecu Info. | Read DTC | Freeze Frame | Erase DTC | Live Data | Component activation | Physical HW |
|--------------|------|--|-----------|----------|--------------|-----------|-----------|----------------------|-------------|
| RR1/RR2/RR3 | Body | IHKA Integrated automatic heating/air conditioning | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | FKA Rear heater/air conditioning | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | HKL Rear-lid lift | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | JBIT Japan Basis Interface Telephone | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | KHI Headset interface | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | INSTR Instrument cluster | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | LM Lights Module | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | LM2 Light module 2 | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | LM2 Light module 2 with adaptive headlight | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | LM2 AHL2 Light module 2 with adaptive headlight 2 | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | FLA High Beam Assist | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | FBI Flexible Bus Interface | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | DVDC DVD Changer | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | DAB Digital tuner | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | NAV Navigation computer | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | JNAV Navigation system, Japan | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | KNAV Navigation system, Korea | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | CNAV Navigation system, China | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | NAJ Navigation computer, Japan | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | NVK Night Vision camera | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | NVE Night Vision Electronics | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | PDC Park Distance Control | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | CA Comfort access system | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | RLS Rain/Light Sensor | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | PM Power Module | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | SASL Satellite, A-pillar, left | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | SASR Satellite, A-pillar, right | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | SBSL Satellite, B-pillar, left | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | SBSR Satellite, B-pillar, right | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | SFZ Satellite vehicle centre | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | SSBF Satellite, seat, passenger | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | SSFA Satellite, seat, driver | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | SSH Satellite, seat, rear | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | STVL Satellite, door, front left | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | STVR Satellite, door, front right | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | SHD Sliding/tilting sunroof | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | SHD Slide/tilt sunroof 2 | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | SINE Siren and tilt sensor | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | SMFA Seat module, driver | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | SMBF Seat module, passenger | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | SMFAH Seat module, driver's side, rear | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | SMBFH Seat module, passenger's side, rear | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | SDARS Satellite tuner | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | SHZH Independent/auxiliary heater | ● | ● | ● | ● | ● | ● | ○ |

| Model Series | Part | Systems | Ecu Info. | Read DTC | Freeze Frame | Erase DTC | Live Data | Component activation | Physical HW |
|--------------|---------|---|-----------|----------|--------------|-----------|-----------|----------------------|-------------|
| RR1/RR2/RR3 | Body | SVS Language processing system | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | SZL Switch centre, steering column | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | SEC2 Supplementary control unit 2 | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | IBOC Digital tuner US | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | TEL Telephone interface | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | TEL Telephone (USA) | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | TCU Telematic Control Unit | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | TMBFT Door module, passenger door | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | TMBFH Door module, passenger's side, rear | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | TMFAT Door module, driver's door | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | TMFAH Door module, driver's side, rear | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | VM Video Module | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | WIM Wiper module | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | ZBM Two-battery management | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | ZGM Central Gateway Module | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | SIM Safety and Information Module | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | SGM-ZGM Safety and Gateway Module (ZGM) | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | SGM-SIM Safety and Gateway Module (SIM) | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | MOST system analysis | ● | ● | ● | ● | ● | ● | ○ |
| RR1/RR2/RR3 | Body | CAN communication analysis | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Drive | CAS Car Access System | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Drive | DDE Diesel Electronics | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Drive | DME Digital Motor Electronics | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Drive | DME Digital Motor Electronics 2 | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Drive | EGS transmission management | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Drive | EKPS Fuel-pump control | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Drive | GWS Gear selector switch | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Chassis | AL active steering | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Chassis | DSC Dynamic Stability Control | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Chassis | EDCSHL Damper satellite, rear left | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Chassis | EDCSHR Damper satellite, rear right | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Chassis | EDCSVL Damper satellite, front left | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Chassis | EDCSVR Damper satellite, front right | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Chassis | EHC Electronic Ride-Height Control | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Chassis | EMF Parking brake | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Chassis | ICM Integrated Chassis Management | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Chassis | VDM Vertical Dynamics Management | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Chassis | VDM2 Vertical dynamics management | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | ACC Active Cruise Control | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | ACSM Crash Safety Module | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | AHM Trailer module | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | AMPT Top Hi-Fi amplifier | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | CBX-ECALL Combox emergency call | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | CBX-MEDIA Combox Multimedia | ● | ● | ● | ● | ● | ● | ○ |

| Model Series | Part | Systems | Ecu Info. | Read DTC | Freeze Frame | Erase DTC | Live Data | Component activation | Physical HW |
|--------------|------|--|-----------|----------|--------------|-----------|-----------|----------------------|-------------|
| RR4/RR5 | Body | CIC Car Information Computer | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | CID Central Information Display | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | CON Controller | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | DVDC DVD Changer | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | EMALI Electric-motor reel, left | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | EMARE Electric-motor reel, right | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | EME Electric machine electronics | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | EME2 Electrical machine electronics | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | FCON Rear compartment controller | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | FD Rear-compartment display | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | FD2 Rear-compartment display 2 | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | FKA Rear heater/air conditioning | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | FLA High Beam Assist | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | FRM Footwell module | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | FZD Function centre, roof | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | GZAL Targeted illumination, left | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | GZAR Targeted illumination, right | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | HKA Rear-cabin automatic A/C | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | HKL Rear-lid lift | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | HSR Rear-axle slip-angle control | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | HUD Head-Up Display | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | IHKA Integrated automatic heating/air conditioning | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | JBE Junction-box electronics | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | KAFAS Camera-based driver-assistance systems | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | INSTR Instrument cluster | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | LHML LED main light module, left | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | LHMR LED main light module, right | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | NVE Night Vision Electronics | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | PDC Park Distance Control | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | RAD Radio | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | RDC Tyre pressure control | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | RSE Rear Seat Entertainment | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | SDARS Satellite tuner | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | SMBF Seat module, passenger | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | SMBFH Seat module, passenger's side, rear | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | SME Accumulator-management electronics | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | SMFA Seat module, driver | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | SMFAH Seat module, driver's side, rear | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | SVT Servotronic | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | SWW Lane change warning | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | SZL Switch centre, steering column | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | STML Headlight driver module, left | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | STMR Headlight driver module, right | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | TRSVC allround-view camera | ● | ● | ● | ● | ● | ● | ○ |

| Model Series | Part | Systems | Ecu Info. | Read DTC | Freeze Frame | Erase DTC | Live Data | Component activation | Physical HW |
|--------------|------|------------------------------------|-----------|----------|--------------|-----------|-----------|----------------------|-------------|
| RR4/RR5 | Body | TBX Touchbox | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | ULF-SBX Interface box | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | ULF-SBX-H Interface box high | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | VM Video Module | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | VSW video switch | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | VTG Transfer case | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | ZGM Central Gateway Control Module | ● | ● | ● | ● | ● | ● | ○ |
| RR4/RR5 | Body | SDARS Satellite tuner | ● | ● | ● | ● | ● | ● | ○ |



Service Function List

| Part | Components | Status | Body Type |
|-------------|------------------------------|--------|---------------------|
| MAINTENANCE | CBS Reset | ● | RR1/RR2/RR3 RR4/RR5 |
| MAINTENANCE | CBS correction, vehicle data | ● | RR1/RR2/RR3 RR4/RR5 |